

Octanol-Water Partition Coefficients of Simple Organic Compounds

Cite as: Journal of Physical and Chemical Reference Data **18**, 1111 (1989); <https://doi.org/10.1063/1.555833>
Submitted: 21 July 1988 . Published Online: 15 October 2009

James Sangster



[View Online](#)



[Export Citation](#)

ARTICLES YOU MAY BE INTERESTED IN

[Evaluation of Data on Solubility of Simple Apolar Gases in Light and Heavy Water at High Temperature](#)

[Journal of Physical and Chemical Reference Data **18**, 1231 \(1989\); https://doi.org/10.1063/1.555834](#)

[Direct calculation of 1-octanol-water partition coefficients from adaptive biasing force molecular dynamics simulations](#)

[The Journal of Chemical Physics **137**, 014502 \(2012\); https://doi.org/10.1063/1.4730040](#)

[A Critical Review of Aqueous Solubilities, Vapor Pressures, Henry's Law Constants, and Octanol-Water Partition Coefficients of the Polychlorinated Biphenyls](#)

[Journal of Physical and Chemical Reference Data **15**, 911 \(1986\); https://doi.org/10.1063/1.555755](#)

Where in the **world** is AIP Publishing?
Find out where we are exhibiting next

AIP Publishing

Octanol-Water Partition Coefficients of Simple Organic Compounds

James Sangster

Sangster Research Laboratories, Suite M-3, 1270 Sherbrooke St. West, Montreal, Quebec, Canada H3G 1H7

Received July 21, 1988; revised manuscript received January 30, 1989

Octanol-water partition coefficients ($\log P$) for 611 simple organic compounds representing all principal classes have been retrieved from the literature. Available experimental details of measurement are documented from original articles. Pertinent thermodynamic relations are presented, with a discussion of direct and indirect methods of measurement. Reported $\log P$ data for each compound have been evaluated according to stated criteria, and recommended values (with uncertainty) are given.

Key words: octanol-water partition coefficient; organic compounds; hydrophobicity; hydrophilicity

Contents

List of tables	1111	2. General characteristics of some measurement and estimation methods for P	1118
List of symbols and abbreviations	1111	3. Partition coefficients of alkanes	1121
1. Introduction	1112	4. Partition coefficients of alkenes and alkynes	1123
1.1. General	1112	5. Partition coefficients of aromatics	1125
1.1.a. Definition	1112	6. Partition coefficients of cycloalkanes and cycloalkenes	1141
1.1.b. Scope of this evaluation	1112	7. Partition coefficients of mixed-type hydrocarbons	1143
1.1.c. Need for critical evaluation	1113	8. Partition coefficients of ethers	1144
1.2. Thermodynamics	1113	9. Partition coefficients of alcohols	1150
1.2.a. General equilibrium relations	1113	10. Partition coefficients of aldehydes	1163
1.2.b. Temperature dependence	1113	11. Partition coefficients of ketones	1165
1.2.c. Specific thermodynamic relations	1113	12. Partition coefficients of acids	1170
2. Methods of measurement	1116	13. Partition coefficients of esters	1177
2.1. Direct or "Experimental" methods	1116	14. Partition coefficients of halogenated compounds	1185
2.1.a. Shake-flask	1116	15. Partition coefficients of amines	1192
2.1.b. Generator column	1116	16. Partition coefficients of nitriles	1216
2.2. Indirect or "Calculation/correlation" methods	1117	17. Partition coefficients of nitro compounds	1219
2.2.a. Methods widely used and/or having some theoretical justification	1117	18. Partition coefficients of amides	1221
2.2.b. Other correlations	1117	19. Partition coefficients of sulphur compounds	1225
3. Comparison of methods of measurement or estimation	1117	20. Partition coefficients of other compounds	1226
4. Retrieval of data	1117		
5. Criteria for evaluation	1118		
6. Presentation of data in Tables 3-20	1119		
7. References	1227		

List of Tables

1. Temperature dependence of $\log P$ of some compounds at room temperature

1113

© 1989 by the U.S. Secretary of Commerce on behalf of the United States. This copyright is assigned to the American Institute of Physics and the American Chemical Society.
Reprints available from ACS; see Reprints Lists at back of issue

List of Symbols and Abbreviations

<i>a</i>	= activity
AMB	= ambient temperature
AQ	= octanol-saturated water phase
AS	= absorption spectrophotometry
<i>B</i>	= organic base
<i>c</i>	= concentration
<i>C_p</i>	= heat capacity at constant pressure
CR	= chemical reaction
<i>D</i>	= direct method
FL	= fluorescence
<i>G</i>	= Gibbs energy

GC	= generator column	x	= mole fraction
GLC	= gas-liquid chromatography	X	= solute
h	= chromatographic peak height, Eq. (28)	?	= doubtful Log P value; Code uncertain
H	= enthalpy		
HA	= organic acid	Greek	
H _M	= Henry's law constant	Δ	= difference in thermodynamic function
(RP)-HPLC	= (reverse-phase) high pressure liquid chromatography	γ	= volume-fraction activity coefficient
I	= indirect method	μ	= chemical potential
K	= Kjeldahl method	φ	= volume fraction
K _a	= acid ionization constant	ζ	= solubility (mol L ⁻¹)
l	= liquid		
m,n	= correlation constants, Eq. (10)	Superscripts	
NS	= neutral salt solution	aq	= octanol-saturated water phase
ORG	= water-saturated octanol phase	0	= standard state
p	= pressure	oct	= pure octanol phase
P	= partition coefficient	org	= water-saturated octanol phase
P _{app}	= apparent partition coefficient	sat	= phase saturated with solute
RC	= radiochemical method	w	= pure water phase
s	= solid	*	= Hansch & Leo "selected" Log P value
S	= entropy		
SF	= shake-flask method	Subscripts	
T	= temperature (kelvin)	app	= apparent (partition coefficient)
Temp.	= temperature of log P measurement (°C)	fus	= fusion
TN	= titration	f	= final
v	= volume (general)	i	= initial
V	= molar volume (L mol ⁻¹)	org	= water-saturated octanol phase
W	= octanol-saturated water solvent	tr	= transfer process
		X	= solute

1. Introduction

1.1. General

1.1.a. Definition

A pure substance may distribute itself between two partially miscible solvents in intimate contact, and the equilibrium ratio of solute concentrations in the two phases has come to be known as the distribution coefficient or partition coefficient.¹ In preparative organic chemistry, the use of solvents of greatly differing polarity (e.g., hydrocarbon and water) facilitates the extraction and purification of desired products. In addition, the biological activity of simple organic compounds was early found to correlate with their oil-water partition coefficients.² It became apparent that, for biological purposes a partition coefficient based on long-chain ester or alcohol solvents was more appropriate. After some deliberation, 1-octanol was chosen as the most useful lipophile solvent in these applications. Most correlation work has been done using the octanol-water pair, and this is the reason for its wide use and the existence of a great quantity of data on the subject.

The octanol-water partition coefficient of a substance X at a given temperature is, by general consent,¹ represented by P and defined by (for reasons explained later, the superscripts "org" and "aq" are used to denote mutually saturated phases, and "oct" and "w" for the pure solvents.)

$$P = [X]^{org}/[X]^{aq}, \quad (1)$$

i.e., the ratio of concentrations (mole/volume) at equilibrium; it is therefore unitless. In the interest of standardization and precision in interpretation, the partition coefficient is defined for the same species on both phases.¹ This is important in considering P of ionizable compounds such as organic

acids, amines, and quaternary ammonium salts, which may also form dimers or ion-pairs. This is discussed further in this Introduction.

In addition, the solvents represented in Eq. (1) are those mutually saturated with each other at the temperature of measurement. This is a natural consequence of the classical "shake-flask" or extraction method used in experimental measurement of P, and is to be taken into account for accuracy in measurement and thermodynamic interpretation.

Further, P is preferably defined as the quantity which is independent of concentration, i.e., that value for which the solute obeys Henry's law in both solvents simultaneously. In practice, this means a P determined at high dilution, or extrapolated to zero concentration. Since P as measured can range over many orders of magnitude (10⁻² to 10⁶), it is usually expressed as its decadic logarithm, log P.

1.1.b. Scope of this evaluation

This work proposes to have retrieved and evaluated most of the significant published experimentally determined values of log P of simple organic molecules. The word "simple" is taken here to indicate molecules containing no or only one polar functional group, i.e., a group having N,O,S and/or halogen atom. A few well-known exceptions (chloroform, CCl₄) have been included. This limits the number of substances involved and, as far as possible, avoids complications of interpretation due to the presence of neighboring polar groups. The compounds are those which are liquids or solids at ordinary temperatures and pressures, and no arbitrary upper carbon number cutoff limit has been imposed. Elements, inorganic, metal-organic and unstable species have been excluded, as well as quaternary ammonium and similar salts.

1.1.c. Need for critical evaluation

The partition coefficient, as properly defined, is a definite equilibrium physico-chemical property of a pure substance under specified conditions. It provides a useful quantitative parameter for representing the lipophilic/hydrophilic nature of the substance. It is a function of the Gibbs energy of transfer from water to octanol and hence describes the thermodynamic tendency for the compound to partition preferentially in different media. It is not surprising, therefore, that it has been widely used in many areas such as:

- design of drugs and pharmaceuticals,⁴
- prediction and correlation of bioconcentration⁵
- and soil and sediment sorption of organic pollutants,
- research on medicinal chemicals,
- modelling of environmental fate of organic chemicals,⁶
- toxicology of substances.

For many substances, $\log P$ has been measured by different laboratories and by different methods. The reported $\log P$ values of a single substance can sometimes vary a great deal; for example, those of *p,p'*-DDT cover a range of a factor of one hundred.² Large uncertainties in $\log P$ are undesirable in general. The accuracy of the simulation, by calculation, of the environmental fate of an organic chemical may become quite sensitive to uncertainties of input parameters (e.g., Mirex in Lake Ontario⁷). The successful development of additive-constitutive calculational schemes^{8,9} for $\log P$, based on molecular structure, requires a database of assessed accuracy. Finally, it is difficult, if not impossible, for the uninitiated user of $\log P$ data to distinguish accurate and inaccurate data by simple inspection.

1.2 Thermodynamics

The thermodynamic relationships between $\log P$ and other quantities will be examined in some detail in this section. Many experimental data on $\log P$ related thermodynamic quantities have appeared recently, some of high quality. Since these were not discussed in any detail in former compilations and reviews,^{1,2} the following exposition is meant to summarize the important thermodynamic relations in a concise and rigorous manner.

1.2.a. General equilibrium relations

The present thermodynamic analysis is a slightly edited restatement of the one currently being used to describe the two-phase system represented by the octanol-water partition coefficient.^{9,10,34,38,58} Like the current practice, it uses volume fractions as composition variable and volume fraction activity coefficients. This convention, when used in conjunction with the (volume-based) partition coefficient, simplifies the thermodynamic argument. An equivalent though incomplete, analysis using mole fractions is given elsewhere.^{33,39} If a liquid substance *X* is distributed between organic and aqueous phases at equilibrium, we can write for each phase⁹

$$\mu_X = \mu_X^0 + RT \ln a_X \quad (2)$$

$$= \mu_X^0 + RT \ln(\gamma_X \varphi_X), \quad (3)$$

where μ_X is the chemical potential of *X* in solution, μ_X^0 is the chemical potential of pure liquid *X*, a_X is its activity in solution, γ_X is the volume-fraction activity coefficient and φ_X is the volume fraction of *X* in the solution. From the defining Eqs. (2) and (3), the activity coefficient is normalized by $\gamma_X \rightarrow 1$ as $\varphi_X \rightarrow 1$.

By definition, in each phase we have

$$[X] V_X = \varphi_X, \quad (4)$$

where V_X is the (partial) molar volume of *X* in solution. (For dilute solutions of liquid nonelectrolytes in water or octanol, partial molar volume can be replaced by pure liquid molar volume without appreciable error.) At equilibrium, $\mu_X^{\text{org}} = \mu_X^{\text{aq}}$. Combining this equality with Eqs. (1), (3), and (4) yields⁹

$$\log P = \log(\gamma_X^{\text{aq}}/\gamma_X^{\text{org}}), \quad (5)$$

i.e., P is equivalent to the ratio of the Henrian activity coefficients of the solute in the phases. Equation (5) has been derived using the assumption that $V_X^{\text{aq}} = V_X^{\text{org}}$.

1.2.b. Temperature dependence

The variation of $\log P$ with temperature¹ is small, approximately $\pm 0.01 \text{ K}^{-1}$. Table 1 presents experimental data of $d(\log P)/dT$ for some specific compounds.

The thermodynamic transfer functions are closely related to $\log P$:

$$\Delta_{\text{tr}} G = -RT \ln P \quad (6)$$

$$d(\Delta_{\text{tr}} G)/dt = -\Delta_{\text{tr}} S \quad (7)$$

$$\Delta_{\text{tr}} G = \Delta_{\text{tr}} H - T\Delta_{\text{tr}} S \quad (8)$$

As a consequence of the definition of P , these transfer quantities are independent of concentration and refer to the difference: (function for solute in water-saturated octanol)—(function for solute in octanol-saturated water).

The temperature dependence of $\Delta_{\text{tr}} G$ and hence of $\log P$ can be represented by $\Delta_{\text{tr}} H$ and $\Delta_{\text{tr}} S$ through Eqs. (6), (7), and (8). A van't Hoff plot of $\ln P$ may be used to obtain

TABLE 1. Temperature dependence of $\log P$ of some compounds at room temperature

Substances	Temperature range, °C	$1000 d(\log P)/dT$, K^{-1}	Ref.
<i>n</i> -propylbenzene	10–35	≈ 0	10,11
chlorinated benzenes	13–33	–29 to –5	12
phenol	10–60	–3.4	16
phenol	20–50	–4.9	17
<i>p</i> -cresol	15–35	–7.5	18
phenol	15–35	–16	18
<i>m</i> -alkoxyphenols	15–35	–5 to –3	19
resorcinol	15–35	–8.8	19
substituted phenols	10–60	–8 to –1	16
substituted phenols	20–50	–3 to +10	17
chlorophenols	...	–8.6 (mean)	20
hydroxybenzoic acids	...	–14 (mean)	20
methyl nicotinate	5–25	7.4	14
ephedrine	15–40	8.1	15
methamphetamine	15–40	0.4	15
alkyl amidopyridines	20–40	2 to 6	13
methyl acetanilides	...	≈ 0 (mean)	20

enthalpy and entropy of transfer.¹⁷⁻²⁰ However, P is a Gibbs energy function—as are solubility and vapor-liquid equilibrium—and these functions are usually found to be relatively insensitive to temperature. The enthalpy of transfer may be more precisely determined²¹ either by direct experimental measurement in an isoperibol flow calorimeter^{22,23} (in which two immiscible phases are brought into direct contact) or indirectly from the calorimetric limiting enthalpies of solution in the two solvents separately.

As will be discussed in greater detail in the next section, both $\Delta_{tr} G$ and $\Delta_{tr} H$ may be determined from measurements on solutions based on the two solvents separately. This is a possible route, provided it is realized that solute thermodynamic functions in pure water or pure octanol may be significantly different from those in mutually saturated solvents.

1.2.c. Specific thermodynamic relations

Mutually saturated solvents.

From liquid-liquid equilibrium data^{2,4} the equilibrium mole fractions of octanol in the two-phase system water/*n*-octanol at 25 °C are 7.03×10^{-5} and 0.793. Saturated octanol thus contains an appreciable amount of water; the molar volume of wet octanol²⁵ is 126.6 cm³, and the water content is equivalent to 1.64 mol L⁻¹. The two phases in a shake-flask determination of P are ternary. The question whether or not the presence of the other solvent in a phase significantly alters the thermodynamic properties of the solute becomes important in considering recently elaborated “activity coefficient” methods of determining the partition coefficient.

For example, Berti *et al.*²² compared the transfer Gibbs energies from shake-flask log P values of some common solutes to those found from the directly measured Henrian activity coefficients of the same solutes in pure octanol and pure water. The differences in $\Delta_{tr} G$, 1 to 2 kJ mol⁻¹, is equivalent to differences of as much as ± 0.4 in log P , being negative or positive or zero, depending on the solute. Calorimetrically determined enthalpies of transfer of *m*-alkoxy phenols²⁶ in neat and mutually saturated solvents differed by up to 1.6 kJ mol⁻¹; the same effect is found in the corresponding enthalpies of solution^{22,26} from which the transfer enthalpies are derived. Again, the magnitude of the effect depends on the solute; the transfer enthalpies of *n*-alkanols²⁷ for example, are much less sensitive in this respect.

Platford^{28,29} used the isopiestic method to measure the limiting activity coefficients of CCl₄ and benzene in neat and mutually saturated solvents, and found no detectable difference in the results. Henrian activity coefficients in octanol for 22 monofunctional compounds were measured by gas chromatography²⁸; within experimental error the relation

$$P = \gamma_x^{\text{org}} / \gamma_x^{\text{act}}, \quad (9)$$

was valid.

Relationship with aqueous solubility.

Thermodynamic considerations have also elucidated the relation between log P and aqueous solubility, ζ , early proposed by Hansch *et al.*³⁰ Since both log P and ζ may be regarded as Gibbs energy transfer functions, an equation of the type

$$\log P = m \log \zeta + n, \quad (10)$$

might be expected to be valid, where m and n are correlation coefficients. A relation like Eq. (10), if true, would greatly reduce the experimental effort necessary to obtain P . The search for refinement and rationalization of Eq. (10) has been lively, giving rise to at least one polemic exchange in the literature.^{31,32}

A relation of the form of Eq. (10) can be derived from thermodynamic first principles.^{33,34} The case for a liquid solute will be given first, as a solid solute introduces a complication into the argument. For a liquid solute distributed at equilibrium between organic and aqueous solvents (The solvents are assumed to be mutually saturated, in order to keep the analysis as close as possible to the conditions in a real shake-flask situation.) Eq. (3) can be applied to both phases to give

$$(\gamma_x \varphi_x)^{\text{org}} = (\gamma_x \varphi_x)^{\text{aq}} \quad (11)$$

which, by Eq. (4) becomes

$$(\gamma_x [X])^{\text{org}} = (\gamma_x [X])^{\text{aq}}. \quad (12)$$

Consider now, as a separate system, the solute in saturation equilibrium in the aqueous solvent. On the assumption that the equilibrium free solute contains no solvent, Eq. (3) under these conditions becomes

$$\mu_x = \mu_x^0 = \mu_x^0 + RT \ln(\gamma_x \varphi_x)^{\text{sat}} \quad (13)$$

or

$$(\gamma_x \varphi_x)^{\text{sat}} = 1. \quad (14)$$

Combined with Eq. (4), this becomes

$$(\gamma_x c_x V_x)^{\text{sat}} = 1, \quad (15)$$

where c_x has units inverse to that of V_x . Recalling Eqs. (1) and (5),

$$P = [X]^{\text{org}} / [X]^{\text{aq}} = \gamma_x^{\text{aq}} / \gamma_x^{\text{org}}. \quad (16)$$

Introducing Eq. (15),

$$P = 1 / (\gamma_x^{\text{org}} \zeta_x^{\text{aq}} V_x) \quad (17)$$

$$\log P = -\log \zeta_x - \log(\gamma_x V_x)^{\text{org}}, \quad (18)$$

Eq. (18) has the same form of Eq. (10). Clearly, data for liquid solutes would all fall on a common linear plot of log P vs log ζ , with the following provisos:

ASSUMPTION 1: γ_x^{org} , the Henrian activity coefficient for liquid solutes in organic solvent, is the same for all solutes.

ASSUMPTION 2: ζ_x refers to water saturated with octanol.

ASSUMPTION 3: the solute obeys Henry's law for concentrations up to saturation in the aqueous solvent.

ASSUMPTION 4: the free liquid solute, as an equilibrium phase, contains no solvent (i.e., its activity is unity).

For solutes which are solid at temperature of measurement, fundamental equations such as Eq. (2) are valid. In this case, however, the reference state for μ_x^0 cannot be the pure solid, since it is desirable to keep the same Raoult's law convention for the activity coefficients. The approach is then

through solid-liquid equilibrium. For a component in equilibrium between solid and liquid phases,

$$\mu_x(s) = \mu_x(1), \quad (19)$$

$$\mu_x^0(s) + RT \ln a_x(s) = \mu_x^0(1) + RT \ln a_x(1), \quad (20)$$

$$\mu_x^0(1) - \mu_x^0(s) = RT \ln a_x(s)/a_x(1). \quad (21)$$

The quantity on the left-hand side of Eq. (21) is the Gibbs energy of fusion of the solute at temperature T , $\Delta_{\text{fus}} G_T^0$. If the equilibrium solid phase is pure solid, then

$$\Delta_{\text{fus}} G_T^0 = -RT \ln a_x(1). \quad (22)$$

For temperatures below the normal melting point of the solute, $\Delta_{\text{fus}} G_T^0$ refers to the process (solid \rightarrow supercooled liquid).^{34,35} Since the solution is saturated,

$$\Delta_{\text{fus}} G_T^0 = -RT \ln(\gamma_x \varphi_x)^{\text{sat}}. \quad (23)$$

The thermodynamic argument represented by Eqs. (12)–(18) can be repeated again, with Eq. (23). The result is

$$\begin{aligned} \log P = & -\Delta_{\text{fus}} G_T^0 / 2.303RT - \log \zeta_x \\ & - \log(\gamma_x V_x)^{\text{org}}, \end{aligned} \quad (24)$$

Eq. (24) is the same as Eq. (18), with the addition of the Gibbs energy of fusion term. The validity of Eq. (24) is of course subject to the same assumptions attached to Eq. (18).

For correlation purposes, the Gibbs energy of fusion to the supercooled liquid state may be expressed in terms of the usual fusion quantities:

$$\begin{aligned} -\Delta_{\text{fus}} G_T^0 / RT \\ = (\Delta_{\text{fus}} H^0 / 2.303R)(T - T_{\text{fus}}) / TT_{\text{fus}} \\ + (\Delta_{\text{fus}} C_p^0)(\ln(T/T_{\text{fus}}) + (T_{\text{fus}} - T)/T). \end{aligned} \quad (25)$$

In Eq. (25), the enthalpy and heat capacity quantities refer to corresponding changes at the normal melting point (T_{fus}). [The heat capacities of solid and liquid solute have been assumed to be independent of temperature. They are not so in general, and Eq. (25) could be modified to take this into account.] Eqs. (24) and (25) together are identical to Eq. (14) of Miller *et al.*³⁴ Eq. (25) may be simplified by putting $\Delta_{\text{fus}} C_p^0 = 0$ and³⁶ $\Delta_{\text{fus}} H^0 = T_{\text{fus}} \Delta_{\text{fus}} S^0 = 56.5 T_{\text{fus}}$ J mol⁻¹. The result is an expression equivalent to Eq. (26) of Mackay *et al.*³³

Apart from these simplifications, the four assumptions quoted above are of varying importance. The Henrian activity coefficient in octanol, γ_x^{oct} , has been estimated by indirect³³ and direct^{37,38} methods. It is clear, particularly for hydrophobic compounds, that this activity coefficient increases with molecular weight (or molar volume). The water solubility ζ_x is usually taken as that in pure water. The solubilities of organic compounds in octanol-saturated water are measurably different.^{26,38,39} The difference increases with molecular weight. It is difficult at present (if not impossible) to define precisely the individual errors introduced into Eqs. (18) and (24) by these assumptions and simplifications.^{33,38,39}

Ratio of solubilities.

It has been stated that P is equivalent to the ratio of solute solubilities in the two solvents,⁴⁰ or is well approximated by this ratio.³⁷ The thermodynamic justification for

liquid and solid solutes is derived from Eqs. (1), (15), and (22) for the case of two phases saturated with solute. The result is

$$P = \zeta_x^{\text{org}} / \zeta_x^{\text{aq}} \approx \zeta_x^{\text{oct}} / \zeta_x^w \quad (26)$$

As before, the important qualifying assumptions apply here also. There may be some fortuitous cancellation of effects. Yalkowsky *et al.*³⁷ have tested Eq. (26) using solubilities in neat solvents for 36 solid compounds and found reasonable, though not exact, correlation.

Henry's law.

The Henry's law constant, like $\log P$, is a limiting Gibbs energy quantity and its usefulness overlaps that of $\log P$.⁴¹ Henry's constant for a solute on the mole fraction scale, H_M , may be defined as⁴¹ (where x is the mole fraction of solute)

$$\lim_{x \rightarrow 0} (p/x) = H_M, \quad (27)$$

where p is the partial pressure of solute above the solution. Henrian behavior of solutes has been exploited⁴² in the "head-space gas chromatographic method" for measuring P . The principal feature of this method⁴³ is the sampling and quantitative analysis, by gas chromatography, of the vapor mixture above a liquid solution. In a measurement of P , the vapor above an unsaturated aqueous solution (volume v_1) of the solute is sampled and the gas chromatographic peak height (h_1) of the solute is obtained. A volume v_2 of octanol is added, and after equilibration the vapor is sampled and analyzed as before (h_2). The partition coefficient is then

$$P = v_1(h_1/h_2 - 1)/v_2. \quad (28)$$

Equation (28) assumes that Henry's law is obeyed by the solute in the aqueous phase; that H_M is independent of the presence of co-solvent; that there is a strict mass balance for the solute; and the vapor behaves ideally.

1.3. The case of ionizable solutes

In the present work, two types of organic compounds may ionize in aqueous solution, viz., acids (HA) and amines (B):



where A^- is the acid anion. [Water should appear on both sides of Eqs. (29) and (30), but since in dilute solution its activity is practically unity and does not change, it may be omitted from the thermodynamic analysis.] The thermodynamic dissociation constant is defined as

$$K_a = a(\text{H}^+) a(\text{A}^-) / a(\text{HA}) \quad (31)$$

after Eq. (29), and

$$K_b = a(\text{H}^+) a(\text{B}) / a(\text{BH}^+) \quad (32)$$

after Eq. (30). Since P is defined only for the same (undissociated) species in both phases, the *apparent* partition coefficient P_{app} (sometimes called distribution coefficient) measured in the presence of appreciable ionization according to Eqs. (29) and (30) will differ from P . It can be shown⁴⁴ that P_{app} and P for an acid are related by

$$P = P_{\text{app}} [1 + 10^{(pH - pK_a)}] \quad (33)$$

and for an amine by

$$P = P_{app} [1 + 10^{(pK_a - pH)}]. \quad (34)$$

For weak acids ($pK_a > 7$) or weak bases ($pK_a < 7$) in water, there is negligible ionization ($P_{app} = P$). For other compounds under some experimental conditions, there will be appreciable ionization. [For example, phenol is a very weak acid ($pK_a = 9.9$) and is not appreciably ionized in neutral solution. For pentachlorophenol, however, the alcoholic hydrogen atom is rendered more labile ($pK_a = 4.8$).] The measured values of P over the pH range 1.2–13.5 vary by more than three orders of magnitude.⁴⁵] In these cases, P_{app} may be corrected according to Eqs. (33) and (34), or a buffer of suitable pH may be used as the aqueous phase in order to suppress ionization. Some compounds (e.g., acids) may form dimers or other associated species in the organic phase. This source of error may be avoided by the use of sufficiently dilute solutions, which is usual practice.

2. Methods of Measurement

Values of P reported in the literature have been determined by many methods. Mention is made in this section of a rather large number of these, but only the more reliable or soundly based will be discussed in some detail. For the purposes of evaluation, the methods have been classified into two groups (direct and indirect). This division is made for convenience of discussion, and does not necessarily imply fundamental or far-reaching theoretical differences.

2.1. Direct or "experimental" methods

2.1.a. Shake-flask method

This classic extraction procedure is widely used and, with due attention to experimental conditions, manipulation and range of applicability produces reliable results. It has been described briefly⁴⁶ and necessary precautions have been discussed in some detail.^{1,3} The case of weakly ionized solutes has been given special attention.⁴⁷ In essence, the method is simple. A small amount of the solute is dissolved in either aqueous or organic phase, equilibrium partition is obtained by agitation, the phases are separated and one or both phases are analyzed for solute. Apart from requirements already mentioned in Sec. 1 of this review, a few of the other important precautions may be mentioned here.

Purity of chemicals.

Depending on the analytical method used, the presence of partitionable impurities in solvents or sample may lead to erroneous measured solute concentrations.

Mutually saturated solvents.

It is often the practice in this method to prepare a solution of known initial solute concentration c_i in one solvent, and equilibrate a definite volume v_1 of this with a definite volume v_2 of the other solvent. The final solute concentration c_f is measured in the first solvent and the partition coefficient is given by the ratio $(c_i - c_f)v_1/c_f v_2$ or its inverse. Since the densities of neat octanol and water-saturated octanol are measurably different, the use of presaturated solvents avoids any error through changes in solvent volume upon equilibration.

Mixing and separation.

Several different methods of agitation are used to mix the solvents into intimate contact. In general, prolonged violent shaking is not necessary and tends to cause emulsion formation. The phases separate under normal gravity and they are usually centrifuged to accelerate the separation of the smallest droplets.

Sampling.

Ideally, both phases are analyzed. This is not always done, for reasons of convenience and time. If only one phase is analyzed, a mass balance between the phases is assumed and it must be established that no solute has been lost by adsorption on glass, rubber stopper or other material used in manipulation. Since many solutes preferentially partition into the organic phase, care must be taken to ensure that sampling devices introduced into the phases do not inadvertently carry over one phase into the other.

Analysis.

Absorption spectrophotometry and gas-liquid chromatography are often used. There may be intermediate extraction and/or concentration steps, or one involving a chemical reaction. The usual precautions in quantitative analysis apply here.

Volatile solutes.

If the solute has an appreciable vapor pressure it may be necessary to consider the amount of vapor space in the libration vessel and details of manipulation during sampling, analysis, etc.

Since the shake-flask method is at times tedious and time-consuming, a number of automated or simplified versions have been used. Most are closed-loop flow devices:

- counter-current distribution (engineering design)
- Centrifugal partition chromatography⁴⁹ may be described as the addition of a high gravity field to a counter-current method.

- The AKUFVE system⁵⁰ uses continuous centrifugation to separate the phases, while the rapid mix, probe^{51,52} uses different membrane filters.

- the segmented flow device⁵³ is a miniaturized counter-current flow system.

- a three-phase partition system⁵⁴ is a kind of counter-current method using two aqueous phases:



where AQ_1 and AQ_2 are different aqueous buffers. This device is used principally for investigating kinetics of partition.

- the exponential concentration change method⁵⁵ may be regarded as a multi-step extraction procedure

2.1.b. Generator column method

The ordinary liquid chromatographic column can be adapted for the measurement of partition coefficients.^{10,11} The solid support is usually silanized diatomaceous silica. The column is loaded by pulling an unsaturated solution of the solute of interest at a known concentration through the column. The solute is eluted with octanol-saturated water, and the effluent is analyzed by high pressure liquid chromatography or gas-

omatography. A primary advantage of this design¹⁰ is the absence of any possibility of emulsion formation, since the solvents are brought into intimate contact by slow permeation of one through the other. It is a closed system and manipulation is minimized; it is a flow system and so interior surfaces in contact with solute in solution may be "conditioned", if necessary, without affecting accuracy.

2.2. Indirect or "Calculation/Correlation" Methods

a. Methods widely used and/or having some theoretical justification

The deduction of P from aqueous solubility and Henry's law constants has been discussed in Sec. 1.2.c. Probably the most widely used correlation method is that with solute distribution volumes or chromatographic capacity factors in reversed-phase high pressure liquid chromatography (RP-HPLC).⁵⁶⁻⁵⁸ The possibility of obtaining a single general purpose correlation has been extremely seductive, as evidenced by the large number of published attempts and detailed investigation of the interacting effects among solute polarity, eluent composition and chemical nature of the stationary phase.⁵⁹ The attempt cannot be described as totally successful, despite recent refinements such as coating the stationary phase with octanol⁶⁰⁻⁶² or dipalmitoyl phosphatidylcholine⁶³ and use of ω -hydroxy silica⁶⁴ as column packings. It appears that satisfactorily precise correlations are obtained when the results are extrapolated to 100% water as solvent or when homologous series plots are used.^{58,65} The method is easily automated.⁶⁶

Reverse-phase thin layer chromatography (RP-TLC)^{67,68} may be considered the two-dimensional analogue of RP-HPLC. The precision of RP-TLC, including a chemically modified version,⁶⁹ is generally inferior to RP-HPLC.

For weakly ionizable solutes, a potentiometric titration method has been used.⁷⁰ Sometimes called microelectrometric titration, this procedure yields values for both P and K_a in a single experiment. Equations have been given for difunctional acids⁷¹ and a completely automated version has been described.⁴⁴ An analogous thermometric titration procedure, based on the enthalpy of protonation of an amine, has also been used.⁷²

A statistical analysis for a correlation between logarithms of octanol-water and cyclohexane-water partition coefficients was carried out by Seiler⁷³ for 230 compounds. A linear relation was found, and the intercept included a term representing hydrogen bonding by the solute. The same relation was obtained for more accurate data⁵⁸ of homologous series with octanol-water and hexadecane-water solvent mixtures and predicted from a lattice-model theory.⁵⁸

Henrian activity coefficients of a solute in both solvents and hence P , may be calculated by the UNIFAC (UNI-Functional Group Activity Coefficients) group contribution model^{74,75,265}; the presence of co-solvent is easily accounted for in the calculation.

The additive-constitutive nature of $\log P$ is a property often displayed by many physico-chemical quantities. This effect has been successfully exploited^{2,8} in the invention of

two fragment constant additivity schemes for $\log P$. The two methods, while similar, are not identical and differ somewhat in accuracy, applicability and ease of use.⁹⁷ Hansch and Leo's method² has been packaged as an interactive computer program (CLOGP).⁷⁶ In a somewhat more elaborate version (MOLY),⁷⁷ the user draws the molecular structure on a graphics terminal.

2.2.b. Other correlations

Both Hansch and Leo's² and Rekker's⁸ fragment additivity schemes tend to be inaccurate for compounds with multiple halogen substitution. A nonlinear function has been devised⁷⁸ for multiply-substituted aromatic and heterocyclic compounds. A number of other quantities with which $\log P$ has been correlated are listed here:

- solute retention indices on two stationary phases in gas chromatography⁶⁷ (useful for volatile solutes)
- solute molar volume⁵⁸
- solute molecular surface area⁷⁹⁻⁸¹
- charge density^{40,82}
- solvatochromic parameters^{83,99}
- molar refraction⁸⁴
- solvent-dependent conformational analysis (SCAP)⁸⁵
- parachor^{86,87}
- membrane cell potentials⁸⁸
- elution times for adsorption on Tygon tubing⁸⁹
- molecular connectivity⁹⁰

3. Comparison of Methods of Measurement or Estimation

When one or more $\log P$ values of a substance are available to a user or evaluator who wishes to place an uncertainty on the single value, or deduce the most probably accurate value, the following considerations are pertinent: (i) the method of measurement or estimation used, together with any available experimental details, (ii) the perceived competence of the measuring laboratory or investigator, (iii) the date of the measurement. Knowledge of the general characteristics of methods of measurement of published P values is necessary for evaluation, even though their usefulness may be qualified by considerations (ii) and (iii) above in certain cases. Table 2 presents characteristics of some direct and indirect methods. Useful discussion is available, along with some tabulated results of intra- and inter-laboratory measurements by different methods.^{11,67,91-94} The consequences of the various considerations in Table 2 are discussed in Sec. 5 below.

4. Retrieval of Data

The basis of the literature search was the Pomona College $\log P$ Database, created and maintained by Prof. Hansch and Leo. It is the most complete compilation of its kind, available online (Technical Database Services, Inc., 10 Columbus Circle, New York, NY 10019) and updated twice yearly. The version of July 1987 was used for the present work. For January 1987-June 1988 the Subject Index of Chemical Abstracts was used to ensure a more complete

TABLE 2. General characteristics of some measurement and estimation methods for P .

Method	Optimal log P range (approx.)	Applicability	Strengths	Weaknesses
Shake-flask (SF)	— 2.5 to 4.5	General neutral species	Direct method Reliable when precautions taken	Time-consuming Requires attention to many details of procedure Less accurate at $\log P > 5$ Temperature control be inefficient
Generator column (G)	2 to 7	General, except for very hydrophilic compounds	Direct method No danger of emulsion Closed system Efficient temperature control Faster than SF	Column becomes strip of solute New column needed each solute Limited to lipophilic compounds Rather elaborate analytical equipment
Reverse-phase high-pressure liquid chromatography (HPLC)	0 to 6	Neutral species only	Fast, convenient Impurities do not interfere Analysis not required	Correlational method Single correlation plot not accurate
Water solubility correlation	2 to 6	Neutral species of limited water solubility	Convenient Has thermodynamic basis	Correlational method Single correlation plot inaccurate
Henrian activity coefficients	Depends upon route to activity coefficient	Neutral species	Thermodynamically exact	Ease of measurement accuracy depends upon route to activity coefficient
Fragmental constants	Same as SF, useful for extrapolation	Same as SF	Fast, convenient Reliable for molecules with not many polar groups	Requires expertise for complicated molecular Usable only for functional groups covered in scheme

coverage. During consultation of original articles, a number of other useful references were found and were incorporated into the present compilation.

For every log P datum of compounds investigated, the original literature reference was consulted, whenever available; in the case of direct methods of measurement, the following information was retrieved (its importance has been pointed out recently⁹⁸):

- temperature of measurement
- equilibration method
- analytical method
- aqueous phase (water, buffer, etc.)
- which phase(s) was analyzed
- if no details were given but a reference was made to another publication, this was noted and the information retrieved.

It was decided to include also a number of log P values obtained by indirect methods, since these are useful for evaluation and, at times, are the only reports available.

Of course, the original articles did not always contain any or all the information sought, but whatever was available was retrieved. The source of a number of the data in the Pomona College Database are unpublished results from, or private communications to Dr. Hansch and Dr. Leo. No experimental details are available concerning these data; in

the present evaluation they are classed as direct measurements. No log P values calculated from fragment constants appear in the compilation, although estimates by Hansch and Leo and Rekker methods were used occasionally as aids in evaluation. In the case of ionizable compounds the log P value given by the author or in the Database, whether corrected for ionization or not—was recorded; data were corrected by the present evaluator.

5. Criteria for Evaluation

The evaluator wishes to have as many aids and tools as can be found; the number and power of these tools vary according to the subject in hand. For example, in the critical evaluation of binary phase diagrams,⁹⁵ available excess thermodynamic data and other thermodynamic constraints (Gibbs-Duhem equation, phase rule, etc.) provide relatively stringent and objective guidelines to data evaluation. In the case of P , however, most of these constraints are not applicable, and the thermodynamics of solute distribution is inadequate at present to provide such constraints.²¹ Only Gibbs energy of distribution is well summarized in the more fragment constant schemes; the corresponding enthalpies of distribution data are, however, absent for the most part.

Wherever both direct and indirect methods are represented in the log *P* values for a given compound, more weight is given to those from direct methods. When necessary or possible, directly determined values are further weighted by the availability of experimental details. In the Pomona College Data Base—and also in the present compilation—Hansch and Leo's selected values are indicated by asterisk. This is a valuable guide in evaluation. In some cases, a recently determined (or redetermined) value by direct method under optimum conditions is a deciding factor. In doubtful cases where the spread in reported values is wide, no direct determinations are at hand, it is helpful to consider simultaneously the value from fragment constant schemes. The Hansch and Leo method was followed in a slightly simplified version,⁹⁶ and the Rekker method also in a simplified version.⁹² It has been found⁹⁷ that both methods generally yield similar results, particularly for the simple molecules considered in the present work.

In those cases where only an asterisked log *P* value is reported, an uncertainty of 10%—considered a fair estimate⁹²—was assigned. Where the recommended value differs markedly from experimental values, this was because more weight was given to log *P* from additivity schemes; the certainty is correspondingly larger.

Based on these considerations, a recommended value is given for each compound, together with an uncertainty (±) in parentheses. This uncertainty is neither simply the standard deviation of all recorded values nor does it represent the total range of all recorded values. Rather it represents the range in which, in the evaluator's judgment, the true value lies. Thus the uncertainty may be large when only one reported datum exists, and smaller according to the number and consistency of reported data. It should be clear in the discussion to this point that there is always an irreducible minimum of arbitrariness in this kind of evaluation.

6. Presentation of Data in Tables 3–20

Retrieved data for 600 simple organic compounds are presented in these Tables according to chemical type:

Table No.

Class of compound

3	Alkanes
4	Alkenes and alkynes
5	Aromatics
6	Cycloalkanes and cycloalkenes
7	Mixed-type hydrocarbons
8	Ethers
9	Alcohols
10	Aldehydes
11	Ketones
12	Acids
13	Esters
14	Halogenated compounds
15	Amines
16	Nitriles
17	Nitro compounds
18	Amides
19	Sulphur compounds
20	Other

Within each table, the general order is by increasing carbon number, then by increasing number of hydrogen atoms. Isomers are listed in increasing degree of branching, and in

the order of primary, secondary, and tertiary compounds. The only exception to these rules is in Table 13 (Esters) where the esters are listed according to the parent acid, e.g.,

Formic acid, *n*-propyl ester
Formic acid, phenyl ester
Acetic acid, methyl ester
Acetic acid, ethyl ester
etc.

but the other rules are adhered to.

Each compound is identified by, from left to right, the chemical formula, name(s) and CAS Registry number. The order of elements in the chemical formula is C, H, N, O, (Br, Cl, F, I), S. For acids and amines only, these are followed by the acid dissociation constant, *pK_a*. Unless otherwise noted, these are for 25 °C and were taken from standard references^{100–103} or from original articles. Some were estimated from data for similar compounds or according to well established methods⁹⁶.

The retrieved data themselves, for each compound, are presented under nine column headings. From left to right these are:

log *P*—the datum quoted in the study under consideration

Asterisk (*): Hansch and Leo selected value,
?: Doubtful value;

Code—this identifies the type of method used for determination:

D: direct method,
I: indirect method,
?: information insufficient or unavailable;

Ref.—source of data. Personal communications to, or unpublished data in the Pomona College Data Base are all assigned to Ref. 104.

Temp.—where original report mentioned temperature, this is indicated (in °C).

AMB: temperature quoted as “ambient;”

Equil. Method—method of equilibration:

GC: generator column
SF: shake-flask;

Anal. method—method used for analysis of the phases:

AS: absorption spectrophotometry,
CR: chemical reaction,
FL: fluorescence,
GLC: gas-liquid chromatography,
HPLC: high-pressure liquid chromatography,
K: Kjeldahl analysis for *N*,
RC: Radiochemical,
TN: acid-base titration;

Aq. phase—nature of the aqueous phase:

W: octanol-saturated water,
NS: neutral salt solution,
*pH*xxx: buffer solution of stated *pH*;

Phase(s) analyzed—AQ: aqueous,

ORG: organic,
one: either aqueous or organic (not specified);

Method ref.—investigator's stated source for method.

The indirect methods used to determine log *P* values

are indicated by short phrases (water solubility correlation, HPLC, etc.). The D and I values are listed in separate groups and placed in increasing order within each group. The last entry for each compound is a recommended log *P* value, with uncertainty in parentheses.

Auxiliary information is provided in footnotes at the end of each table. In Tables 12 and 15, ion corrected log *P* values (reported at source) are footnoted as such. All others are not ion corrected.

Table 3. Alkanes

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₅ H ₁₂	n-Pentane		CAS # 109-66-0					
2.50	D	30		SF	GLC	W	AQ	46
2.50	D	105		SF				
3.23	D	104	0				Both	
*3.39	D	104					Both	
3.62	D	9,10	25	G	GLC	W	Both	11
3.62	D	58	25	G	GLC	W	Both	9
3.60	I	58	25	from measured activity coefficients				
3.64	I	10		from measured activity coefficients				
3.45 (0.20)	Recommended							
C ₅ H ₁₂	2,2-Dimethylpropane (neopentane)		CAS # 463-82-1					
*3.11	D	104						
3.11 (0.20)	Recommended							
C ₆ H ₁₄	n-Hexane		CAS # 110-54-3					
4.11	D	9,10	25	G	GLC	W	Both	11
4.11	D	58	25	G	GLC	W	Both	11
3.00?	I	42		head-space chromatographic method				
3.90	I	106	20	from measured activity coefficients				
4.16	I	58	25	from measured activity coefficients				
4.20	I	10	25	from measured activity coefficients				
4.25	I	22	25	from measured activity coefficients				
4.00 (0.25)	Recommended							
C ₆ H ₁₄	3-Methylpentane		CAS # 96-14-0					
2.80?	T			head-space chromatographic method				
3.60 (0.20)	Recommended							
C ₆ H ₁₄	2,2-Dimethylbutane		CAS # 75-83-2					
*3.82	D	104					Both	
3.82 (0.40)	Recommended							
C ₆ H ₁₄	2,3-Dimethylbutane		CAS # 79-29-8					
*3.85	D	104					Both	
3.85 (0.40)	Recommended							

Table 3. Alkanes (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_6H_{14}		2,3-Dimethylbutane		CAS # 79-29-8				
*3.85	D	104					Both	
3.85 (0.40)	Recommended							
C_7H_{14}		n-Heptane		CAS # 142-82-5				
4.66	D	9,10	25	G	GLC	W	Both	11
4.66	D	58	25	G	GLC	W	Both	9
4.48	I	22	25	from measured activity coefficients				
4.73	I	58	25	from measured activity coefficients				
4.76	I	10	25	from measured activity coefficients				
4.50 (0.25)	Recommended							
C_8H_{18}		n-Octane		CAS # 111-65-9				
5.18	D	9,10	25	G	GLC	W	Both	11
5.18	D	58	25	G	GLC	W	Both	9
4.00?	I	109		head-space chromatographic method				
5.24	I	58	25	from measured activity coefficients				
5.29	I	10	25	from measured activity coefficients				
5.15 (0.45)	Recommended							
C_9H_{20}		n-Nonane		CAS # 111-84-2				
4.51	I	109		head-space chromatographic method				
5.65 (0.60)	Recommended							
$C_{10}H_{22}$		n-Decane		CAS # 124-18-5				
5.01	I	109		head-space chromatographic method				
6.25 (0.70)	Recommended							
$C_{12}H_{26}$		n-Dodecane		CAS # 112-40-3				
5.64 ^a	D	110						
6.10	I	109		head-space chromatographic method				
6.80 (1.00)	Recommended							
$C_{14}H_{30}$		n-Tetradecane		CAS # 629-59-4				
7.20	I	109		head-space chromatographic method				
8.00 (1.00)	Recommended							

^a W. E. Hammers, personal communication

Table 4. Alkenes and alkynes

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₄ H ₆	1,3-Butadiene		CAS # 106-99-0					
*1.99	D	104					Both	
1.99 (0.20)	Recommended							
C ₄ H ₆	2-Butyne		CAS # 503-17-3					
*1.46	D	104					Both	
1.46 (0.20)	Recommended							
C ₄ H ₈	cis-2-Butene		CAS # 590-18-1					
*2.33	D	104					Both	
2.33 (0.30)	Recommended							
C ₄ H ₈	trans-2-Butene		CAS # 624-64-6					
*2.31	D	104					Both	
2.31 (0.30)	Recommended							
C ₄ H ₈	2-Methylpropene (isobutene)		CAS # 115-11-7					
*2.34	D	104					Both	
*2.40	D	104					Both	
2.35 (0.40)	Recommended							
C ₅ H ₈	1,4-Pentadiene		CAS # 591-93-5					
*2.48	D	104					Both	
2.48 (0.30)	Recommended							
C ₅ H ₈	1-Pentyne		CAS # 627-19-0					
*1.98	D	30,111	25	SF	GLC	W	One	46
2.12	D	9,10	25	G	GLC	W	Both	11
1.98 (0.20)	Recommended							
C ₆ H ₁₀	1,5-Hexadiene		CAS # 592-42-7					
2.45?	D	104						
2.80 (0.30)	Recommended							

Table 4. Alkenes and alkynes (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_6H_{10}	1-Hexyne		CAS # 693-02-7					
2.73	D	9,10	25	G	GLC	W	Both	11
2.73 (0.30)	Recommended							
C_6H_{12}	1-Hexene		CAS # 592-41-6					
*3.39	D	9	25	G	GLC	W	Both	11
3.39	D	58	25	G	GLC	W	Both	9
3.47	D	10	25	G	HPLC	W	Both	
3.40	I	58	25	from measured activity coefficients				
3.47	I	10	25	from measured activity coefficients				
3.40 (0.10)	Recommended							
C_7H_{14}	1-Heptene		CAS # 592-76-7					
*3.99	D	9,10	25	G	GLC	W	Both	11
3.99	D	58	25	G	GLC	W	Both	9
4.06	I	58	25	from measured activity coefficients				
3.99 (0.10)	Recommended							
C_8H_{16}	1-Octene		CAS # 111-66-0					
4.56	D	58	25	G	GLC	W	Both	9
*4.57	D	9	25	G	GLC	W	Both	11
4.88	D	10	25	G	HPLC	W	Both	
4.72	I	58	25	from measured activity coefficients				
4.76	I	10	25	from measured activity coefficients				
4.57 (0.20)	Recommended							
C_9H_{18}	1-Nonene		CAS # 124-11-8					
*5.15	D	9	25	G	GLC	W	Both	11
5.15	D	58	25	G	GLC	W	Both	9
5.35	D	10	25	G	HPLC	W	Both	
5.31	I	58	25	from measured activity coefficients				
5.34	I	10	25	from measured activity coefficients				
5.15 (0.20)	Recommended							

Table 5. Aromatics

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₆	Benzene		CAS # 71-43-2					
1.56	D	40	25	SF	AS	pH7.4	Both	117
2.01	D	58	25	G	HPLC	W	Both	11
2.03	D	104				a	Both	
2.04	D	104				D ₂ O	Both	
2.04	D	115		SF	AS	NS	AQ	
2.11	D	113	25	SF	AS	W	Both	
2.12	D	108	23	SF	RC	W	Both	
*2.13	D	46	25	SF	AS	W	AQ	
2.13	D	114	25	SF	GLC	W	AQ	
2.13	D	10	25	G	HPLC	W		
2.15	D	104						
2.15	D	104					Both	
2.19	D	104				pH2.7		
1.83 ^c	I	65		HPLC				
1.90	I	33		from water solubility correlation				
1.98	I	58		from measured activity coefficients				
2.03	I	10	25	from measured activity coefficients				
2.13	I	106	25	from measured activity coefficients				28,29
2.15	I	74	25	from UNIFAC activity coefficients				
2.17 ^b	I	64		HPLC				
2.31	I	116		HPLC				
2.34	I	112		HPLC				
2.13 (0.10)	Recommended							
C ₆ D ₆	Hexadeuterobenzene		CAS # 1076-43-3					
2.03	D	115		SF	AS	NS	AQ	
2.03 (0.20)	Recommended							
C ₇ H ₈	Toluene		CAS # 108-88-3					
2.11	D	40	25	SF	AS	pH7.4	Both	117
2.21	D	108	23	SF	RC	W	Both	
2.61	D	115		SF	AS	NS	AQ	
2.65	D	9,10	25	G	HPLC	W	Both	11
2.65	D	58	25	G	HPLC	W	Both	11
2.68	D	118	23	SF	HPLC	W	Both	
2.69	D	46	25	SF	AS	W	AQ	
*2.73	D	104						
2.80	D	104						

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₇ H ₈		Toluene (continued)						
2.51	I	33	25		from water solubility correlation			
2.51 ^c	I	65		HPLC				
2.64	I	58	25		from measured activity coefficients			
2.65	I	64		HPLC				
2.66	I	10	25		from measured activity coefficients			
2.76	I	74	25		from UNIFAC activity coefficients			
2.77	I	119		HPLC				
2.88	I	75	25		from UNIFAC activity coefficients			
2.94	I	112		HPLC				
2.73 (0.10)	Recommended							
C ₇ D ₈		Octadeuterotoluene		CAS #	2037-26-5			
2.57	D	115		SF	AS	NS	AQ	
2.57 (0.20)	Recommended							
C ₈ H ₁₀		1,2-Dimethylbenzene (o-xylene)		CAS #	95-47-6			
*3.12	D	104						
3.13	D	9,10	25	G	HPLC	W	Both	11
2.77	D	104						
3.04	I	33	25		from water solubility correlation			
3.04 ^c	I	65		HPLC				
3.15	I	10	25		from measured activity coefficients			
3.12 (0.20)	Recommended							
C ₈ H ₁₀		1,3-Dimethylbenzene (m-xylene)		CAS #	108-38-3			
*3.20	D	104						
3.20	D	9,10	25	G	HPLC	W	Both	11
3.22 ^c	I	65		HPLC				
3.25	I	10	25		from measured activity coefficients			
3.37	I	57		HPLC				
3.20 (0.20)	Recommended							
C ₈ H ₁₀		1,4-Dimethylbenzene (p-xylene)		CAS #	106-42-3			
*3.15	D	104						
3.18	D	9,10	25	G	HPLC, GLC	W	Both	11
3.08	I	42			head-space chromatographic method			
3.15 ^c	I	65		HPLC				107
3.52	I	75	25		from UNIFAC activity coefficients			
3.15 (0.20)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₁₀	Ethylbenzene		CAS # 100-41-1					
3.13	D	9,10	25	G	HPLC	W	Both	11
3.13	D	58	25	G	HPLC	W	Both	11
*3.15	D	120		SF	AS	W	AQ	46
3.07 ^c	I	65		HPLC				
3.10	I	33	25	from water solubility correlation				
3.12	I	122		HPLC				
3.14	I	58	25	from measured activity coefficients				
3.15	I	10	25	from measured activity coefficients				
3.28	I	75	25	from UNIFAC activity coefficients				
3.15 (0.20)	Recommended							
C ₉ H ₈	Indene		CAS # 95-13-6					
*2.92	D	104						
3.26	I	65		HPLC				
2.92 (0.20)	Recommended							
C ₉ H ₁₂	n-Propylbenzene		CAS # 103-65-1					
3.44	D	118	23	SF	HPLC	W	Both	
3.57	D	104						
3.68	D	120		SF	AS	W	AQ	46
3.69 ^d	D	9,10	25	G	HPLC	W	Both	
3.69	D	58	25	G	HPLC	W	Both	11
*3.72 ^b	D	11	25	SF,G	HPLC	W	Both	
3.59	I	33	25	from water solubility correlation				
3.60	I	42		head-space chromatographic method				107
3.69	I	121		HPLC				
3.71	I	58	25	from measured activity coefficients				
3.73	I	10	25	from measured activity coefficients				
3.90	I	121		HPLC				
3.69 (0.15)	Recommended							
C ₉ H ₁₂	Isopropylbenzene		CAS # 98-82-8					
*3.66	D	104						
3.66	D	104						
3.51	I	42		head-space chromatographic method				107
3.52	I	122		HPLC				
3.63	I	33	25	from water solubility correlation				
3.66 (0.20)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₉ H ₁₂	1,2,3-Trimethylbenzene			CAS # 526-73-8				
3.55	D	9,10	25	G	HPLC	W	Both	11
*3.66	I	121		HPLC				
3.60 (0.20)	Recommended							
C ₉ H ₁₂	1,2,4-Trimethylbenzene			CAS # 95-63-6				
3.63	D	10	25	G	HPLC	W	Both	
3.58	I	33	25	from water solubility correlation				
*3.78	I			HPLC				
3.63 (0.15)	Recommended							
C ₉ H ₁₂	1,3,5-Trimethylbenzene (mesitylene)			CAS # 108-67-8				
*3.42	D	104						
3.84	I	121		HPLC				
4.15	I	75	25	from UNIFAC activity coefficients				
3.42 (0.30)	Recommended							
C ₉ H ₁₂	1-Methyl-2-ethylbenzene (2-ethyltoluene)			CAS # 611-14-3				
*3.53	D	9,10	25	G	HPLC	W	Both	11
3.63	I	42		head-space chromatographic method				107
3.53 (0.30)	Recommended							
C ₉ H ₁₂	1-Methyl-4-ethylbenzene (4-ethyltoluene)			CAS # 622-96-8				
3.63	I	42		head-space chromatographic method				107
3.63 (0.40)	Recommended							
C ₁₀ H ₈	Naphthalene			CAS # 91-20-3				
3.01	D	40	25	SF	AS	pH7.4	Both	117
3.28	D	94		SF		W	AQ	
*3.30	D	104						
3.35	D	68		SF	GLC	W	Both	
3.35	D	10	25	G	HPLC	W	Both	
3.36	D	86	20	SF	GLC	W	AQ	
3.36	D	113	25	SF	AS	W	Both	46
3.37	D	124						
3.40	D	126	23	SF	FL	W	AQ	

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{10}H_8$		Naphthalene (continued)						
3.45	D	125		SF				1
3.59	D	104						
3.17	I	56		HPLC				
3.29	I	119		HPLC				
3.30 ^b	I	33	25	from water solubility correlation				
3.30 ^b	I	64		HPLC				
3.35	I	42		head-space chromatographic method				107
3.43	I	65		HPLC				
3.65	I	75	25	from UNIFAC activity coefficients				
3.35 (0.10)	Recommended							
$C_{10}H_8$		Azulene	CAS # 275-51-4					
*3.20	D	104						
3.22	D	127		SF	AS	W	ORG	3
3.22 (0.20)	Recommended							
$C_{10}H_{14}$		n-Butylbenzene	CAS # 104-51-8					
*4.26	D	104						
4.28	D	9,10	25	G	HPLC, GLC	W	Both	11
4.29	D	58	25	G	HPLC	W	Both	11
4.01	I	42		head-space chromatographic method				107
4.18	I	68	25	from water solubility correlation				
4.34	I	58	25	from measured activity coefficients				
4.44	I	121		HPLC				
4.26 (0.15)	Recommended							
$C_{10}H_{14}$		tert-Butylbenzene	CAS # 98-06-6					
4.07	D	118	23	SF	HPLC	W	Both	
*4.11	D	104						
4.11	D	104						
4.11 (0.10)	Recommended							
$C_{10}H_{14}$		1-Methyl-4-isopropylbenzene (p-cymene)	CAS # 25155-15-1					
*4.10	D	108	23	SF	RC	W	Both	
4.14	I	74	25	from UNIFAC activity coefficients				
4.10 (0.10)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{10}H_{14}$					CAS # 488-23-3			
3.98	D	10	25	G	HPLC	W	Both	
*4.11	I	121		HPLC				
4.00 (0.20)	Recommended							
$C_{10}H_{14}$					CAS # 527-53-7			
4.04	D	10	25	G	HPLC	W	Both	
*4.17	I	121		HPLC				
4.10 (0.20)	Recommended							
$C_{10}H_{14}$					CAS # 95-93-2			
*4.00	D	104						
2.80?	I	42			head-space chromatographic method			107
4.24	I	123			HPLC			
4.10 (0.20)	Recommended							
$C_{11}H_{10}$					CAS # 90-12-0			
*3.87	D	126	23	SF	FL	W	AQ	
3.95	I	33	25		from water solubility correlation			
3.87 (0.20)	Recommended							
$C_{11}H_{10}$					CAS # 91-57-6			
*3.86	D	126	23	SF	FL	W	AQ	
4.11	D	113	25	SF	AS	W	Both	
3.90	I	33	25		from water solubility correlation			
4.01	I	65			HPLC			
4.09	I	119			HPLC			
4.00 (0.20)	Recommended							
$C_{11}H_{16}$					CAS # 538-68-1			
4.90	D	9,10	25	G	HPLC	W	Both	11
4.90 (0.30)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₁ H ₁₆		Pentamethylbenzene		CAS # 700-12-9				
*4.56	I	121		HPLC				
4.57	I	123		HPLC				
4.56 (0.40)	Recommended							
C ₁₂ H ₁₀		Biphenyl		CAS # 92-52-4				
3.16	D	40	25	SF	AS	pH7.4	Both	117
3.76	D	34	25	G	GLC	W	Both	11
3.89	D	129	25	G	HPLC	W	Both	
3.91	D	92		SF				
3.95	D	104						
4.04	D	125		SF				1
4.04	D	108	23	SF	HPLC	W	Both	
3.63 ^b	I	130		HPLC				
3.70 ^b	I	64		HPLC				
3.75	I	56		HPLC				
3.77	I	116		HPLC				
3.79	I	128		HPLC				
4.01	I	65		HPLC				
4.02	I	42		head-space chromatographic method				107
4.06	?	131						
4.10	I	68	25	from water solubility correlation				
4.13	I	119		HPLC				
4.14	I	33	25	from water solubility correlation				
4.24	I	37		from solubility ratio				
4.25	I	74	25	from UNIFAC activity coefficients				
3.98 (0.10)	Recommended							
C ₁₂ H ₁₀		Acenaphthene		CAS # 83-32-9				
3.91 ^{b,e}	D	110		SF				
*3.92	D	108	23	SF	RC	W	Both	
4.15	I	33	25	from water solubility correlation				
4.43	I	74	25	from UNIFAC activity coefficients				
3.92 (0.25)	Recommended							
C ₁₂ H ₁₂		1-Ethynaphthalene		CAS # 1127-76-0				
*4.39	D	38	23	SF	FL	W	AQ	
4.42	I	33	25	from water solubility correlation				
4.40 (0.40)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{12}H_{12}$					CAS # 939-27-5			
*4.38	D	126	23	SF	FL	W	AQ	
4.38 (0.50)	Recommended							
$C_{12}H_{12}$					CAS # 573-98-8			
*4.31	D	126	23	SF	FL	W	AQ	
4.31 (0.40)	Recommended							
$C_{12}H_{12}$					CAS # 575-41-7			
*4.42	D	126	23	SF	FL	W	AQ	
4.55	I	33	25	from water solubility	correlation			
4.42 (0.30)	Recommended							
$C_{12}H_{12}$					CAS # 571-58-4			
*4.37	D	126	23	SF	FL	W	AQ	
4.39	I	33	25	from water solubility	correlation			
4.37 (0.30)	Recommended							
$C_{12}H_{12}$					CAS # 571-61-9			
*4.38	D	126	23	SF	FL	W	AQ	
4.35	I	33	25	from water solubility	correlation			
4.38 (0.30)	Recommended							
$C_{12}H_{12}$					CAS # 575-37-1			
*4.44	D	126	23	SF	FL	W	AQ	
4.44 (0.30)	Recommended							
$C_{12}H_{12}$					CAS # 569-41-5			
*4.26	D	126	23	SF	FL	W	AQ	
4.26 (0.30)	Recommended							
$C_{12}H_{12}$					CAS # 581-42-0			
*4.31	D	126	23	SF	FL	W	AQ	
4.32	I	33	25	from water solubility	correlation			
4.31 (0.30)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{12}H_{18}$		n-Hexylbenzene		CAS # 1077-16-3				
*5.52	D	9,10	25	G	HPLC	W	Both	11
5.24	I	68	25		from water solubility correlation			
5.52 (0.30)	Recommended							
$C_{12}H_{18}$		Hexamethylbenzene		CAS # 87-85-4				
4.31	D	104						
4.61	D	10	25	G	HPLC	W	Both	
5.00	I	123			HPLC			
*5.11	I	121			HPLC			
4.75 (0.25)	Recommended							
$C_{13}H_{10}$		Fluorene		CAS # 86-73-7				
*4.18	D	104						
4.18	D	132		SF	GLC	pH7	Both	
4.18	D	37	30	SF	AS	W	Both	
4.18	I	68	25		from water solubility correlation			
4.23	I	119		HPLC				
4.27	I	33	25		from water solubility correlation			
4.34	I	37	25		from solubility ratio			
4.18 (0.20)	Recommended							
$C_{13}H_{12}$		Diphenylmethane		CAS # 101-81-5				
*4.14	D	104						
4.22	I	65		HPLC				
4.14 (0.20)	Recommended							
$C_{13}H_{12}$		4-Methylbiphenyl		CAS # 644-08-6				
4.63	D	81	25	G	GLC	W	Both	129
4.66	I	119		HPLC				
4.63 (0.20)	Recommended							
$C_{13}H_{14}$		1,4,5-Trimethylnaphthalene		CAS # 2131-41-1				
4.79	I	33	25		from water solubility correlation			
5.10 (0.50)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{13}H_{14}$		2,3,6-Trimethylnaphthalene			CAS # 829-26-5			
*4.73	D	126	23	SF	FL	W	AQ	
4.73 (0.40)	Recommended							
$C_{14}H_{10}$		Anthracene			CAS # 120-12-7			
*4.45	D	124		SF				
4.45	D	132		SF	GLC	pH7	Both	
4.54	D	113	25	SF	AS	W	Both	
3.45?	I	56		HPLC				
4.20	I	122		HPLC				
4.51	I	65		HPLC				
4.60	I	64		HPLC				
4.63	I	42		head-space chromatographic method				107
4.63	I	119		HPLC				
4.73	I	33	25	from water solubility correlation				
4.80	I	130		HPLC				
4.50 (0.15)	Recommended							
$C_{14}H_{10}$		Phenanthrene			CAS # 85-01-8			
*4.46	D	124		SF				
4.52	D	92		SF				
4.57	D	113	25	SF	AS	W	Both	
4.28	I	57		HPLC				
4.31	I	92		HPLC				
4.50	I	119		HPLC				
4.63	I	42		head-space chromatographic method				107
4.64	I	33	25	from water solubility correlation				
4.52 (0.15)	Recommended							
$C_{14}H_{12}$		trans-1,2-Diphenylethene (trans-stilbene)			CAS # 103-30-0			
*4.81	D	104						
4.81 (0.40)	Recommended							
$C_{14}H_{12}$		1-Methylfluorene			CAS # 1730-37-6			
*4.97 ^f	D	38						
4.97	I	119		HPLC				
4.97 (0.30)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{14}H_{12}$				9,10-Dihydroanthracene	CAS # 613-31-0			
*4.25	D	104						
4.25	(0.30)	Recommended						
$C_{14}H_{14}$				Bibenzyl (1,2-diphenylethane)	CAS # 103-29-7			
*4.79	D	104						
4.82	D	104						
4.60	I	116		HPLC				
4.71	I	65		HPLC				
4.82	I	37		from solubility ratio				
4.70	(0.20)	Recommended						
$C_{14}H_{14}$				4,4'-Dimethylbiphenyl	CAS # 613-33-2			
5.09	D	81	25	G	GLC	W	Both	129
5.09	(0.30)	Recommended						
$C_{14}H_{22}$				1-Phenyloctane (n-octylbenzene)	CAS # 2189-60-8			
6.30	D	68		SF	GLC	W	Both	
6.30	(0.40)	Recommended						
$C_{15}H_{12}$				1-Methylphenanthrene	CAS # 832-69-9			
5.08	I	119		HPLC				
5.08	(0.40)	Recommended						
$C_{15}H_{12}$				2-Methylphenanthrene	CAS # 2531-84-2			
5.24	I	119		HPLC				
5.24	(0.40)	Recommended						
$C_{15}H_{12}$				3-Methylphenanthrene	CAS # 832-71-3			
5.15	I	119		HPLC				
5.15	(0.40)	Recommended						

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{15}H_{12}$		9-Methylanthracene		CAS # 779-02-2				
*5.07	D	113	25	SF	AS	W	Both	
4.96	I	99		from solvatochromic parameters				
5.07	I	38	25	from water solubility correlation				
5.10	I	119		HPLC				
5.65	I	33	25	from water solubility correlation				
5.07 (0.20)	Recommended							
$C_{16}H_{10}$		Pyrene		CAS # 129-00-0				
*4.88	D	104						
5.09	D	133	AMB	SF	RC	W	Both	134,135
5.18	D	113	25	SF	AS	W	Both	
4.50	I	122		HPLC				
5.08	I	119		HPLC				
5.12	I	33	25	from water solubility correlation				
5.22	I	42		head-space chromatographic method				107
5.00 (0.20)	Recommended							
$C_{16}H_{10}$		Fluoranthene		CAS # 206-44-0				
5.20g	D	136						
4.85	I	119		HPLC				
5.22	I	38	25	from water solubility correlation				
5.29	I	33	25	from water solubility correlation				
5.20 (0.20)	Recommended							
$C_{16}H_{14}$		2-Ethylnanthracene		CAS # 52251-71-5				
5.85	I	119		HPLC				
5.85 (0.30)	Recommended							
$C_{16}H_{14}$		9,10-Dimethylnanthracene		CAS # 781-43-1				
5.25	I	38	25	from water solubility correlation				
5.25	I	33	25	from water solubility correlation				
5.48	I	99		from solvatochromic parameters				
5.69	I	119		HPLC				
5.69 (0.40)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{16}H_{26}$		1-Phenyldecane (n-decylbenzene)		CAS # 104-72-3				
7.35	D	68		SF	GLC	W	Both	
7.35 (0.40)	Recommended							
$C_{17}H_{12}$		1,2-Benzofluorene (benz(a)fluorene)		CAS # 238-84-6				
5.32	I	38	25	from water solubility correlation				
5.32	I	33	25	from water solubility correlation				
5.68	I	119		HPLC				
5.40 (0.40)	Recommended							
$C_{17}H_{12}$		2,3-Benzofluorene (benz(b)fluorene)		CAS # 243-17-4				
5.75	I	38	25	from water solubility correlation				
5.77	I	119		HPLC				
5.75 (0.40)	Recommended							
$C_{18}H_{12}$		9,10-Benzophenanthrene (triphenylene)		CAS # 217-59-4				
5.49	I	119		HPLC				
5.49 (0.50)	Recommended							
$C_{18}H_{12}$		1,2-Benzanthracene (benz(a)anthracene)		CAS # 56-55-3				
5.91	I	38	25	from water solubility correlation				
6.10	I	33	25	from water solubility correlation				
5.79	I	119		HPLC				
5.91 (0.40)	Recommended							
$C_{18}H_{12}$		Naphthacene (benz(b)anthracene)		CAS # 92-24-0				
*5.90	D	113	25	SF	AS	W	Both	
5.48	I	99		from solvatochromic parameters				
5.54	I	33	25	from water solubility correlation				
5.76	I	119		HPLC				
5.90	I	38	25	from water solubility correlation				
5.76 (0.30)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{18}H_{12}$		Chrysene		CAS # 218-01-9				
5.91	D	68		SF	GLC	W	Both	
5.73	I	119		HPLC				
5.79	I	38	25	from water solubility correlation				
6.01	I	33	25	from water solubility correlation				
5.86 (0.40)	Recommended							
$C_{18}H_{14}$		4-Phenylbiphenyl (p-terphenyl)		CAS # 26140-60-3				
*6.03	I	123		HPLC				
6.03 (0.50)	Recommended							
$C_{20}H_{12}$		Perylene		CAS # 198-55-0				
5.82	I	119		HPLC				
6.50	I	38	25	from water solubility correlation				
6.53	I	33	25	from water solubility correlation				
6.25 (0.50)	Recommended							
$C_{20}H_{12}$		3,4-Benzopyrene (benz(a)pyrene)		CAS # 50-32-8				
6.00	D	137	23	SF	AS	W	Both	
6.50	D	68		SF	GLC	W	Both	
*5.97	I	137		HPLC				
5.98 ^f	I	38	25	from water solubility correlation				
6.04	I	119		HPLC				
6.50	I	128		HPLC				
6.57	I	33	25	from water solubility correlation				
6.78	I	6		HPLC				
6.83	I	138		HPLC				
6.35 (0.40)	Recommended							
$C_{20}H_{12}$		3,4-Benzofluoranthene		CAS # 205-99-2				
5.78	I	119		HPLC				
5.78 (0.50)	Recommended							
$C_{20}H_{14}$		9-Phenylanthracene		CAS # 602-55-1				
6.01	I	119		HPLC				
6.01 (0.50)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₂₀ H ₁₆				7,12-Dimethylbenz(a)anthracene	CAS # 57-97-6			
*5.80	D	133	AMB	SF	RC	W	Both	134
5.80 (0.50)	Recommended							
C ₂₁ H ₁₆				3-Methylcholanthrene	CAS # 56-49-5			
*6.42	D	133	AMB	SF	RC	W	Both	134
6.69	I	33	25	from water solubility correlation				
7.11	I	38	25	from water solubility correlation				
6.75 (0.50)	Recommended							
C ₂₂ H ₁₂				Benzo(g,h,i)perylene	CAS # 191-24-2			
6.25	I	99		from solvatochromic parameters				
6.63	I	119		HPLC				
6.77	I	33	25	from water solubility correlation				
7.10	I	38	25	from water solubility correlation				
6.90 (0.40)	Recommended							
C ₂₂ H ₁₄				2,3:6,7-Dibenzanthracene (pentacene)				
7.19	I	38	25	from water solubility correlation				
7.19 (0.70)	Recommended							
C ₂₂ H ₁₄				1,2:3,4-Dibenzanthracene (dibenz(a,c)anthracene)				
7.19	I	38	25	from water solubility correlation				
7.19 (0.70)	Recommended							
C ₂₂ H ₁₄				1,2:5,6-Dibenzanthracene (dibenz(a,h)anthracene)	CAS # 53-70-3			
*6.50	D	133	AMB	SF	RC	W	Both	134
6.52	I	99		from solvatochromic parameters				
7.19	I	38	25	from water solubility correlation				
6.75 (0.40)	Recommended							
C ₂₂ H ₁₄				3,4-Benzenaphthacene (benz(a)naphthacene)	CAS # 226-88-0			
6.81	I	119		HPLC				
6.81 (0.70)	Recommended							

Table 5. Aromatics (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₂₄ H ₁₂	Coronene		CAS # 191-07-1					
*5.40	I	94		HPLC				
7.64	I	38	25		from water solubility correlation			
6.5 (1.0)	Recommended							

^a Phases were D₂O and C₈H₁₇OD.^b Average value.^c From a restricted correlation plot.^d Extrapolated to zero concentration in organic phase.^e D. Kotzias, personal communication^f It is not clear whether this is authors' value or one from the literature.^g W. Klopffer et al., personal communication.

Table 6. Cycloalkanes and cycloalkenes

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₅ H ₁₀	Cyclopentane		CAS # 287-92-3					
2.64	D	104						
*3.00	D	104						
2.05?	I	42		head-space chromatographic method				107
3.00 (0.30)	Recommended							
C ₆ H ₈	1,3-Cyclohexadiene		CAS # 592-57-4					
*2.47	D	104					Both	
2.47 (0.25)	Recommended							
C ₆ H ₈	1,4-Cyclohexadiene		CAS # 628-41-1					
*2.30	D	104						
2.30 (0.25)	Recommended							
C ₆ H ₁₀	Cyclohexene		CAS # 110-83-8					
1.90?	D	139		SF	GLC			1
*2.86	D	104					Both	
2.86 (0.25)	Recommended							
C ₆ H ₁₂	Cyclohexane		CAS # 110-82-7					
*3.44	D	104						
2.44?	I	42		head-space chromatographic method				107
3.70	I	22	25	from measured activity coefficients				
3.44 (0.35)	Recommended							
C ₆ H ₁₂	Methylcyclopentane		CAS # 96-37-7					
*3.37	D	104						
2.35?	I	42		head-space chromatographic method				107
3.37 (0.30)	Recommended							
C ₇ H ₈	1,3,5-Cycloheptatriene		CAS # 544-25-2					
*2.63	D	92		SF				
3.03	I	92		HPLC				
2.63 (0.40)	Recommended							

Table 6. Cycloalkanes and cycloalkenes (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_7H_{14}		Methylcyclohexane		CAS # 108-87-2				
2.76?	I	42			head-space chromatographic method			107
3.88 (0.40)	Recommended							
C_8H_{12}		1,5-Cyclooctadiene		CAS # 111-78-4				
3.16	D	92			SF			
3.94	I	92		HPLC				
3.55 (0.40)	Recommended							
C_8H_{16}		Cyclooctane		CAS # 292-64-8				
3.28?	I	42			head-space chromatographic method			107
4.45 (0.40)	Recommended							
$C_{10}^{II}H_{16}$		Adamantane		CAS # 281-23-2				
5.20?	D	140			SF	RC	pH7.4	Both
4.24 (0.50)	Recommended							1
$C_{12}H_{18}$		1,5,9-Cyclododecatriene		CAS # 4904-61-4				
4.12?	D	92,142			SF			
5.65	I	141		HPLC				
5.50 (0.40)	Recommended							

Table 7. Mixed-type hydrocarbons

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_8H_6		Ethyynylbenzene		CAS # 536-74-3				
*2.53	D	120		SF	AS	W	AQ	46
2.16	I	143		HPLC				
2.40 (0.25)	Recommended							
C_8H_8		Phenylethene (styrene)		CAS # 100-42-5				
*2.95	D	104						
3.16	D	108	23	SF	HPLC	W	Both	
2.76	I	144		HPLC				
2.90	I	119		HPLC				
3.39	I	74	25	from UNIFAC activity coefficients				
3.05 (0.30)	Recommended							
C_9H_{10}		1-Phenyl-1-propene		CAS # 637-50-3				
3.35	D	104						
3.35 (0.15)	Recommended							
C_9H_{10}		3-Phenyl-1-propene (allylbenzene)		CAS # 300-57-2				
*3.23	D	104						
3.23 (0.15)	Recommended							
C_9H_{10}		Indane		CAS # 496-11-7				
3.18	D	104						
3.33	D	104						
3.33 (0.30)	Recommended							
C_9H_{10}		Phenylcyclopropane (cyclopropylbenzene)		CAS # 873-49-4				
*3.27	D	104						
3.27 (0.25)	Recommended							
$C_{13}H_{10}$		Hept-1,3-diyn-5-enylbenzene		CAS # 13678-98-3				
4.76	I	145		HPLC				112,146
4.8 (1.0)	Recommended							

Table 7. Mixed-type hydrocarbons

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{14}H_{12}$				Vinylacenaphthene (isomer not specified)				
3.99	I	119		HPLC				
3.99 (0.40)		Recommended						

Table 8. Ethers

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_2H_4O				Epoxyethane (ethylene oxide)	CAS # 75-21-8			
*-0.30	D	104					Both	
-0.30 (0.20)		Recommended						
C_2H_6O				Oxapropane (dimethyl ether)	CAS # 115-10-6			
*0.10	D	104					Both	
0.10 (0.20)		Recommended						
C_3H_6O				1,2-Epoxypropane (propylene oxide)	CAS # 75-56-9			
*0.03	D	104						
0.03 (0.10)		Recommended						
C_4H_8O				1,4-Epoxy-1,3-butadiene (furan)	CAS # 110-00-9			
*1.34	D	104					Both	
1.34	D	104						
1.13	I	123		HPLC				
1.34 (0.20)		Recommended						
C_4H_6O				1,4-Epoxy-2-butene (2,5-dihydrofuran)	CAS # 1708-29-8			
*0.46	D	104					Both	
0.46 (0.25)		Recommended						

Table 8. Ethers (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₄ H ₈ O		3-Oxa-1-pentene (ethylvinyl ether)		CAS # 109-92-2				
*1.04	D	104						
1.04 (0.20)	Recommended							
C ₄ H ₈ O		1,4-Epoxybutane (tetrahydrofuran)		CAS # 109-99-9				
0.22	D	80		SF	GLC	W	ORG	
*0.46	D	104					Both	
0.46 (0.10)	Recommended							
C ₄ H ₁₀ O		3-Oxapentane (diethyl ether)		CAS # 60-29-7				
0.77	D	104						
0.83	D	147	20	SF	CR	W	Both	
*0.89	D	104					Both	148
0.89 (0.10)	Recommended							
C ₅ H ₆ O		2-Methylfuran		CAS # 534-22-5				
*1.85	D	104						
1.85 (0.20)	Recommended							
C ₅ H ₁₀ O		1,5-Epoxyptane (tetrahydropyran)		CAS # 142-68-7				
0.64	D	80		SF	GLC	W	ORG	
0.82 (0.20)	Recommended							
C ₅ H ₁₂ O		2-Oxa-3,3-dimethylbutane (methyl t-butyl ether)		CAS # 1634-04-4				
*0.94	D	80		SF	GLC	W	ORG	
0.94 (0.30)	Recommended							
C ₆ H ₈ O		2-Ethylfuran		CAS # 3208-16-0				
*2.40	D	104						
2.40 (0.20)	Recommended							
C ₆ H ₁₀ O		1,2-Epoxyhexane		CAS # 286-16-8				
1.26	D	149	37	SF	GLC	pH7.4	ORG	
1.30 (0.30)	Recommended							

Table 8. Ethers (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₁₂ O			cis-2,5-Dimethyltetrahydrofuran		CAS # 2144-41-4			
*1.22	D	80		SF	GLC	W	ORG	
1.22 (0.25)	Recommended							
C ₆ H ₁₂ O			trans-2,5-Dimethyltetrahydrofuran		CAS # 2390-94-5			
*1.34	D	80		SF	GLC	W	ORG	
1.34 (0.25)	Recommended							
C ₆ H ₁₄ O			4-Oxaheptane (di-n-propyl ether)		CAS # 111-43-3			
*2.03	D	104						
2.03 (0.15)	Recommended							
C ₆ H ₁₄ O			3-Oxa-2,4-dimethylpentane (diisopropyl ether)	CAS # 108-20-3				
*1.52	D	80		SF	GLC	W	ORG	
1.52 (0.25)	Recommended							
C ₆ H ₁₄ O			3-Oxaheptane (butylethyl ether)		CAS # 628-81-9			
*2.03	D	111		SF	GLC	W	one	46
2.03 (0.15)	Recommended							
C ₇ H ₈ O			Methoxybenzene (anisole)		CAS # 100-66-3			
2.04	D	40	25	SF	AS	pH 7.4	Both	117
*2.11	D	46	25	SF	AS	W	AQ	
2.08	?	150						
2.10	I	60		HPLC				
2.16 ^a	I	64		HPLC				
2.24	I	57		HPLC				
2.11 (0.10)	Recommended							
C ₈ H ₆ O			Benzofuran		CAS # 271-89-6			
*2.67	D	104						
2.67 (0.20)	Recommended							

Table 8. Ethers (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₈ O				Phenylepoxyethane (styrene oxide)	CAS # 96-09-3			
*1.51	D	149	37	SF	GLC	pH7.4	ORG	
*1.61	D	104						
1.84	D	151		SF	HPLC	NS	Both	
1.61 (0.20)								Recommended
C ₈ H ₈ O				2,3-Dihydrobenzofuran	CAS # 496-16-2			
*2.14	D	151		SF	HPLC	NS	Both	
2.14 (0.20)								Recommended
C ₈ H ₁₀ O				Benzylmethyl ether	CAS # 538-86-3			
*1.35	D	104						
1.35 (0.15)								Recommended
C ₈ H ₁₀ O				Ethoxybenzene (phenetole)	CAS # 103-73-1			
*2.51	D	104						
2.68	I	57		HPLC				
2.51 (0.20)								Recommended
C ₈ H ₁₀ O				2-Methylanisole	CAS # 578-58-5			
*2.74	D	104						
2.74 (0.20)								Recommended
C ₈ H ₁₀ O				3-Methylanisole	CAS # 100-84-5			
*2.66	D	104						
2.66 (0.20)								Rccommnded
C ₈ H ₁₀ O				4-Methylanisole	CAS # 104-93-8			
2.66	D	104						
*2.81	D	104						
2.81 (0.25)								Recommended
C ₈ H ₁₂ O				1-Vinyl-3,4-epoxycyclohexane				
2.08	D	149	37	SF	GLC	pH7.4	ORG	
1.90 (0.20)								Recommended

Table 8. Ethers (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_8H_{14}O$								
2.43	D	149	37	SF	GLC	pH7.4	ORG	
2.28 (0.20)	Recommended							
$C_8H_{18}O$								
*3.21	D	152	25	SF	GLC	W	?	
3.21 (0.25)	Recommended							
$C_8H_{18}O$								
*2.78	D	80		SF	GLC	W	ORG	
2.78 (0.25)	Recommended							
$C_9H_{10}O$								
*2.94	D	104						
2.94 (0.30)	Recommended							
$C_9H_{12}O$								
2.16	?	131						
2.16 (0.20)	Recommended							
$C_9H_{12}O$								
*3.18	D	104						
3.18 (0.30)	Recommended							
$C_9H_{12}O$								
*2.92	D	104						
2.92 (0.30)	Recommended							
$C_{10}H_{14}O$								
2.70	D	120		SF	AS	W	AQ	46
2.70 (0.30)	Recommended							

Table 8. Ethers (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₂ H ₈ O		Dibenzofuran			CAS # 132-64-9			
*4.12	D	104						
4.17	D	108	23	SF	HPLC	W	Both	
3.96	I	138		HPLC				
4.12 (0.20)	Recommended							
C ₁₂ H ₁₀ O		Diphenyl ether			CAS # 101-84-8			
4.08	D	108	23	SF	HPLC	W	Both	
4.20	D	135	20	SF	GLC	W	Both	
*4.21	D	104						
4.36	D	104						
3.87	I	65		HPLC				
4.21 (0.20)	Recommended							
C ₁₂ H ₂₂ O		1,2-Epoxycyclododecane						
4.70	I	141		HPLC				
4.57 (0.35)	Recommended							
C ₁₃ H ₁₂ O		Benzylphenyl ether			CAS # 946-80-5			
*3.79	D	104						
3.79 (0.30)	Recommended							

^a Average value.

Table 9. Alcohols

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_4O	Methanol		CAS # 76-56-1					
-0.82	D	147		SF	CR	W	Both	148
*-0.77	D	104					Both	
-0.71	D	27	25	SF	GLC	pH7	Both	158
-0.70 ^c	D	110		SF				
-0.68	D	154		SF	AS			
-0.66 ^a	D	155				pH6		
-0.52	D	156		SF	RC	b	Both	
-0.32	D	157	34	SF	RC	pH7.4	Both	
-0.64	?	153						
-0.74 (0.07)	Recommended							
$\text{C}_2\text{H}_6\text{O}$	Ethanol		CAS # 64-17-5					
-0.32 ^a	D	155		SF		pH6		
-0.32	D	147	20	SF	CR	W	Both	148
*-0.31	D	104					Both	
-0.30	D	159		SF	GLC	W	one	162
-0.30	D	160	25	SF	RC	W	Both	
-0.22	D	161				pH7.2		
-0.20	D	27	25	SF	GLC	pH7	Both	158
-0.18	D	156		SF	RC	b	Both	
-0.15	D	154		SF	AS			
-0.30 (0.03)	Recommended							
$\text{C}_3\text{H}_4\text{O}$	2-Propyn-1-ol		CAS # 107-19-7					
*-0.38	D	104						
-0.38 (0.20)	Recommended							
$\text{C}_3\text{H}_6\text{O}$	2-Propen-1-ol (allyl alcohol)		CAS # 107-18-6					
*0.17	D	104						
0.17 (0.10)	Recommended							
$\text{C}_3\text{H}_8\text{O}$	1-Propanol		CAS # 71-23-8					
*0.25	D	104					Both	
0.30	D	159		SF	GLC	W	one	162, 163
0.32	D	27	25	SF	GLC	pH7	Both	158
0.25 (0.05)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₃ H ₈ O	2-Propanol		CAS # 67-63-0					
*0.05	D	159		SF	GLC	W	one	162,163
0.14	I	164		HPLC				
0.05 (0.20)	Recommended							
C ₄ H ₁₀ O	1-Butanol		CAS # 71-36-3					
0.32?	D	157		SF	AS			
0.79	D	9,10	25	G	GLC	W	Both	11
0.79	D	58	25	G	GLC	W	Both	9
0.87	D	27	25	SF	GLC	pH7	Both	158
*0.88	D	104						
0.88 ^a	D	155		SF		pH6		
0.89	D	104						
0.93	D	156		SF	RC	b	Both	
0.76	I	10	25	from measured activity coefficients				
0.80	I	58	25	from measured activity coefficients				
1.02	I	165		HPLC				
0.84 (0.04)	Recommended							
C ₄ H ₁₀ O	2-Methyl-1-propanol (isobutanol)		CAS # 78-83-1					
0.65	D	104						
*0.76	D	159		SF	GLC	W	one	162,163
0.83	D	147	20	SF	CR	W	Both	148
0.76 (0.07)	Recommended							
C ₄ H ₁₀ O	2-Butanol		CAS # 78-92-2					
*0.61	D	111		SF	GLC	W	one	46
0.81	I	165		HPLC				
0.65 (0.10)	Recommended							
C ₄ H ₁₀ O	2-Methyl-2-propanol (t-butyl alcohol)		CAS # 75-65-0					
*0.35	D	104					Both	
0.37	D	111		SF	GLC	W	one	46
0.39	I	164		HPLC				
0.59	I	165		HPLC				
0.35 (0.10)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_5H_8O		2-Methyl-3-butyn-2-ol			CAS # 115-19-5			
*0.28	D	104						
0.28 (0.10)	Recommended							
$C_5H_{12}O$		1-Pentanol		CAS # 71-41-0				
1.40	D	104						
1.49	D	27	25	SF	GLC	pH7	Both	158
1.53	D	58	25	G	GLC	W	Both	9
1.53	D	9,10	25	G	GLC	W	Both	11
*1.56	D	104					Both	
1.33	I	122		HPLC				
1.48	I	165		HPLC				
1.55	I	58	25	from measured activity coefficients				
1.51 (0.05)	Recommended							
$C_5H_{12}O$		3-Methyl-1-butanol (isopentanol)		CAS # 123-51-3				
1.16	D	104						
1.42	D	104					Both	
1.16	I	164		HPLC				
1.28 (0.12)	Recommended							
$C_5H_{12}O$		2,2-Dimethyl-1-propanol		CAS # 75-84-3				
1.32	D	159		SF	GLC	W	one	162,163
1.36	D	30,111		SF	GLC	W	one	46
*1.31	I	164		HPLC				
1.31 (0.05)	Recommended							
$C_5H_{12}O$		2-Pentanol		CAS # 6032-29-7				
*1.19	I	164		HPLC				
1.34	I	165		HPLC				
1.25 (0.06)	Recommended							
$C_5H_{12}O$		3-Pentanol		CAS # 584-02-1				
*1.21	D	104					Both	
1.09	I	164		HPLC				
1.37	I	165		HPLC				
1.21 (0.10)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₅ H ₁₂ O					CAS # 598-75-4			
*1.28	D	159		SF	GLC	W	one	162,163
1.61	I	166		HPLC				
1.28 (0.20)	Recommended							
C ₅ H ₁₂ O					CAS # 75-85-4			
0.89	D	105		SF				
0.89	D	30	25	SF	GLC	W	AQ	46
0.89 (0.10)	Recommended							
C ₅ H ₁₂ O					2-Ethyl-2-propanol (tert-pentanol)	CAS # 75-84-4		
*0.89	D	167		SF	AS	W	AQ	46
1.15	I	165		HPLC				
0.95 (0.10)	Recommended							
C ₆ H ₆ O					Phenol	CAS # 108-95-2		
0.60?	D	169	18	SF	AS	pH6.8	AQ	
0.62?	D	172		SF	CR,AS	pH7.4	AQ	1
1.37	D	16	60	SF	CR,AS	pH2	AQ	
1.45	D	10	25	G	HPLC	W	Both	
1.46	D	86	20	SF	AS	W	AQ	46
*1.46	D	46	25	SF	AS	W	AQ	
1.48d	D	168		SF				175
1.48	D	104						
1.48	D	18	22	AKUFVE				50
1.51	D	171	25	SF	AS	pH5.6	AQ	
1.51	D	16	25	SF	CR,AS	pH2	AQ	
1.54	D	50	25	AKUFVE	AS	pH 8	Both	
1.54	D	17	35	SF	AS	NS	AQ	
1.55	D	16	10	SF	CR,AS	pH2	AQ	
1.75	D	47	21	SF	AS	pH7	ORG	
1.08	I	75	25	from UNIFAC activity coefficients				
1.11	I	121		HPLC				
1.35	I	116		HPLC				
1.42e	I	65		HPLC				
1.49	?	170						
1.55	?	177	25					
1.57	I	173	37	microelectrometric titration				
1.60	?	176	25					
1.61	I	174		W				
2.20	?	153		HPLC and thin-layer chromatography				
1.50 (0.05)	Recommended							178

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_6H_{12}O$		Cyclohexanol		CAS # 108-93-0				
*1.23	D	30,111		SF	GLC	W	one	46
1.23 (0.20)		Recommended						
$C_6H_{14}O$		1-Hexanol		CAS # 111-27-3				
2.02	D	152	25	SF	GLC	W	?	
2.03	D	9,10	25	G	GLC	W	Both	11
*2.03	D	104						
2.03	D	58	25	G	GLC	W	Both	9
2.04	D	27	25	SF	GLC	pH7	Both	158
1.86	I	122		HPLC				
1.99	I	165		HPLC				
2.03	I	164		HPLC				
2.05	I	58	25	from measured activity coefficients				
2.03 (0.03)		Recommended						
$C_6H_{14}O$		2-Hexanol		CAS # 626-93-7				
*1.76	I	164		HPLC				
1.76 (0.20)		Recommended						
$C_6H_{14}O$		3-Hexanol		CAS # 623-37-0				
*1.65	I	164		HPLC				
1.65 (0.20)		Recommended						
$C_6H_{14}O$		3,3-Dimethyl-2-butanol		CAS # 464-07-3				
*1.48	D	159		SF	GLC	W	one	162,163
1.48 (0.20)		Recommended						
C_7H_8O		Benzyl alcohol		CAS # 100-51-6				
1.00	D	179	20	SF	AS	NS	AQ	
1.10	D	156		SF	RC	b	Both	
1.10	D	104						
*1.10	D	30,46	25	SF	AS	W	AQ	
0.87	?	153						
1.06	I	65		HPLC				
1.05 (0.10)		Recommended						

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₇ H ₈ O		2-Methylphenol	(o-cresol)		CAS # 95-48-7			
1.93	D	173	37	SF		pH7.4		
*1.95	D	104						
1.96	D	10	25	G	HPLC	W	Both	
1.97	D	104						
2.01	D	17	35	SF	AS	NS	AQ	
2.04	D	180	22	SF	CR,AS	f	AQ	
1.83	I	174		HPLC and thin-layer chromatography				
2.09	I	166		HPLC				
1.98 (0.05)		Recommended						
C ₇ H ₈ O		3-Methylphenol	(m-cresol)		CAS # 108-39-4			
1.94	D	173	37	SF		pH7.4		
1.95d	D	168		SF				175
*1.96	D	46	25	SF	AS	W	AQ	
1.96	D	9,10	25	G	HPLC	W	Both	
2.01	D	104						
2.06	D	17	35	SF	AS	NS	AQ	
1.94	I	174		HPLC				
2.01	?	181						
1.98 (0.08)		Recommended						
C ₇ H ₈ O		4-Methylphenol	(p-cresol)		CAS # 106-44-5			
1.91	D	173	37	SF		pH7.4		
1.92	D	104						
*1.94	D	46	25	SF	AS	W	AQ	
1.95d	D	168		SF				175
1.98	D	18	22	SF	AS			50
1.99	D	171	25	SF	AS	pH5.6	AQ	
2.10	D	17	35	SF	AS	NS	AQ	
1.62	I	57		HPLC				
1.73	I	75	25	from UNIFAC activity coefficients				
1.97	I	166		HPLC				
2.03	I	174		HPLC				
2.10	?	177	25					
2.17	?	181						
1.97 (0.07)		Recommended						
C ₇ H ₁₄ O		cis-2-Methylcyclohexanol			CAS # 7443-70-1			
*1.84	I	164		HPLC				
1.84 (0.10)		Recommended						

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_7H_{14}O$							CAS # 7443-52-9	
*1.82	I	164		HPLC				
1.82 (0.10)	Recommended							
$C_7H_{14}O$							CAS # 589-91-3	
*1.79	D	104						
1.79 (0.15)	Recommended							
$C_7H_{16}O$							CAS # 111-70-6	
2.57	D	9,10	25	G	GLC	W	Both	
2.57	D	58	25	G	GLC	W	Both	9
2.60	D	164	25	G	GLC	W	Both	11
2.65	D	27	25	SF	GLC	pH7	Both	158
*2.72	D	104						
2.39	I	122		HPLC				
2.41	I	165		HPLC				
2.62 (0.10)	Recommended							
$C_7H_{16}O$							CAS # 543-49-7	
*2.31	D	104						
2.31 (0.20)	Recommended							
$C_7H_{16}O$							CAS # 589-82-2	
*2.24	D	104						
2.24 (0.20)	Recommended							
$C_7H_{16}O$							CAS # 589-55-9	
*2.22	D	104						
2.13	I	164		HPLC				
2.22 (0.10)	Recommended							
$C_8H_{10}O$							CAS # 587-03-1	
*1.60	D	46	25	SF	AS	W		AQ
1.60 (0.15)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_8H_{10}O$				4-Methylbenzyl alcohol	CAS # 589-18-4			
*1.58	D	46	25	SF	AS	W	AQ	
1.59	D	104						
1.58 (0.15)	Recommended							
$C_8H_{10}O$				2-Ethylphenol	CAS # 90-00-6			
*2.47	D	104						
2.64	?	181						
2.64	I	174		HPLC				
2.47 (0.15)	Recommended							
$C_8H_{10}O$				3-Ethylphenol	CAS # 620-17-7			
*2.40	D	46	25	SF	AS	W	AQ	
2.47	?	181						
2.59	I	174		HPLC				
2.50 (0.10)	Recommended							
$C_8H_{10}O$				4-Ethylphenol	CAS # 123-07-9			
*2.58	D	171	25	SF	AS	pH5.6	AQ	
2.60	D	17	35	SF	AS	NS	AQ	
2.26	?	170						
2.37	I	174		HPLC				
2.59	?	177	25					
2.50 (0.10)	Recommended							
$C_8H_{10}O$				1-Phenylethanol	CAS # 1517-69-7			
*1.42	D	104						
1.42 (0.15)	Recommended							
$C_8H_{10}O$				2-Phenylethanol	CAS # 60-12-8			
1.29	D	179	20	SF	AS	NS	AQ	
*1.36	D	120		SF	AS	W	AQ	46
1.36 (0.10)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_8H_{10}O$		2,4-Dimethylphenol		CAS #	105-67-9			
*2.30	D	182	20	SF	CR,AS	pH2	AQ	183
2.34	D	10	25	G	HPLC	W	Both	
2.42	D	108	23	SF	RC	W	Both	
2.54	D	17	35	SF	AS	NS	AQ	
2.35 (0.15)	Recommended							
$C_8H_{10}O$		2,5-Dimethylphenol		CAS #	95-87-4			
*2.33	D	182	20	SF	CR,AS	pH2	AQ	183
2.35	D	10	25	G	HPLC	W	Both	
2.34 (0.15)	Recommended							
$C_8H_{10}O$		2,6-Dimethylphenol		CAS #	576-26-1			
2.27	D	104						
2.31	D	10	25	G	HPLC	W	Both	
*2.36	D	104						
2.40	D	17	35	SF	AS	pH2	AQ	
2.07	I	57		HPLC				
2.38	I	166		HPLC				
2.36 (0.10)	Recommended							
$C_8H_{10}O$		3,4-Dimethylphenol		CAS #	95-65-8			
*2.23	D	182	20	SF	CR,AS	pH2	AQ	183
2.23 (0.25)	Recommended							
$C_8H_{10}O$		3,5-Dimethylphenol		CAS #	108-68-9			
*2.35	D	104						
2.55	D	17	35	SF	AS	NS	AQ	
2.31	?	170						
2.38	I	75	25	from UNIFAC	activity coefficients			
2.35 (0.15)	Recommended							
$C_8H_{16}O$		α, α, α -2,6-Dimethylcyclohexanol		CAS #	39170-84-8			
*2.37	I	164		HPLC				
2.37 (0.25)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₁₆ O				α, α, β -2,6-Dimethylcyclohexanol		CAS # 39170-83-7		
*2.10	I	164		HPLC				
2.10	(0.25)	Recommended						
C ₈ H ₁₆ O				α, β, β -2,6-Dimethylcyclohexanol		CAS # 42846-29-7		
*2.38	I	164		HPLC				
2.38	(0.25)	Recommended						
C ₈ H ₁₈ O				1-Octanol	CAS # 111-87-5			
3.15	D	147	25	SF	CR	W	AQ	148
3.16	D	184	23	SF		W	AQ	
3.27	D	27	25	SF	GLC	pH7	Both	158
2.80	I	165		HPLC				
2.92	I	122		HPLC				
*2.97	I	112		HPLC				
3.07	(0.10)	Recommended						
C ₈ H ₁₈ O				2-Octanol	CAS # 123-96-6			
*2.90	I	164		HPLC				
2.90	(0.25)	Recommended						
C ₈ H ₁₈ O				4-Octanol	CAS # 589-62-8			
*2.68	I	164		HPLC				
2.68	(0.25)	Recommended						
C ₉ H ₁₀ O				3-Phenyl-2-propen-1-ol (cinnamyl alcohol)	CAS # 104-54-1			
*1.95	D	104						
1.78	I	57		HPLC				
1.95	(0.20)	Recommended						
C ₉ H ₁₂ O				3-Phenyl-1-propanol	CAS # 122-97-4			
1.85	D	179	20	SF	AS	NS	AQ	
*1.88	D	120		SF	AS	W	AQ	46
1.88	(0.10)	Recommended						

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_9H_{12}O$		2-n-Propylphenol		CAS # 644-35-9				
*2.93	D	104						
2.93 (0.25)	Recommended							
$C_9H_{12}O$		4-n-Propylphenol		CAS # 645-56-7				
*3.20	D	17	35	SF	AS	NS	AQ	
3.21	?	177	25					
3.20 (0.10)	Recommended							
$C_9H_{12}O$		2-Isopropylphenol		CAS # 88-69-7				
*2.88	D	104						
2.88 (0.20)	Recommended							
$C_9H_{12}O$		2,3,6-Trimethylphenol		CAS # 2416-94-6				
2.67	D	10	25	G	HPLC	W	Both	
2.67 (0.35)	Recommended							
$C_9H_{12}O$		2,4,6-Trimethylphenol		CAS # 527-60-6				
2.73	D	10	25	G	HPLC	W	Both	
2.73 (0.35)	Recommended							
$C_9H_{20}O$		1-Nonanol		CAS # 143-08-8				
3.77	D	9,10	25	G	GLC	W	Both	11
*4.26	D	104						
4.02 (0.30)	Recommended							
$C_{10}H_8O$		1-Naphthol		CAS # 90-15-3				
2.31	D	185	20	SF	CR,AS	f	AQ	
*2.84	D	172		SF	FL	pH7.4		1
2.98	D	111		SF	AS	W	AQ	46
3.09	D	186		SF	g	pH6.5	AQ	
2.28	I	57		HPLC				
2.84 (0.20)	Recommended							

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{10}H_8O$		2-Naphthol		CAS # 135-19-3				
*2.70	D	187		SF	AS	f	Both	46
2.84	D	111		SF	AS	w	one	46
2.89	D	185	20	SF	CR,AS	f	AQ	
2.46 ^e	I	65		HPLC				
2.70 (0.15)		Recommended						
$C_{10}H_{14}O$		4-n-Butylphenol		CAS # 1638-22-8				
3.65	D	17	20	SF	AS	NS	AQ	
3.65 (0.20)		Recommended						
$C_{10}H_{14}O$		4-tert-Butylphenol		CAS # 98-54-4				
3.04 ^{c,h}	D	110		SF				
3.04 (0.40)		Recommended						
$C_{10}H_{20}O$		cis-4-tert-Butylcyclohexanol		CAS # 937-05-3				
*3.02	I	164		HPLC				
3.02 (0.40)		Recommended						
$C_{10}H_{20}O$		trans-4-tert-Butylcyclohexanol		CAS # 21862-63-5				
*3.09	I	164		HPLC				
3.09 (0.40)		Recommended						
$C_{10}H_{22}O$		1-Decanol		CAS # 112-30-1				
*4.57	D	104						
3.98	I	122		HPLC				
4.57 (0.50)		Recommended						
$C_{12}H_{26}O$		1-Dodecanol		CAS # 112-53-8				
*5.13	D	104						
5.24	D	132		SF	GLC	pH7	Both	
5.04	I	122		HPLC				
5.13 (0.30)		Recommended						

Table 9. Alcohols (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{13}H_{10}O$			7-Phenyl-4,6-diyn-hept-2-en-1-ol		CAS # 13641-62-8			
2.48	I	145		HPLC				
2.48 (0.50)		Recommended						
$C_{13}H_{12}O$			Diphenylmethanol		CAS # 91-01-0			
2.03	D	104						
*2.67	D	125		SF				1
2.67	D	104						
2.67 (0.25)		Recommended						
$C_{14}H_{14}O$			Phenyl-2-methylphenylmethanol		CAS # 5472-13-9			
*3.06	D	104						
3.06 (0.30)		Recommended						
$C_{14}H_{14}O$			Phenyl-4-methylphenylmethanol		CAS # 1517-63-1			
*3.13	D	104						
3.13 (0.30)		Recommended						
$C_{14}H_{22}O$			2,6-Di-sec-butylphenol		CAS # 5510-99-6			
4.38	I	104		HPLC				
4.4 (1.0)		Recommended						
$C_{19}H_{16}O$			Triphenylmethanol		CAS # 76-84-6			
*3.68	D	104						
3.68 (0.40)		Recommended						

^a J. Y. Park, unpublished data.^b Schistosome saline solution.^c D. Kotzias, personal communication.^d K. Thomae, personal communication.^e From a restricted correlation plot.^f "Acidified".^g Chemical reaction followed by density measurement.^h Average value.

Table 10. Aldehydes

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_2O		Methanal (formaldehyde)		CAS # 50-00-0				
*0.35	D	188	25	SF	CR	W	Both	
0.35 (0.10)	Recommended							
$\text{C}_2\text{H}_4\text{O}$		Ethanal (acetaldehyde)		CAS # 75-07-0				
0.52	D	10	25	G	HPLC	W	Both	
0.45 (0.10)	Recommended							
$\text{C}_3\text{H}_4\text{O}$		Propenal (acrolein)		CAS # 107-02-8				
-0.01	D	104						
-0.01 (0.25)	Recommended							
$\text{C}_3\text{H}_6\text{O}$		Propanal		CAS # 123-38-6				
*0.59	D	104						
0.59 (0.20)	Recommended							
$\text{C}_4\text{H}_8\text{O}$		Butanal		CAS # 123-72-8				
*0.88	D	104						
0.88 (0.20)	Recommended							
$\text{C}_5\text{H}_8\text{O}$		2-Ethylpropenal		CAS # 922-63-4				
*1.24	D	104						
1.24 (0.20)	Recommended							
$\text{C}_6\text{H}_{12}\text{O}$		Hexanal		CAS # 66-25-1				
*1.78	D	189	25	SF	GLC	pH7	AQ	46
1.78 (0.15)	Recommended							

Table 10. Aldehydes (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₇ H ₆ O		Benzaldehyde		CAS # 100-52-7				
1.43	D	190	25	SF	AS	W	ORG	191
1.45	D	171	25	SF	AS	pH5.6	AQ	
*1.48	D	104						
1.44 ^a	I	64		HPLC				
1.56	I	65		HPLC				
2.33	I	56		HPLC				
1.48 (0.08)		Recommended						
C ₈ H ₈ O		Phenylethanal		CAS # 122-78-1				
*1.78	D	104						
1.78 (0.25)		Recommended						
C ₈ H ₈ O		2-Methylbenzaldehyde		CAS # 529-20-4				
*2.26	D	192	AMB	SF	AS	W	AQ	
2.26 (0.20)		Recommended						
C ₁₃ H ₈ O		7-Phenylhept-2-ene-4,6-diynal		CAS # 20252-42-0				
3.09	I	145		HPLC				112,146
3.1 (1.0)		Recommended						

^a Average value.

Table 11. Ketones

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₃ H ₆ O					CAS # 67-64-1			
-0.48	D	193		SF	GLC	W	AQ	194
*-0.24	D	147	20	SF	CR	W	Both	148
-0.24 (0.10)	Recommended							
C ₄ H ₈ O					CAS # 78-93-3			
0.26	D	147	20	SF	CR	W	Both	148
0.26	D	193		SF	GLC	W	AQ	194
*0.29	D	30,111		SF	AS, GLC	W	one	46
0.50	D	104				D ₂ O		
0.69?	D	9,10	25	G	GLC	W	Both	11
0.29 (0.05)	Recommended							
C ₅ H ₁₀ O					CAS # 107-87-9			
0.78	D	193		SF	GLC	W	AQ	194
*0.91	D	189	25	SF	AS	pH7	AQ	46
0.84 (0.08)	Recommended							
C ₅ H ₁₀ O					CAS # 96-22-0			
0.99	D	9,10	25	G	GLC	W	Both	11
0.67	I	22	25	from measured activity coefficients				
0.75	I	10	25	from measured activity coefficients				
0.82 (0.15)	Recommended							
C ₅ H ₁₀ O					CAS # 563-80-4			
*0.56	D	193		SF	GLC	W	AQ	194
0.56 (0.10)	Recommended							
C ₆ H ₈ O					CAS # 2550-28-9			
*0.58	D	104						
0.58 (0.15)	Recommended							
C ₆ H ₈ O					CAS # 930-68-7			
*0.61	D	104						
0.61 (0.15)	Recommended							

Table 11. Ketones (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_6H_{10}O$		1-Hexen-5-one		CAS # 109-49-9				
*1.02	D	120		SF	AS	W	AQ	46
1.02 (0.10)	Recommended							
$C_6H_{10}O$		Cyclohexanone		CAS # 108-94-1				
*0.81	D	104						
0.81 (0.15)	Recommended							
$C_6H_{12}O$		2-Hexanone		CAS # 591-78-6				
1.19	D	193		SF	GLC	W	AQ	194
*1.38	D	120		SF	AS	W	AQ	46
1.39	I	57		HPLC				
1.38 (0.20)	Recommended							
$C_6H_{12}O$		4-Methyl-2-pentanone		CAS # 108-10-1				
*1.31	D	193		SF	GLC	W	AQ	194
1.31 (0.20)	Recommended							
$C_7H_{14}O$		2-Heptanone		CAS # 110-43-0				
*1.98	D	9,10	25	G	HPLC	W	Both	11
2.03	D	193		SF	GLC	W	AQ	194
2.08	I	10	25	from measured activity coefficients				
1.98 (0.15)	Recommended							
$C_7H_{14}O$		5-Methyl-2-hexanone		CAS # 110-12-3				
*1.88	D	193		SF	GLC	W	AQ	194
1.88 (0.15)	Recommended							

Table 11. Ketones (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₈ O		Acetophenone		CAS # 98-86-2				
1.58	D	46	25	SF	AS	W	AQ	
1.58	D	118	23	SF	HPLC	W	Both	
1.59	D	197	AMB	SF	RC	W	Both	
1.63	D	92		SF				
1.68	D	190	25	SF	AS	W	ORG	191
1.73	D	195		SF	AS	W	AQ	46
1.58	I	196		HPLC				
1.59	?	198						
1.65	I	92		HPLC				
1.71 ^a	I	64		HPLC				
1.72	I	65		HPLC				
1.80	I	121		HPLC				
1.63 (0.05)	Recommended							
C ₈ H ₁₆ O		2-Octanone		CAS # 111-13-7				
*2.37	D	193		SF	GLC	W	AQ	194
2.76	D	9,10	25	G	HPLC	W	Both	11
2.37 (0.10)	Recommended							
C ₉ H ₈ O		Acrylophenone		CAS # 768-03-6				
*1.88	D	104						
1.88 (0.30)	Recommended							
C ₉ H ₁₀ O		Propiophenone		CAS # 93-55-0				
*2.19	D	104						
2.21	D	190	25	SF	AS	W	ORG	191
2.16	I	57		HPLC				
2.19 (0.10)	Recommended							
C ₉ H ₁₀ O		4-Methylacetophenone		CAS # 122-00-9				
2.28	D	195		SF	AS	W	AQ	46
*2.10	I	196		HPLC				
2.19 (0.10)	Recommended							

Table 11. Ketones (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_9H_{10}O$				1-Phenyl-2-propanone		CAS # 103-79-7		
*1.44 1.17 ^a	D I	120 64		SF HPLC	AS	W	AQ	46
1.44 (0.10)	Recommended							
$C_9H_{18}O$				2-Nonanone		CAS # 821-55-6		
3.14 3.18	D D	193 9,10	25	SF G HPLC	GLC	W W	AQ Both	194 11
3.16 (0.20)	Recommended							
$C_9H_{18}O$				5-Methyl-2-octanone		CAS # 58654-67-4		
2.92	D	193		SF	GLC	W	AQ	194
2.92 (0.20)	Recommended							
$C_{10}H_{10}O$				4-Phenyl-3-buten-2-one (methylstyryl ketone)		CAS # 122-57-6		
*2.07	?	199						
2.07 (0.30)	Recommended							
$C_{10}H_{20}O$				2-Decanone		CAS # 693-54-9		
3.73 3.81	D D	193 9,10	25	SF G HPLC	GLC	W W	AQ Both	194 11
3.77 (0.40)	Recommended							
$C_{11}H_{14}O$				4-Isopropylacetophenone		CAS # 645-13-6		
2.98	I	196				thin-layer chromatography		
2.98 (0.30)	Recommended							
$C_{11}H_{22}O$				2-Undecanone		CAS # 112-12-9		
4.09	D	193		SF	GLC	W	AQ	194
4.09 (0.30)	Recommended							
$C_{12}H_{10}O$				1-Acetylazulene		CAS # 7206-57-7		
*2.87	D	127		SF	AS	W	ORG	3
2.87 (0.25)	Recommended							

Table 11. Ketones (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₂ H ₁₄ O		4-Phenylcyclohexanone		CAS # 4894-75-1				
2.30	I	143		HPLC				
2.45 (0.25)		Recommended						
C ₁₂ H ₂₂ O		Cyclododecanone		CAS # 830-13-7				
4.10	I	141		HPLC				
4.10 (0.40)		Recommended						
C ₁₃ H ₈ O		9-Fluorenone		CAS # 486-25-9				
*3.58	D	104						
3.58 (0.30)		Recommended						
C ₁₃ H ₁₀ O		Benzophenone		CAS # 119-61-9				
3.12	D	104						
*3.18	D	104						
3.58	D	190	25	SF	AS	W	ORG	191
3.18 (0.20)		Recommended						
C ₁₄ H ₁₂ O		2-Phenylacetophenone		CAS # 451-40-1				
*3.18	D	104						
3.18 (0.25)		Recommended						

^a Average value.

Table 12. Acids

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_2O_2	Methanoic (formic) acid		CAS # 64-18-6			$\text{pK}_a = 3.74$		
*-0.54	D	147	20	SF	T	W	Both	148
-0.54	D	200	25	SF	T	W	Both	
-0.54 (0.20)	Recommended							
$\text{C}_2\text{H}_4\text{O}_2$	Ethanoic (acetic) acid		CAS # 64-19-7			$\text{pK}_a = 4.76$		
-0.31	D	147	20	SF	T	W	Both	148
-0.30	D	201	28	SF	T	W	Both	
-0.29	D	202	25	SF	RC	pHl		
*-0.17	D	104						
-0.24 ^a	?	173	37					
-0.17 (0.20)	Recommended							
$\text{C}_3\text{H}_6\text{O}_2$	Propanoic acid		CAS # 79-09-4			$\text{pK}_a = 4.87$		
0.25	D	147	20	SF	T	W	Both	148
0.27	D	203		SF	T	W	AQ	204
*0.33	D	104						
0.32 ^a	?	173	37					
0.33 (0.10)	Recommended							
$\text{C}_4\text{H}_6\text{O}_2$	2-Butenoic (crotonic) acid (isomer not specified)		CAS # 3724-65-0			$\text{pK}_a \sim 4.5$		
*0.72	D	104						
0.72	D	104						
0.66 ^a	?	173						
0.72 (0.15)	Recommended							
$\text{C}_4\text{H}_6\text{O}_2$	2-Methylpropenoic (methacrylic) acid		CAS # 79-41-4			$\text{pK}_a = 4.66$		
*0.93	D	205	22	SF	T	W	AQ	
0.93 (0.20)	Recommended							
$\text{C}_4\text{H}_8\text{O}_2$	Butanoic acid		CAS # 107-92-6			$\text{pK}_a = 4.82$		
*0.79	D	147	20	SF	T	W	Both	148
0.83 ^a	?	173	37					
0.98	?	206						
0.79 (0.10)	Recommended							

Table 12. Acids (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₅ H ₁₀ O ₂		Pentanoic acid		CAS # 109-52-4		pK _a = 4.83		
*1.39 ^a	?	173	37					
1.51	?							
1.39 (0.15)	Recommended							
C ₆ H ₈ O ₂		2,4-Hexadienoic (sorbic) acid		CAS # 110-44-1		pK _a = 4.6 (est.)		
*1.33 ^a	?	173	37					
1.33 (0.25)	Recommended							
C ₆ H ₁₂ O ₂		Hexanoic (caproic) acid		CAS # 142-62-1		pK _a = 4.87		
1.88	D	104						
*1.92	D	104						
1.92	D	203		SF	T	W	AQ	204
2.09	D	207	25	SF	FL	pH0.5	AQ	
1.87	I	122		HPLC				
1.93	?	206						
2.07a	?	173	37					
1.92 (0.15)	Recommended							
C ₆ H ₁₂ O ₂		2-Methylpentanoic acid		CAS # 97-61-0		pK _a = 4.79 (18°C)		
*1.80	?	206						
1.80 (0.15)	Recommended							
C ₆ H ₁₂ O ₂		2-Ethylbutanoic acid		CAS # 88-09-5		pK _a = 4.74		
*1.68	?	206						
1.68 (0.20)	Recommended							
C ₇ H ₆ O ₂		Benzoic acid		CAS # 65-85-0		pK _a = 4.20		
1.24?	D	210	25	SF	AS	pH1	AQ	
1.68	D	208	25	SF	AS	W	Both	
*1.87	D	46	25	SF	AS	W	AQ	
1.88	D	207	25	SF	AS	pH0.5	AQ	
1.94	D	211		SF	RC	pH0.5	Both	

Table 12. Acids (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_7H_6O_2$		Benzoic acid (continued)						
1.47	I	37	25	from solubility ratio				
1.71 ^a	?	173	37					
1.87	I	44	25	microelectrometric titration				
1.97	I	209	25	microelectrometric titration				
2.03	?	150						
1.87 (0.10)	Recommended							
$C_8H_8O_2$		Phenylethanoic acid	CAS # 103-82-2		$pK_a = 4.31$			
1.18?	D	214	25	SF	b	W	Both	
*1.41	D	46	25	SF	AS	W	AQ	
1.45	D	213	25	SF	AS	pH3.5	Both	
1.51	D	154		SF	AS			
1.45 ^a	?	173	37					
1.95?	I	123		HPLC				
1.41 (0.15)	Recommended							
$C_8H_8O_2$		2-Methylbenzoic acid	CAS # 118-90-1		$pK_a = 3.92$			
2.18	D	215	25	SF	AS	W	AQ	
*2.46	D	104				pH1		
2.46 (0.20)	Recommended							
$C_8H_8O_2$		3-Methylbenzoic acid	CAS # 99-04-7		$pK_a = 4.27$			
*2.37	D	46	25	SF	AS	W	AQ	
2.37 (0.20)	Recommended							
$C_8H_8O_2$		4-Methylbenzoic acid	CAS # 99-94-5		$pK_a = 4.39$			
*2.27	D	46	25	SF	AS	W	AQ	
2.36	D	71	23	SF	AS	pH2.3	ORG	
2.34	I	44	25	microelectrometric titration				
2.67?	I	123		HPLC				
2.34 (0.20)	Recommended							

Table 12. Acids (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₁₆ O ₂		Octanoic (caprylic) acid		CAS # 124-07-2		pK _a = 4.89		
2.93	I	122			HPLC			
*3.05 ^a	?	173						
3.05 (0.20)	Recommended							
C ₈ H ₁₆ O ₂		2-Ethylhexanoic acid		CAS # 149-57-5		pK _a = 4.8 (est.)		
*2.64	?	206						
2.64 (0.25)	Recommended							
C ₈ H ₁₆ O ₂		2-Propylpentanoic acid		CAS # 99-66-1		pK _a = 4.8 (est.)		
0.13 ^c	D	104				pH7.5		
*2.75	?	206						
2.75 (0.25)	Recommended							
C ₉ H ₈ O ₂		3-Phenyl-2-propenoic (cinnamic) acid (isomer not specified)		CAS # 621-82-9		pK _a ~ 4.2		
2.08	D	154		SF	AS			
2.37	D	104				pH1		
2.41 ^a	?	173	37					
2.25 (0.25)	Recommended							
C ₉ H ₈ O ₂		trans-3-Phenyl-2-propenoic acid		CAS # 140-10-3		pK _a = 4.44		
*2.13	D	104						
2.39	I	216		HPLC				
2.13 (0.20)	Recommended							
C ₉ H ₁₀ O ₂		2-Phenylpropanoic acid		CAS # 492-37-5		pK _a = 4.7 (est.)		
1.80 ^c	D	213	25	SF	AS	pH3.5	Both	
1.80 (0.20)	Recommended							
C ₉ H ₁₀ O ₂		3-Phenylpropanoic acid		CAS # 501-52-0		pK _a = 4.66		
*1.84	D	120		SF	AS	W	AQ	46
1.91	D	213	25	SF	AS	pH3.5	Both	
1.84 (0.15)	Recommended							

Table 12. Acids (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_9H_{10}O_2$				3-Methylphenylethanoic acid	CAS # 621-36-3		$pK_a = 4.4$ (est.)	
*1.95	D	46	25	SF	T	W	AQ	
1.95 (0.20)	Recommended							
$C_9H_{10}O_2$				4-Methylphenylethanoic acid	CAS # 622-47-9		$pK_a = 4.37$	
*1.86	D	46	25	SF	AS	W	AQ	
1.86 (0.20)	Recommended							
$C_9H_{18}O_2$				2-Propylhexanoic acid	CAS # 3274-28-0		$pK_a = 4.7$ (est.)	
*3.01	?	206						
3.01 (0.30)	Recommended							
$C_{10}H_{10}O_2$				2-Methyl-3-phenylpropenoic acid	CAS # 1199-77-5		$pK_a = 4.4$ (est.)	
2.89	I	216		HPLC				
2.60 (0.35)	Recommended							
$C_{10}H_{20}O_2$				Decanoic (capric) acid	CAS # 334-48-5		$pK_a = 4.9$ (est.)	
*4.09	D	104						
3.99	I	122		HPLC				
4.09 ^a	?	173						
4.09 (0.30)	Recommended							
$C_{10}H_{20}O_2$				2-Propylheptanoic acid	CAS # 31080-39-4		$pK_a = 4.7$ (est.)	
*3.20	?	206						
3.55 (0.40)	Rccommendcd							
$C_{10}H_{20}O_2$				2-Butylhexanoic acid	CAS # 3115-28-4		$pK_a = 4.7$ (est.)	
*3.20	?	206						
3.55 (0.40)	Recommended							

Table 12. Acids (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{11}H_{10}O_2$				5-Phenyl-2,4-pentadienoic acid	CAS # 1552-94-9		$pK_a = 4.3$ (est.)	
3.15	I	216		HPLC				
2.5 (0.5)	Recommended							
$C_{12}H_{24}O_2$				Dodecanoic (lauric) acid	CAS # 143-07-7		$pK_a = 5.3$ ($20^{\circ}C$)	
*4.20	D	104						
5.05	I	122		HPLC				
4.6 (0.5)	Recommended							
$C_{14}H_{12}O_2$				Diphenylethanoic acid	CAS # 117-34-0		$pK_a = 3.94$	
*2.17	D	212		SF	AS	W	AQ	
*3.09	D	104				pH1		
2.6 (0.5)	Recommended							
$C_{14}H_{28}O_2$				Tetradecanoic (myristic) acid	CAS # 544-63-8		$pK_a = 4.5$ (est.)	
6.11	I	122		HPLC				
6.1 (0.6)	Recommended							
$C_{15}H_{10}O_2$				Anthracene-9-carboxylic acid	CAS # 723-62-6		$pK_a = 3.65$ ($20^{\circ}C$)	
3.11	D	217		SF	RC	W	Both	134
4.3 (0.5)	Recommended							
$C_{16}H_{30}O_2$				8-Hexadecenoic (palmitoleic) acid (isomer not specified)	CAS # 17004-62-5		$pK_a = 4.5$ (est.)	
6.58	I	122		HPLC				
6.58 (0.65)	Recommended							
$C_{16}H_{32}O_2$				Hexadecanoic (palmitic) acid	CAS # 57-10-3		$pK_a = 4.5$ (est.)	
7.17	I	122		HPLC				
7.17 (0.70)	Recommended							

Table 12. Acids (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{18}H_{30}O_2$				9,12,15-Octadecatrienoic (linolenic) acid	CAS # 463-40-1			
6.46	I	122		HPLC			$pK_a = 4.5$ (est.)	
6.46 (0.65)	Recommended							
$C_{18}H_{32}O_2$				9,12-Octadecadienoic (linoleic) acid	CAS # 60-33-3		$pK_a = 4.77$	
7.05	I	122		HPLC				
7.05 (0.70)	Recommended							
$C_{18}H_{34}O_2$				9-Octadecenoic (oleic) acid (isomer not specified)	CAS # 2027-47-6			
7.64	I	122		HPLC			$pK_a = 4.5$ (est.)	
7.64 (0.76)	Recommended							
$C_{18}H_{36}O_2$				Octadecanoic (stearic)acid	CAS # 57-11-4		$pK_a = 4.5$ (est.)	
8.23	I	122		HPLC				
8.23 (0.82)	Recommended							
$C_{20}H_{32}O_2$				5,8,11,14-eicosatetraenoic (arachidonic) acid	CAS # 506-32-1			
6.98	I	122		HPLC			$pK_a = 4.5$ (est.)	
6.98 (0.70)	Recommended							
$C_{20}H_{40}O_2$				Eicosanoic acid	CAS # 506-30-9		$pK_a = 4.5$ (est.)	
9.29	I	122		HPLC				
9.29 (0.93)	Recommended							

^a From an unidentified literature source.^b RC or AS or T.^c Not ion-corrected.

Table 13. Esters

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₄ H ₈ O ₂		Methanoic acid, n-propyl ester			CAS # 110-74-7			
*0.83	D	104						
0.83 (0.15)	Recommended							
C ₇ H ₆ O ₂		Methanoic acid, phenyl ester			CAS # 1864-94-4			
*1.26	I	60		HPLC				
1.26 (0.30)	Recommended							
C ₃ H ₆ O ₂		Ethanoic acid, methyl ester			CAS # 79-20-9			
*0.18	D	147	20	SF	CR	W	Both	148
0.18 (0.05)	Recommended							
C ₄ H ₆ O ₂		Ethanoic acid, vinyl ester			CAS # 108-05-4			
0.60	D	218		SF				
*0.73	D	104						
0.21?	I	144		HPLC				
0.73 (0.15)	Recommended							
C ₄ H ₈ O ₂		Ethanoic acid, ethyl ester			CAS # 141-78-6			
0.66	D	147	20	SF	CR	W	Both	148
0.68	D	9,10	25	G	GLC	W	Both	11
*0.73	D	30,111		SF	GLC	W	one	46
0.53	I	10	25	from measured activity coefficients				
0.73 (0.05)	Recommended							
C ₅ H ₁₀ O ₂		Ethanoic acid, n-propyl ester			CAS # 109-60-4			
1.24	D	9,10	25	G	GLC	W	Both	11
1.11	I	10	25	from measured activity coefficients				
1.24 (0.15)	Recommended							
C ₆ H ₁₂ O ₂		Ethanoic acid, n-butyl ester			CAS # 123-86-4			
1.82	D	9,10	25	G	GLC	W	Both	11
1.69	I	10	25	from measured activity coefficients				
1.82 (0.15)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_8H_8O_2$							CAS # 122-79-2	
*1.49	D	46	25	SF	AS	W	AQ	
1.49 (0.20)	Recommended							
$C_9H_{10}O_2$							CAS # 140-11-4	
*1.96	D	120		SF	AS	W	AQ	46
1.99	D	219	25	SF	AS	W	AQ	46
1.96 (0.15)	Recommended							
$C_9H_{10}O_2$							CAS # 533-18-6	
*1.93	D	104						
2.11	D	192	AMB	SF	AS	W	AQ	
1.93 (0.20)	Recommended							
$C_9H_{10}O_2$							CAS # 122-46-3	
*2.09	D	192	AMB	SF	AS	W	AQ	
2.09 (0.20)	Recommended							
$C_9H_{10}O_2$							CAS # 140-39-6	
*2.11	D	192	AMB	SF	AS	W	AQ	
2.11 (0.20)	Recommended							
$C_{10}H_{12}O_2$							CAS # 103-45-7	
*2.30	D	120		SF	AS	W	AQ	46
2.30 (0.25)	Recommended							
$C_{10}H_{12}O_2$							CAS # 3245-23-6	
*2.56	D	104						
2.56 (0.25)	Recommended							
$C_{10}H_{12}O_2$							CAS # 3056-59-5	
*2.42	D	104						
2.42 (0.30)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₀ H ₁₂ O ₂					Ethanoic acid, 4-methylbenzyl ester	CAS#	2216-45-7	
*2.44	D	219	25	SF	AS	W	AQ	
2.44 (0.25)	Recommended							
C ₄ H ₆ O ₂					Propenoic acid, methyl ester	CAS #	96-33-3	
*0.80	D	194	AMB	SF	GLC	W	AQ	
0.36?	I	144		HPLC				
0.80 (0.15)	Recommended							
C ₅ H ₈ O ₂					Propenoic acid, ethyl ester	CAS #	140-88-5	
*1.32	D	104						
*1.33	D	194	AMB	SF	GLC	W	AQ	
0.66?	I	144		HPLC				
1.32 (0.15)	Recommended							
C ₇ H ₁₂ O ₂					Propenoic acid, n-butyl ester	CAS #	141-32-2	
*2.36	D	194	AMB	SF	GLC	W	AQ	
1.67?	I	144		HPLC				
2.36 (0.25)	Recommended							
C ₇ H ₁₂ O ₂					Propenoic acid, isobutyl ester	CAS #	106-63-8	
*2.22	D	194	AMB	SF	GLC	W	AQ	
2.22 (0.25)	Recommended							
C ₅ H ₁₀ O ₂					Propanoic acid, ethyl ester	CAS #	105-37-3	
*1.21	D	111		SF	GLC	W	one	46
1.43	D	9,10	25	G	GLC	W	Both	11
1.60	I	57		HPLC				
1.21 (0.15)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_5H_8O_2$							CAS # 80-62-6	
0.70?	D	144		SF				
*1.38	D	194	AMB	SF	GLC	W	AQ	
0.67?	I	144		HPLC				
1.38 (0.15)	Recommended							
$C_6H_{10}O_2$							CAS # 97-63-2	
1.30?	D	144		SF				
*1.94	D	194	AMB	SF	GLC	W	AQ	
1.25?	I	144		HPLC				
1.94 (0.20)	Recommended							
$C_7H_{12}O_2$							CAS # 4655-34-9	
*2.25	D	194	AMB	SF	GLC	W	AQ	
2.25 (0.25)	Recommended							
$C_8H_{14}O_2$							CAS # 97-88-1	
2.60	D	144		SF				
*2.88	D	194	AMB	SF	GLC	W	AQ	
2.26?	I	144		HPLC				
2.88 (0.30)	Recommended							
$C_8H_{14}O_2$							CAS # 97-86-9	
*2.66	D	194	AMB	SF	GLC	W	AQ	
2.01?	I	144		HPLC				
2.66 (0.25)	Recommended							
$C_8H_{14}O_2$							CAS # 585-07-9	
*2.54	D	194	AMB	SF	GLC	W	AQ	
2.01?	I	144		HPLC				
2.54 (0.25)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₀ H ₁₆ O ₂					2-Methylpropenoic acid, cyclohexyl ester	CAS # 101-43-9		
3.96	I	144		HPLC				
3.6 (0.4)	Recommended							
C ₁₁ H ₁₂ O ₂					2-Methylpropenoic acid, benzyl ester	CAS # 2495-37-6		
2.16	I	144		HPLC				
2.7 (0.3)	Recommended							
C ₁₂ H ₂₂ O ₂					2-Methylpropenoic acid, 2-ethylhexyl ester	CAS # 688-84-6		
4.35	I	144		HPLC				
4.8 (0.5)	Recommended							
C ₁₄ H ₂₆ O ₂					2-Methylpropenoic acid, isodecyl ester	CAS # 29964-84-9		
4.92	I	144		HPLC				
5.9 (0.6)	Recommended							
C ₁₁ H ₁₄ O ₂					3-Methylbutanoic acid, phenyl ester	CAS # 15806-38-9		
3.18	D	220		SF	AS	W	AQ	46
3.18 (0.30)	Recommended							
C ₁₄ H ₂₀ O ₂					3-Methylbutanoic acid, benzyl ester			
3.26	D	220		SF	AS	W	AQ	46
3.26 (0.30)	Recommended							
C ₈ H ₈ O ₂					Benzoic acid, methyl ester	CAS # 93-58-3		
2.14	D	221	21	SF	HPLC	W	AQ	
2.23	D	190	25	SF	AS	W	ORG	191
2.15	I	122		HPLC				
2.22	I	57		HPLC				
2.20 (0.15)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_9H_{10}O_2$		Benzoic acid, ethyl ester			CAS # 93-89-0			
2.20	D	154		SF	AS			
*2.64	D	104						
2.64	D	221	21	SF	HPLC	W		AQ
2.64 ^a	?	222						
2.64 (0.20)	Recommended							
$C_{10}H_{12}O_2$		Benzoic acid, n-propyl ester			CAS # 2315-68-6			
1.80?	D	221	21	SF	HPLC	W		AQ
3.18 (0.25)	Recommended							
$C_{10}H_{12}O_2$		Benzoic acid, isopropyl ester			CAS # 939-48-0			
3.09	I	122		HPLC				
*3.18	?	223						
3.18 (0.25)	Recommended							
$C_{11}H_{14}O_2$		Benzoic acid, n-butyl ester			CAS # 136-60-7			
3.74	I	122		HPLC				
3.74 (0.37)	Recommended							
$C_{12}H_{16}O_2$		Benzoic acid, isopentyl ester						
4.15	I	122		HPLC				
4.15 (0.40)	Recommended							
$C_{13}H_{10}O_2$		Benzoic acid, phenyl ester			CAS # 93-99-2			
3.58	D	104						
*3.59	D	104						
3.59 (0.25)	Recommended							
$C_{14}H_{12}O_2$		Benzoic acid, benzyl ester			CAS # 120-51-4			
*3.97	D	104						
3.97 (0.30)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{13}H_{18}O_2$								
4.20	D	220		SF	AS	W	AQ	46
4.20 (0.40)	Recommended							
$C_9H_{10}O_2$							CAS # 101-41-7	
*1.83	D	120		SF	AS	W	AQ	46
1.83 (0.20)	Recommended							
$C_9H_{10}O_2$							CAS # 89-71-4	
*2.75	D	104						
2.75 (0.25)	Recommended							
$C_{10}H_{10}O_2$							3-Phenylpropenoic acid, methyl ester (isomer not specified)	
*2.62	?	199					CAS # 103-26-4	
2.62 (0.25)	Recommended							
$C_{11}H_{12}O_2$							3-Phenylpropenoic acid, ethyl ester (isomer not specified)	
2.91	D	154		SF	AS		CAS # 103-36-6	
*2.99	?	199						
2.99 (0.25)	Recommended							
$C_{18}H_{16}O_2$							3-Phenylpropenoic acid, 3-phenylpropenyl ester	
*4.45	I	216		HPLC			CAS # 122-69-0	
4.45 (0.40)	Recommended							
$C_{10}H_{12}O_2$							3-Phenylpropanoic acid, methyl ester	CAS # 103-25-3
*2.32	D	120		SF	AS	W	AQ	46
2.32 (0.20)	Recommended							
$C_{10}H_{20}O_2$								
4.32	D	9,10	25	G	GLC	W	Both	11
3.87 (0.40)	Recommended							

Table 13. Esters (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{11}H_{18}O_2$	2,2-Dimethyl-3-(2-methylpropenyl)-cyclopropane carboxylic acid, methyl ester	CAS # 24141-52-4						
*3.76	D	219	25	SF	AS	W	AQ	
3.76 (0.40)	Recommended							
$C_{17}H_{22}O_2$	2,2-Dimethyl-3-(2-methylpropenyl)-cyclopropane carboxylic acid, benzyl ester	CAS # 64312-78-3						
*5.49	D	219	25	SF	AS	W	AQ	
5.49 (0.50)	Recommended							
$C_{11}H_{22}O_2$	Decanoic acid, methyl ester	CAS # 110-42-9						
4.41	D	9,10	25	G	GLC	W	Both	11
4.41 (0.40)	Recommended							
$C_{12}H_{16}O_2$	2-Phenyl-3-methylbutanoic acid, methyl ester							
3.33	D	220		SF	AS	W	AQ	46
3.33 (0.30)	Recommended							

^a D. E. Leahy and co-workers, personal communication.

Table 14. Halogenated compounds

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CCl_4	Tetrachloromethane			CAS # 56-23-5				
2.62	D	135	20	SF	GLC	W	Both	
2.73	D	108	23	SF	RC	W	Both	
*2.83	D	104					Both	
2.03	I	65		HPLC				
2.54	I	33	25	from water solubility correlation				
2.81	I	74	25	from UNIFAC activity coefficients				
2.83 (0.25)	Recommended							
CHCl_3	Trichloromethane			CAS # 67-66-3				
1.90	D	108	23	SF	RC	W	Both	
1.94	D	104						
*1.97	D	30,111		SF	GLC	D_2O W	one	46
1.43	I	33	25	from water solubility correlation				
1.91	I	74	25	from UNIFAC activity coefficients				
3.04?	I	65		HPLC				
1.97 (0.15)	Recommended							
CH_2Cl_2	Dichloromethane			CAS # 75-09-2				
*1.25	D	104					Both	
1.25 (0.15)	Recommended							
CH_2F_2	Difluoromethane			CAS # 75-10-5				
*0.20	D	104					Both	
0.20 (0.20)	Recommended							
CH_2I_2	Diiodomethane			CAS # 75-11-6				
*2.30	D	104						
2.30 (0.20)	Recommended							
CH_3Br	Bromomethane			CAS # 74-83-9				
*1.19	D	104						
1.19 (0.20)	Recommended							

Table 14. Halogenated compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_3Cl				CAS # 74-87-3				
*0.91	D	104					Both	
0.91 (0.20)	Recommended							
CH_3F				CAS # 593-53-3				
*0.51	D	104					Both	
0.51 (0.20)	Recommended							
CH_3I				CAS # 74-88-4				
*1.51	D	104					Both	
1.69	D	147	19	SF		W	Both	148
1.51 (0.15)	Recommended							
$\text{C}_2\text{H}_5\text{Br}$				CAS # 74-96-4				
*1.61	D	104					Both	
1.61 (0.20)	Recommended							
$\text{C}_2\text{H}_5\text{Cl}$				CAS # 75-00-3				
*1.43	D	104					Both	
1.43 (0.20)	Recommended							
$\text{C}_2\text{H}_5\text{I}$				CAS # 75-03-6				
*2.00	D	30,111		SF	GLC	W	AQ	46
2.00 (0.20)	Recommended							
$\text{C}_3\text{H}_5\text{Br}$				CAS # 106-95-6				
*1.79	D	9,10	25	G	HPLC	W	Both	11
1.79 (0.20)	Recommended							
$\text{C}_3\text{H}_7\text{Br}$				CAS # 106-94-5				
*2.10	D	30,111		SF	GLC	W	one	46
2.10 (0.20)	Recommended							

Table 14. Halogenated compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₃ H ₇ Cl		1-Chloropropane		CAS #	540-54-5			
2.04	D	104					Both	
2.04 (0.20)	Recommended							
C ₃ H ₇ Cl		2-Chloropropane		CAS #	75-29-6			
*1.90	D	104						
1.90 (0.20)	Recommended							
C ₄ H ₇ Br		4-Bromo-1-butene		CAS #	5162-44-7			
2.53	D	9,10	25	G	HPLC	W	Both	11
2.34 (0.20)	Recommended							
C ₄ H ₉ Br		1-Bromobutane		CAS #	109-65-9			
2.75	D	9,10	25	G	GLC	W	Both	11
2.75	D	58	25	G	HPLC	W	Both	11
2.64	I	58	25	from measured activity coefficients				
2.79	I	10	25	from measured activity coefficients				
2.75 (0.15)	Recommended							
C ₄ H ₉ Cl		1-Chlorobutane		CAS #	109-69-3			
2.39	D	30	25	SF	GLC	W	AQ	46
2.55	D	9,10	25	G	GLC	W	Both	11
*2.64	D	104					Both	
2.39	?	105						
2.64 (0.25)	Recommended							
C ₄ H ₉ F		1-Fluorobutane		CAS #	2366-52-1			
*2.58	D	104						
2.58 (0.30)	Recommended							

Table 14. Halogenated compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_5H_{11}Br$		1-Bromopentane		CAS # 110-53-2				
*3.37	D	9	25	G	GLC	W	Both	11
3.37	D	58	25	G	HPLC	W	Both	11
3.49	D	10	25	G	GLC	W	Both	
3.32	I	58	25	from measured activity coefficients				
3.37 (0.25)	Recommended							
$C_5H_{11}F$		1-Fluoropentane		CAS # 592-50-7				
*2.33	D	111		SF	GLC	W	AQ	46
2.05	I	33	25	from water solubility correlation				
2.33 (0.20)	Recommended							
C_6H_5Br		Bromobenzene		CAS # 108-86-1				
2.98	D	10	25	G	HPLC	W	Both	
*2.99	D	30,46	25	SF	AS	W	AQ	
3.01	D	114	25	SF	GLC	W	AQ	
2.84	I	33	25	from water solubility correlation				
2.94	I	116		HPLC				
3.02	I	92		HPLC				
3.02	I	122		HPLC				
3.15	I	65		HPLC				
2.99 (0.15)	Recommended							
C_6H_5Cl		Chlorobenzene		CAS # 108-90-7				
2.46	D	224	AMB	SF	AS	W	one	
2.60	D	108	23	SF	RC	W	Both	
2.81	D	10	25	G	HPLC	W	Both	
2.84	D	114	25	SF	GLC	W	AQ	
*2.84	D	30,46	25	SF	AS	W	AQ	
2.98	D	9,10	25	G	HPLC	W	Both	11
2.98	D	34	25	G	HPLC	W	Both	11
2.18?	?	150						
2.63	I	33	25	from water solubility correlation				
2.75 ^a	I	64		HPLC				
2.83	I	10	25	from measured activity coefficients				
2.84	I	112		HPLC				
3.00	I	130		HPLC				
3.08	I	75	25	from UNIFAC activity coefficients				
2.84 (0.15)	Recommended							

Table 14. Halogenated compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₅ F		Fluorobenzene		CAS # 462-06-6				
*2.27	D	46	25	SF	AS	W	AQ	
2.27	(0.20)	Recommended						
C ₆ H ₅ I		Iodobenzene		CAS # 591-50-4				
*3.25	D	104						
3.28	D	9,10	25	G	HPLC	W	Both	11
3.03	I	33	25	from water solubility correlation				
3.37	I	65		HPLC				
3.25	(0.15)	Recommended						
C ₆ H ₁₁ Br		Bromocyclohexane		CAS # 108-85-0				
*3.20	D	139		SF	GLC	W		1
3.20	(0.25)	Recommended						
C ₆ H ₁₃ Br		1-Bromohexane		CAS # 111-25-1				
*3.80	D	9,10	25	G	GLC	W	Both	11
3.80	D	58	25	G	HPLC	W	Both	11
3.80	I	58	25	from measured activity coefficients				
3.80	(0.20)	Recommended						
C ₇ H ₇ Br		Benzyl bromide		CAS # 100-39-0				
*2.92	D	104						
2.92	(0.30)	Recommended						
C ₇ H ₇ Cl		Benzyl chloride		CAS # 100-44-7				
*2.30	D	225	22	SF	GLC,RC	W	Both	
2.30	(0.20)	Recommended						
C ₇ H ₇ Cl		2-Chlorotoluene		CAS # 95-49-8				
*3.42	D	104						
3.52	I	112		HPLC				
3.59	I	65		HPLC				
3.42	(0.20)	Recommended						

Table 14. Halogenated compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_7H_7Cl		3-Chlorotoluene		CAS # 108-41-8				
*3.28	D	104						
3.28	(0.20)	Recommended						
C_7H_7Cl		4-Chlorotoluene		CAS # 106-43-4				
*3.33	D	104						
3.30	?	131						
3.42	I	112		HPLC				
3.33	(0.15)	Recommended						
$C_7H_{15}Br$		1-Bromoheptane		CAS # 629-04-9				
*4.36	D	9,10	25	G	GLC	W	Both	11
4.36	D	58	25	G	HPLC	W	Both	11
4.44	I	58	25	from measured activity coefficients				
4.36	(0.15)	Recommended						
$C_7H_{15}Cl$		1-Chloroheptane		CAS # 629-06-1				
*4.15	D	9,10	25	G	GLC	W	Both	11
4.15	(0.25)	Recommended						
$C_7H_{15}I$		1-Iodoheptane		CAS # 4282-40-0				
*4.70	D	9,10	25	G	GLC	W	Both	11
4.70	(0.30)	Recommended						
$C_8H_{17}Br$		1-Bromooctane		CAS # 111-83-1				
*4.89	D	9,10	25	G	GLC	W	Both	11
4.89	D	58	25	G	HPLC	W	Both	11
5.09	I	58	25	from measured activity coefficients				
4.89	(0.35)	Recommended						
$C_{10}H_7Cl$		1-Chloronaphthalene		CAS # 90-13-1				
3.90	D	226		SF	GLC	W	Both	68
3.90	(0.30)	Recommended						

Table 14. Halogenated compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{10}H_7Cl$			2-Chloronaphthalene		CAS # 91-58-7			
3.98 ^b	D	226		SF	GLC	W	Both	68
4.07 ^b	?	227						
3.98 (0.30)	Recommended							
$C_{10}H_{21}Br$			1-Bromodecane		CAS # 112-29-8			
6.43	I	141			HPLC			
6.0 (0.5)	Recommended							
$C_{12}H_9Cl$			2-Chlorobiphenyl		CAS # 2051-60-7			
*4.38	D	129	25	G	HPLC	W	Both	
4.50	D	34	25	G	GLC	W	Both	
4.59	D	68		SF	GLC	W	Both	
4.10 ^b	I	141			HPLC			
4.54 ^b	?	228						
4.60	I	128			HPLC			
4.52 (0.30)	Recommended							
$C_{12}H_9Cl$			3-Chlorobiphenyl		CAS # 2051-61-8			
*4.58	D	129	25	G	HPLC	W	Both	
4.71	D	68		SF	GLC	W	Both	
4.42 ^b	I	128			HPLC			
4.95 ^b	?	228						
4.58 (0.30)	Recommended							
$C_{12}H_9Cl$			4-Chlorobiphenyl		CAS # 2051-62-9			
4.49	D	129	25	G	HPLC	W	Both	
*4.61	D	68		SF	GLC	W	Both	
4.26 ^b	?	227						
4.40 ^b	I	128			HPLC			
4.90 ^b	?	229						
4.61 (0.30)	Recommended							

^a Average value.^b From an unidentified literature source.

Table 15. Amines

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_5N		Aminomethane	CAS # 74-89-5			$\text{pK}_a = 10.65$		
*-0.57	D	147	20	SF	K	W	Both	148
-0.57	D	202	25	SF	RC	pH13		
-0.57 (0.10)	Recommended							
$\text{C}_2\text{H}_7\text{N}$		Aminoethane	CAS # 75-04-7			$\text{pK}_a = 10.70$		
-0.30 ^b	D	230	20	SF	T	W	AQ	
*-0.13	D	104				pH13		
-0.13 (0.10)	Recommended							
$\text{C}_2\text{H}_7\text{N}$		Dimethylamine	CAS # 124-40-3			$\text{pK}_a = 10.77$		
*-0.38	D	202	25	SF	RC	pH13		
-0.38 (0.10)	Recommended							
$\text{C}_3\text{H}_7\text{N}$		3-Amino-1-propene (allyl amine)	CAS # 107-11-9			$\text{pK}_a = 9.51$		
*0.03	D	104				pH13		
0.03 (0.10)	Recommended							
$\text{C}_3\text{H}_9\text{N}$		1-Aminopropane	CAS # 107-10-8			$\text{pK}_a = 10.68$		
0.28	D	230	20	SF	T	W	AQ	
*0.48	D	104				pH13		
0.48 (0.20)	Recommended							
$\text{C}_3\text{H}_9\text{N}$		2-Aminopropane	CAS # 75-31-0			$\text{pK}_a = 10.63$		
-0.03	D	104				pH13		
*0.26	D	104						
0.26 (0.15)	Recommended							
$\text{C}_3\text{H}_9\text{N}$		Methylethyl amine	CAS # 624-78-2			$\text{pK}_a = 11$ (est.)		
*0.15	D	104				pH13		
0.15 (0.10)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₃ H ₉ N		Trimethyl amine		CAS # 75-50-3		pK _a = 9.79		
*0.16	D	104					Both	
0.27	D	231	25	SF	T	W	Both	232
0.16 (0.10)	Recommended							
C ₄ H ₅ N		Pyrrole		CAS # 109-97-7		pK _a = -4.1		
*0.75	D	111		SF	AS	W	one	46
0.75 (0.10)	Recommended							
C ₄ H ₉ N		Pyrrolidine		CAS # 123-75-1		pK _a = 11.18		
*0.46	D	104				pH13		
0.46 (0.25)	Recommended							
C ₄ H ₁₁ N		1-Aminobutane		CAS # 109-73-9		pK _a = 10.64		
-1.22 ^a	D	233	AMB	SF	RC	pH7	Both	3
0.68	D	147	20	SF	K	W	Both	148
0.80	D	92		SF				
0.81	D	104						
0.88	D	231	25	SF	T	W	Both	232
*0.97	D	104				pH13		
1.02 ^b	D	104				pH9.4		
0.86 (0.20)	Recommended							
C ₄ H ₁₁ N		1-Amino-2-methylpropane (isobutyl amine)		CAS # 78-81-9		pK _a = 10.58		
*0.73	D	104				pH13		
0.88 ^b	D	104				pH9.4		
0.73 (0.15)	Recommended							
C ₄ H ₁₁ N		2-Aminobutane (sec-butyl amine)		CAS # 513-49-5		pK _a = 10.56		
0.74	D	104				pH13		
0.74 (0.15)	Recommended							
C ₄ H ₁₁ N		2-Methyl-2-aminopropane (tert-butyl amine)		CAS # 75-64-9				
*0.40	D	104				pK _a = 10.68		
0.40 (0.20)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_4H_{11}N$		Diethylamine		CAS # 109-89-7		$pK_a = 11.07$		
0.43	D	147	19	SF	K	W	Both	148
0.57	D	231	25	SF	T	W	Both	232
*0.58	D	104				pH13		
0.81	I	65		HPLC				
0.58 (0.15)	Recommended							
$C_4H_{11}N$		Ethyldimethyl amine		CAS # 598-56-1		$pK_a = 10.16 (20^\circ C)$		
0.70	D	104						
0.70 (0.20)	Recommended							
C_5H_5N		Pyridine		CAS # 110-86-1		$pK_a = 5.21$		
0.62	D	115		SF	AS	pH7.4	AQ	
0.64	D	104						
*0.65	D	120		SF	AS	W	AQ	46
0.66	D	104						
0.68	D	104						
0.78 ^b	D	235	25	SF	AS	NS	Both	
1.04	D	234		SF		W		124
0.54	I	75	25	from UNIFAC activity coefficients				
0.62	I	60		HPLC				
0.63	I	44	25	microelectrometric titration				
0.63	I	209	25	microelectrometric titration				
0.65 (0.05)	Recommended							
C_5H_7N		N-Methylpyrrole		CAS # 96-54-8		$pK_a = -3.15$		
*1.21	D	151		SF	HPLC	NS	Both	
1.21	D	104						
1.21 (0.20)	Recommended							
$C_5H_{11}N$		Allylethyl amine		CAS # 2424-02-4		$pK_a = 10. (est.)$		
*0.81	D	104				pH13		
0.81 (0.10)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₅ H ₁₁ N	Piperidine		CAS # 110-89-4			pK _a = 11.13		
0.60 ^b	D	104				pH9.4		
*0.84	D	104				pH13		
0.85	D	104						
0.84 (0.10)	Recommended							
C ₅ H ₁₃ N	1-Aminopentane		CAS # 110-58-7			pK _a = 10.61		
-0.86 ^a	D	233	AMB	SF	RC	pH7	Both	3
*1.49	D	104				pH13		
1.49 ^b	D	104				pH9.4		
1.49 (0.15)	Recommended							
C ₅ H ₁₃ N	Methylbutyl amine		CAS # 110-68-9			pK _a = 11. (est.)		
*1.33	D	104				pH13		
1.33 (0.15)	Recommended							
C ₅ H ₁₃ N	Ethylisopropyl amine		CAS # 19961-27-4			pK _a = 11. (est.)		
*0.93	D	104				pH13		
0.93 (0.10)	Recommended							
C ₆ H ₇ N	Aniline		CAS # 62-53-3			pK _a = 4.60		
0.89	D	115		SF	AS	pH7.4	AQ	
0.89	D	171	25	SF	AS	pH5.6	AQ	
*0.90	D	30,46	25	SF	AS	W	AQ	
0.90	D	86	20	SF	AS	W	AQ	46
0.95 ^a	D	237	37	SF	AS	pH7.4	AQ	46
0.98	D	238		SF	AS	pH7.5	AQ	1
0.98	D	104						
0.85	?	150						
0.90 ^d	?	236						
0.91	I	112		HPLC				
0.93 ^e	I	64		HPLC				
0.95	I	166		HPLC				
0.99	I	75	25	from UNIFAC activity coefficients				
1.02 ^{e,f}	?	110						
1.08 ^g	I	65		HPLC				
1.08	I	93		HPLC				
1.09	I	92		HPLC				
0.90 (0.05)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₇ N		2-Methylpyridine		CAS # 109-06-8		pK _a = 5.95		
*1.11	D	104						
1.11	(0.15)	Recommended						
C ₆ H ₇ N		3-Methylpyridine		CAS # 108-99-6		pK _a = 5.65		
*1.20	D	104						
1.19	I	98		HPLC				
1.20	(0.15)	Recommended						
C ₆ H ₇ N		4-Methylpyridine		CAS # 108-89-4		pK _a = 6.02		
*1.22	D	104						
1.33 ^b	D	235	25	SF	AS	NS	Both	
1.22	(0.10)	Recommended						
C ₆ H ₁₁ N		Diallyl amine		CAS # 124-02-7		pK _a = 9.29		
*1.11	D	104				pH13		
1.11	(0.15)	Recommended						
C ₆ H ₁₃ N		Aminocyclohexane		CAS # 108-91-8		pK _a = 10.67		
*1.49	D	104				pH13		
1.49	(0.10)	Recommended						
C ₆ H ₁₃ N		Allylpropyl amine		CAS # 5666-21-7		pK _a = 10. (est.)		
*1.33	D	104				pH13		
1.33	(0.15)	Recommended						
C ₆ H ₁₃ N		N-Methylpiperidine		CAS # 626-67-5		pK _a = 10.13		
-0.40 ^a	D	239		SF		pH7.4		
*1.30	D	239		SF		pH11		
1.30	(0.15)	Recommended						

Table 15. Amines (continued)

log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₁₅ N		1-Aminohexane		CAS # 111-26-2		pK _a = 10.60		
-0.42 ^a	D	233	AMB	SF	RC	pH7	Both	3
1.98	D	225	22	SF	GLC, RC	W	Both	
1.98 ^b	D	104				pH9.4		
*2.06	D	104				pH13		
2.15	D	104				pH12		
2.11	?	240						
2.06 (0.10)	Recommended							
C ₆ H ₁₅ N		Di-n-propylamine		CAS # 142-84-7		pK _a = 10.93		
1.46 ^b	D	104				pH9.4		
*1.67	D	104				pH13		
1.73	D	104						
1.67 (0.08)	Recommended							
C ₆ H ₁₅ N		Butyldimethyl amine		CAS # 927-62-8		pK _a = 10.19 (20°C)		
*1.70	D	104						
1.70 (0.20)	Recommended							
C ₆ H ₁₅ N		Triethylamine		CAS # 121-44-8		pK _a = 10.76		
1.15 ^b	D	104				pH9.4		
1.44	D	104						
1.45	D	104				pH13		
1.45 (0.10)	Recommended							
C ₇ H ₉ N		Benzylamine		CAS # 100-46-9		pK _a = 9.36		
-1.39 ^a	D	241	37	SF	RC	pH7	Both	
0.29 ^a	D	241	37	SF	RC	pH9.9	Both	
1.03	D	179	20	SF	AS	pH > 11	AQ	
*1.09	D	120		SF	AS	W	AQ	46
1.09 (0.10)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_7H_9N		2-Methylaniline		CAS # 95-53-4		$pK_a = 4.43$		
1.29	D	242		SF	AS	W	AQ	46
*1.32	D	104						
1.42	D	238		SF	AS	pH7.5	AQ	1
1.34 ^e	I	64		HPLC				
1.40 ^d	?	236						
1.43	I	166		HPLC				
1.63	I	56		HPLC				
1.32 (0.10)	Recommended							
C_7H_9N		3-Methylaniline		CAS # 108-44-1		$pK_a = 4.70$		
*1.40	D	46	25	SF	AS	W	AQ	
1.42	D	86	20	SF	AS	W	AQ	46
1.43	D	104						
1.45	I	166		HPLC				
1.40 (0.05)	Recommended							
C_7H_9N		4-Methylaniline		CAS # 106-49-0		$pK_a = 5.08$		
1.39	D	238		SF	AS	pH7.5	AQ	1
*1.39	D	46	25	SF	AS	W	AQ	
1.40	D	86	20	SF	AS	W	AQ	46
1.41	D	104						
1.44	D	237	37	SF	AS	pH7.4	AQ	46
1.56	D	71	23	SF	AS		ORG	
1.39 ^d	?	236						
1.41 ^e	I	64		HPLC				
1.42	I	57		HPLC				
1.48	I	166		HPLC				
1.39 (0.05)	Recommended							
C_7H_9N		N-Methylaniline		CAS # 100-61-8		$pK_a = 4.85$		
*1.66	D	104						
1.82	D	242		SF	AS	W	AQ	46
1.66 ^d	?	236						
1.68	?	223						
1.70	I	57		HPLC				
1.66 (0.15)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₇ H ₉ N		2-Ethylpyridine		CAS # 100-71-0	pK _a = 5.93			
*1.69 ^a	D	189	25	SF	AS	pH7	AQ	46
1.69 (0.15)	Recommended							
C ₇ H ₉ N		2,6-Dimethylpyridine		CAS # 108-48-5	pK _a = 6.67			
*1.68 ^a	D	189	25	SF	AS	pH7	AQ	46
1.63	I	57		HPLC				
1.68 (0.15)	Recommended							
C ₇ H ₁₃ N		1-Azabicyclo 2,2,2 octane (quinuclidine)		CAS # 100-76-5	pK _a = 10.95			
1.20 ^a	D	104			pH9.4			
*1.38	D	104			pH13			
1.38 (0.15)	Recommended							
C ₇ H ₁₅ N		N-Ethylpiperidine		CAS # 766-09-6	pK _a = 10.45			
-1.52 ^b	D	239		SF		pH7.4		
1.30?	D	239		SF		pH11		
1.88 (0.25)	Recommended							
C ₇ H ₁₇ N		1-Aminoheptane		CAS # 111-68-2	pK _a = 10.66			
0.15 ^a	D	233	AMB	SF	RC	pH7	Both	3
*2.57 ^b	D	104		SF		pH9.4		
2.57 (0.25)	Recommended							
C ₇ H ₁₇ N		2-Aminoheptane		CAS # 44652-67-7	pK _a = 10.58			
*2.40	D	243		SF	GLC	pH13	AQ	
2.40 (0.20)	Recommended							
C ₇ H ₁₇ N		Propyl-n-butyl amine		CAS # 20193-21-9	pK _a = 11. (est.)			
*2.12	D	104				pH13		
2.12 (0.20)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₇ H ₁₇ N		Propylisobutyl amine	CAS # 39190-66-4			pK _a = 11. (est.)		
*2.07	D	104				pH13		
2.07	(0.20)	Recommended						
C ₇ H ₁₇ N		Propyl-sec-butyl amine	CAS # 39190-67-5			pK _a = 11. (est.)		
*1.91	D	104				pH13		
1.91	(0.20)	Recommended						
C ₈ H ₇ N		Indole	CAS # 120-72-9			pK _a = -3.17		
2.00	D	104						
2.12	D	104						
*2.14	D	111		SF	AS	W	one	46
2.25	D	40	25	SF	AS	pH7.4	Both	117
1.66	I	56		HPLC				
1.81	I	65		HPLC				
1.92	I	92		HPLC				
2.14	(0.10)	Recommended						
C ₈ H ₉ N		N-Benzylidenemethyl amine	CAS # 622-29-7					
*1.64	D	104						
1.64	(0.15)	Recommended						
C ₈ H ₁₁ N		1-Amino-2-phenylethane	CAS # 64-04-0			pK _a = 9.82		
-1.39 ^a	D	241	37	SF	RC	pH7	Both	
-1.18 ^a	D	246	AMB	SF	RC	pH7.4	Both	
-1.14 ^a	D	245		SF	FLorRC	pH7.4	AQ	
0.35 ^a	D	241	37	SF	RC	pH10	Both	
1.16 ^b	D	246	AMB	SF	RC	pH7.4	Both	
1.28	D	247	25	SF	AS		AQ	
1.37 ^b	D	179	20	SF	AS		AQ	
1.38	D	245		SF	FLorRC	pH7.4	AQ	
*1.41	D	120		SF	AS	W	AQ	46
1.52 ^b	D	244	AMB	SF	AS	pH8	AQ	46,248
1.41	(0.05)	Recommended						

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₁₁ N	2-Ethylaniline		CAS # 578-54-1			pK _a = 4.34		
*1.74	D	104						
1.74 (0.25)	Recommended							
C ₈ H ₁₁ N	4-Ethylaniline		CAS # 589-16-2		pK _a = 5.00			
*1.96 ^a	D	237	37	SF	AS	pH7.4	AQ	46
1.97	D	238		SF	AS	pH7.5	AQ	1
1.96 (0.10)	Recommended							
C ₈ H ₁₁ N	2,4-Dimethylaniline		CAS # 95-68-1		pK _a = 4.87			
1.68	D	238		SF	AS	pH7.5	AQ	1
1.68 (0.20)	Recommended							
C ₈ H ₁₁ N	N-Methylbenzyl amine		CAS # 103-67-3		pK _a = 9.56			
*1.52	D	104				pH13		
1.52 (0.20)	Recommended							
C ₈ H ₁₁ N	N-Ethylaniline		CAS # 103-69-5		pK _a = 5.12			
2.26	D	242	25	SF	AS	W	AQ	46
*2.16 ^d	?	236						
2.16 (0.20)	Recommended							
C ₈ H ₁₁ N	2,N-Dimethylaniline		CAS # 611-21-2		pK _a = 4.60			
*2.16 ^d	?	236						
2.16 (0.20)	Recommended							
C ₈ H ₁₁ N	4,N-Dimethylaniline		CAS # 623-08-5		pK _a = 5.25			
*2.15 ^d	?	236						
2.15 (0.20)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_8H_{11}N$		N,N-Dimethylaniline		CAS # 121-69-7			$pK_a = 5.10$	
2.29	D	154		SF	AS			
*2.31	D	46	25	SF	AS	W	AQ	
2.62	D	40	25	SF	AS	pH7.4	Both	117
2.31 ^d	?	236						
2.31 (0.10)	Recommended							
$C_8H_{11}N$		4-n-Propylpyridine		CAS # 1122-81-2			$pK_a = 6.05$	
*2.10	D	104						
2.10 (0.20)	Recommended							
$C_8H_{11}N$		2,4,6-Trimethylpyridine		CAS # 108-75-8			$pK_a = 7.42$	
*1.88	D	104						
2.01	D	98	23	SF	AS	W	Both	143
1.88 (0.25)	Recommended							
$C_8H_{19}N$		1-Aminooctane		CAS # 111-86-4			$pK_a = 10.61$	
0.76 ^a	D	233	AMB	SF	RC	pH7	Both	3
3.09 (0.40)	Recommended							
$C_8H_{19}N$		1-Amino-2-ethylhexane		CAS # 104-75-6			$pK_a = 11.$ (est.)	
*2.82 ^b	D	104				pH9.4		
2.82 (0.35)	Recommended							
$C_8H_{19}N$		Di-n-butylamine		CAS # 111-92-2			$pK_a = 11.25$	
2.68	D	104						
*2.83	D	104				pH9.4		
2.83 (0.30)	Recommended							
$C_8H_{19}N$		Ethyldi-n-propyl amine	CAS # 20634-92-8				$pK_a = 11.$ (est.)	
*2.68	D	104						
2.68 (0.30)	Recommended							

Table 15 . Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₉ H ₇ N		Quinoline	CAS # 91-22-5			pK _a = 4.87		
*2.03	D	120		SF	AS	W	AQ	46
2.06	D	40	25	SF	AS	pH7.4	Both	117
1.88	I	57		HPLC				
2.02	I	60		HPLC				
2.03d	?	236						
2.03 (0.10)	Recommended							
C ₉ H ₇ N		Isoquinoline	CAS # 119-65-3			pK _a = 5.39		
*2.08	D	111		SF	AS	W	one	46
2.08 (0.20)	Recommended							
C ₉ H ₉ N		1-Methylindole	CAS # 603-76-9			pK _a = -2.14		
*2.72	D	104						
2.72 (0.25)	Recommended							
C ₉ H ₉ N		2-Methylindole	CAS # 95-20-5			pK _a = -0.19		
*2.53 ^a	D	249	25	SF	AS	pH7.4	Both	
2.53 (0.25)	Recommended							
C ₉ H ₉ N		3-Methylindole	CAS # 83-34-1			pK _a = -3.40		
*2.60	D	40	25	SF	AS	pH7.4	Both	117
2.60 (0.25)	Recommended							
C ₉ H ₉ N		5-Methylindole	CAS # 614-96-0			pK _a = -3.3		
*2.68	D	40	25	SF	AS	pH7.4	Both	117
2.68 (0.25)	Recommended							
C ₉ H ₁₁ N		cis-1-Amino-2-phenylcyclopropane	CAS # 69684-88-4			pK _a = 10. (est.)		
*1.49	D	243		SF	GLC	pH13		
1.49 (0.20)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₉ H ₁₁ N				trans-1-Amino-2-phenylcyclopropane	CAS # 95-62-5	pK _a = 10. (est.)		
*1.58	D	243		SF	GLC	pH13		
1.58 (0.20)	Recommended							
C ₉ H ₁₁ N				1,2,3,4-Tetrahydroquinoline	CAS # 635-46-1	pK _a = 5.03		
*2.29 ^d	?	236						
2.29 (0.25)	Recommended							
C ₉ H ₁₃ N				1-Amino-3-phenylpropane	CAS # 2038-57-5	pK _a = 10. (est.)		
*1.83	D	120		SF	AS	W	AQ	46
1.83	D	179	20	SF	AS	pH>12	AQ	
1.83 (0.20)	Recommended							
C ₉ H ₁₃ N				1-Phenyl-2-aminopropane (amphetamine)	CAS # 300-62-9	pK _a = 9.90		
-1.18	D	104				pH1		
-0.94 ^a	D	246	AMB	SF	RC	pH7.4	Both	
-0.84 ^a	D	245		SF	FLorRC	pH7.4	AQ	
0.31 ^a	D	251	25	SF	RC	pH7.4	Both	3
1.54 ^b	D	246	AMB	SF	RC	pH7.4	Both	
1.56	D	104				pH10.2		
1.64 ^b	D	245		SF	FLorRC	pH7.4	AQ	
1.69	D	247	25	SF	AS	c	AQ	
*1.76	D	104						
1.81	D	243		SF	GLC	pH13	AQ	
2.05 ^b	D	121	25	SF	RC	pH7.4	Both	3
-0.68	?	250				pH7.2		
1.76 (0.10)	Recommended							
C ₉ H ₁₃ N				4-n-Propylaniline	CAS # 622-80-0	pK _a = 4.9 (est.)		
2.40	D	238		SF	AS	pH7.5	AQ	1
2.40 (0.25)	Recommended							
C ₉ H ₁₃ N				4-Isopropylaniline	CAS # 99-88-7	pK _a = 4.85 (20°C)		
*2.23 ^a	D	237	37	SF	AS	pH7.4	AQ	46
2.31	D	238		SF	AS	pH7.5	AQ	1
*2.49 ^a	D	237	37	SF	AS	pH7.4	AQ	46
2.34 (0.25)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_9H_{13}N$		N-Propylaniline		CAS # 622-80-0		$pK_a = 4.92$		
*2.45	D	242		SF	AS	W	AQ	46
2.45 (0.25)	Recommended							
$C_9H_{13}N$		2-tert-Butylpyridine		CAS # 5944-41-2		$pK_a = 5.83$		
*2.40	I	98		HPLC				143
2.40 (0.25)	Recommended							
$C_9H_{13}N$		4-n-Butylpyridine		CAS # 5335-75-1		$pK_a = 6.0$ (cst.)		
3.13 ^b	D	252	25	SF	AS	NS	AQ	
3.13 (0.30)	Recommended							
$C_9H_{13}N$		N,N-Dimethylbenzyl amine		CAS # 103-83-3		$pK_a = 8.97$		
1.79 ^b	D	104				$pH8$		
1.80 ^b	D	104				$pH9.4$		
1.91	D	104						
*1.98	D	104				$pH13$		
1.98 (0.25)	Recommended							
$C_9H_{13}N$		2,N,N-Trimethylaniline		CAS # 609-72-3		$pK_a = 5.98$		
*2.85	D	192	AMB	SF	AS	$pH>8$	AQ	
2.81 ^d	?	236						
2.85 (0.25)	Recommended							
$C_9H_{13}N$		3,N,N-Trimethylaniline		CAS # 121-72-2		$pK_a = 5.27$		
*2.80	D	192	AMB	SF	AS	$pH>7$	AQ	
2.80 (0.25)	Recommended							
$C_9H_{13}N$		4,N,N-Trimethylaniline		CAS # 99-97-8		$pK_a = 5.19$		
2.61	D	192	AMB	SF	AS	$pH>7$	AQ	
*2.81 ^d	?	236						
2.81 (0.30)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_9H_{15}N$		Triallyl amine	CAS # 102-70-5			$pK_a = 8.31$		
*2.59	D	104				pH13		
2.59 (0.25)	Recommended							
$C_9H_{19}N$		2-Amino-3-cyclohexylpropane	CAS # 54704-34-6			$pK_a = 11.$ (est.)		
*2.96	D	243	SF	GLC	pH13	AQ		
2.96 (0.30)	Recommended							
$C_9H_{21}N$		1-Aminononane	CAS # 112-20-9			$pK_a = 10.64$		
1.33 ^a	D	233	AMB	SF	RC	pH7	Both	3
3.60 (0.35)	Recommended							
$C_9H_{21}N$		Tri-n-propyl amine	CAS # 102-69-2			$pK_a = 10.46$		
2.79	D	104						
*2.79 ^b	D	104				pH9.4		
2.79 (0.30)	Recommended							
$C_{10}H_9N$		1-Aminonaphthalene	CAS # 134-32-7			$pK_a = 3.92$		
2.27	D	238	SF	AS	pH7.5	AQ	1	
2.25 ^d	?	236						
2.25 (0.25)	Recommended							
$C_{10}H_9N$		2-Aminonaphthalene	CAS # 91-59-8			$pK_a = 4.15$		
2.40	D	238	SF	AS	pH7.5	AQ	1	
2.40	I	75	25	from UNIFAC activity coefficients				
2.40 (0.25)	Recommended							
$C_{10}H_9N$		2-Phenylpyrrole	CAS # 3042-22-6			$pK_a = -4.5$ (est.)		
2.76	I	143	HPLC					
2.76 (0.30)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₀ H ₁₁ N		1,2-Dimethylindole		CAS # 875-79-6		pK _a = -0.1 (est.)		
*2.82	D	40	25	SF	AS	pH7.4	Both	117
2.82 (0.30)	Recommended							
C ₁₀ H ₁₃ N		2-Amino-1,2,3,4-tetrahydronaphthalene		CAS # 2954-50-9		pK _a = 11. (est.)		
*2.08	D	243		SF	GLC	pH13	AQ	
2.08 (0.20)	Recommended							
C ₁₀ H ₁₃ N		2-Phenylpyrrolidine		CAS # 1006-64-0		pK _a = 9.60		
1.89	I	143	23			microelectrometric titration		
1.89 (0.20)	Recommended							
C ₁₀ H ₁₃ N		3-Methyl-1,2,3,4-tetrahydroisoquinoline		CAS # 29726-60-1		pK _a = 5.6 (est.)		
*1.93	D	243		SF	GLC	pH13	AQ	
1.93 (0.20)	Recommended							
C ₁₀ H ₁₅ N		1-Amino-4-phenylbutane		CAS # 13214-66-9		pK _a = 10.36		
-0.67 ^a	D	253		SF	AS	pH6.8	AQ	
*2.40	D	179	20	SF	AS	pH>12	AQ	
2.45	D	243		SF	GLC	pH13	AQ	
2.40 (0.15)	Recommended							
C ₁₀ H ₁₅ N		1-Phenyl-2-aminobutane		CAS # 53309-89-0		pK _a = 10. (est.)		
*2.28	D	247	25	SF	AS	c	AQ	
2.28 (0.20)	Recommended							
C ₁₀ H ₁₅ N		4-n-Butylaniline		CAS # 104-13-2		pK _a = 4.8 (est.)		
3.05	D	238		SF	AS	pH7.5	AQ	1
3.05 (0.30)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{10}H_{15}N$		4-tert-Butylaniline		CAS # 769-92-6		$pK_a = 4.95$		
2.47	D	238		SF	AS	pH7.5	AQ	1
2.47 (0.25)	Recommended							
$C_{10}H_{15}N$		2,6-Diethylaniline		CAS # 579-66-8		$pK_a = 4.0$ (est.)		
0.95?	?	150						
3.1 (0.3)	Recommended							
$C_{10}H_{15}N$		N-Butylaniline		CAS # 1126-78-9		$pK_a = 5.28$		
3.58	D	242		SF	AS	W	AQ	46
3.10 (0.20)	Recommended							
$C_{10}H_{15}N$		N-Methyl-2-amino-3-phenylpropane (methamphetamine)		CAS # 537-46-2				
-1.30	D	104				$pH1$		$pK_a = 11.$ (est.)
-1.18	D	104				$pH1$		
*2.07	D	104				$pH13$		
2.16	D	243		SF	GLC	$pH13$	AQ	
2.07 (0.20)	Recommended							
$C_{10}H_{15}N$		4-Pentylpyridine		CAS # 2961-50-4		$pK_a = 6.0$ (est.)		
3.75 ^b	D	252	25	SF	AS	NS	AQ	
3.45 (0.30)	Recommended							
$C_{10}H_{15}N$		N,N-Diethylaniline		CAS # 91-66-7		$pK_a = 6.55$		
*3.31 ^d	?	236						
3.31 (0.20)	Recommended							
$C_{10}H_{23}N$		1-Aminodecane		CAS # 2016-57-1		$pK_a = 10.64$		
1.92 ^a	D	233	AMB	SF	RC	pH7	Both	3
4.1 (0.4)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{11}H_9N$			2-Phenylpyridine	CAS # 1008-89-5		$pK_a = 4.63$		
*2.63	D	104					Both	
2.68	I	143		HPLC				
2.63 (0.25)	Recommended							
$C_{11}H_9N$			4-Phenylpyridine	CAS # 939-23-1		$pK_a = 5.45$		
2.45	D	104						
*2.59	D	104						
2.62	D	104					Both	
2.58	I	143		HPLC				
2.59 (0.10)	Recommended							
$C_{11}H_{13}N$			2-Endoamino-benzobicyclo [2,2,1] -heptane	CAS # 58742-04-4				
						$pK_a = 11.$ (est.)		
*2.00	D	254		SF	GLC	pH13	Both	
2.00 (0.20)	Recommended							
$C_{11}H_{13}N$			2-Exoamino-benzobicyclo [2,2,1] -heptane	CAS # 62624-26-4				
						$pK_a = 11.$ (est.)		
*2.09	D	254		SF	GLC	pH13	Both	
2.09 (0.20)	Recommended							
$C_{11}H_{13}N$			9-Endoamino-benzobicyclo[2,2,1] -heptane	CAS # 72597-35-4				
						$pK_a = 11.$ (est.)		
*2.08	D	254		SF	GLC	pH13	Both	
2.08 (0.20)	Recommended							
$C_{11}H_{13}N$			9-Exoamino-benzobicyclo[2,2,1] -heptane	CAS # 14098-20-5				
						$pK_a = 11.$ (est.)		
*2.13	D	254		SF	GLC	pH13	Both	
2.13	D	243		SF	GLC	pH13	AQ	
2.13 (0.20)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{11}H_{15}N$							CAS # 19485-85-9	
							$pK_a = 10.$ (est.)	
*2.38	D	243		SF	GLC	pH13	AQ	
2.38 (0.20)	Recommended							
$C_{11}H_{15}N$							$pK_a = 10.41$	
2.39	I	143	23				microelectrometric titration	
2.39 (0.20)	Recommended							
$C_{11}H_{15}N$							$pK_a = 7.0$ (est.)	
2.78	D	104						
*2.98	D	104				pH13		
2.98 (0.30)	Recommended							
$C_{11}H_{17}N$							$pK_a = 10.03$	
*2.79	D	247	25	SF	AS	pH>12	AQ	
2.79 (0.25)	Recommended							
$C_{11}H_{17}N$							$pK_a = 9.90$	
*2.59	D	247	25	SF	AS	pH>12	AQ	
2.59 (0.25)	Recommended							
$C_{11}H_{17}N$							$pK_a = 11.$ (est.)	
2.76	D	243		SF	GLC	pH13	AQ	
2.76 (0.25)	Recommended							
$C_{11}H_{17}N$							CAS # 1199-99-1	
							$pK_a = 10.$ (est.)	
*2.73	D	120		SF	AS	W	AQ	46
2.73 (0.27)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₁ H ₁₇ N		4-Hexylpyridine		CAS # 27876-24-0		pK _a = 6.0 (est.)		
4.35 ^b	D	252	25	SF	AS	NS	AQ	
4.35 (0.40)	Recommended							
C ₁₁ H ₂₃ N		1-cyclooctyl-2-aminopropane				pK _a = 11. (est.)		
*3.70	D	243		SF	GLC	pH13	AQ	
3.70 (0.30)	Recommended							
C ₁₂ H ₉ N		Carbazole	CAS # 86-74-8		pK _a = -4. (est.)			
3.29	D	40	25	SF	AS	pH7.4	Both	117
*3.72	D	104						
3.76	D	104						
3.01	I	65	HPLC					
3.72 (0.40)	Recommended							
C ₁₂ H ₁₁ N		2-Aminobiphenyl	CAS # 90-41-5		pK _a = 3.82 (22°C)			
2.83 ^a	D	104			pH7.4			
*2.84	D	104						
2.84 (0.25)	Recommended							
C ₁₂ H ₁₁ N		4-Aminobiphenyl	CAS # 92-67-1		pK _a = 4.26			
2.86	D	238		SF	AS	pH7.5	AQ	1
2.86 (0.25)	Recommended							
C ₁₂ H ₁₁ N		Diphenylamine	CAS # 122-39-4		pK _a = 0.78			
3.22	D	40	25	SF	AS	pH7.4	Both	117
3.34	D	104						
3.37	D	92		SF				
3.42	D	86	20	SF	AS	W	AQ	46
*3.50	D	104						
2.37?	I	56	HPLC					
2.69? ^e	I	64	HPLC					
3.50 (0.25)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{12}H_{15}N$			2-Endoamino-benzobicyclo[2,2,2]-octane			CAS # 14342-36-0		
*2.29	D	254		SF	GLC	pH13	Both	$pK_a = 11.$ (est.)
2.29	(0.20)	Recommended						
$C_{12}H_{15}N$			2-Exoamino-benzobicyclo[2,2,2]-octane			CAS # 15537-20-9		
*2.32	D	254		SF	GLC	pH13	Both	$pK_a = 11.$ (cst.)
2.32	(0.20)	Recommended						
$C_{12}H_{15}N$			2-Endomethylamino-benzobicyclo[2,2,1]-heptane			CAS # 58742-05-5		
*2.32	D	254		SF	GLC	pH13	Both	$pK_a = 11.$ (est.)
2.32	(0.20)	Recommended						
$C_{12}H_{15}N$			2-Exomethylamino-benzobicyclo[2,2,1]-heptane			CAS # 62624-27-5		
*2.41	D	254		SF	GLC	pH13	Both	$pK_a = 11.$ (est.)
2.41	(0.20)	Recommended						
$C_{12}H_{15}N$			9-Endomethylamino-benzobicyclo[2,2,1]-heptane			CAS # 86992-69-0		
*2.37	D	254		SF	GLC	pH13	Both	$pK_a = 11.$ (est.)
2.37	(0.20)	Recommended						
$C_{12}H_{15}N$			9-Exomethylamino-benzobicyclo[2,2,1]-heptane			CAS # 86943-79-5		
*2.47	D	254		SF	GLC	pH13	Both	$pK_a = 11.$ (est.)
2.47	D	243		SF	GLC	pH13	AQ	
2.47	(0.25)	Recommended						

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₁₂ H ₁₇ N		4-Cyclohexylaniline		CAS # 6373-50-8		pK _a = 4.96		
3.31	D	238		SF	AS	pH7.5	AQ	1
*3.65	D	104						
3.65 (0.30)	Recommended							
C ₁₂ H ₁₉ N		1-Phenyl-2-aminohexane		CAS # 67309-36-8		pK _a = 10.04		
*3.36	D	247	25	SF	AS	pH>12	AQ	
3.36 (0.20)	Recommended							
C ₁₂ H ₁₉ N		1-Phenyl-2-amino-4-methylpentane		CAS # 67309-38-0		pK _a = 10.03		
*3.29	D	247	25	SF	AS	pH>12	AQ	
3.29 (0.30)	Recommended							
C ₁₂ H ₁₉ N		1-Phenyl-2-amino-3,3-dimethylbutane		CAS # 67309-37-9		pK _a = 9.64		
*2.91	D	247	25	SF	AS	pH>12	AQ	
2.91 (0.30)	Recommended							
C ₁₂ H ₁₉ N		1-(3,4,5-Trimethylphenyl)-2-aminopropane				pK _a = 10. (est.)		
1.48? ^b	D	248	AMB	SF	AS	pH7.4	AQ	
3.50 (0.35)	Recommended							
C ₁₂ H ₁₉ N		2,6-Diisopropylaniline		CAS # 24544-04-5		pK _a = 4.0 (est.)		
*3.18	D	104						
3.18 (0.30)	Recommended							
C ₁₂ H ₁₉ N		4-Heptylpyridine		CAS # 40089-90-5		pK _a = 6.0 (est.)		
5.00 ^b	D	252	25	SF	AS	NS	AQ	
5.00 (0.50)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{13}H_9N$	Acridine		CAS # 260-94-6		$pK_a = 10.65$			
3.29 ^a	D	255		SF	AS	pH7.4		
3.32	D	132		SF	GLC	pH7	Both	
*3.40	?	124						
3.62	?	198						
3.40 (0.25)	Recommended							
$C_{13}H_{13}N$	N-Benzylaniline		CAS # 103-32-2		$pK_a = 4.04$			
*3.13	D	104						
3.13 (0.30)	Recommended							
$C_{13}H_{13}N$	N,N-Diphenylaminomethane		CAS # 552-82-9		$pK_a = 0.7$ (est.)			
3.16	D	104						
*3.90	D	104				pH13		
3.90 (0.30)	Recommended							
$C_{14}H_{11}N$	2-Aminoanthracene		CAS # 613-13-8		$pK_a = 4.1$			
4.13?	D	217	AMB	SF	RC	W	Both	134
3.4 (0.3)	Recommended							
$C_{15}H_{11}N$	2-Phenylquinoline		CAS # 612-96-4		$pK_a = 4.4$ (est.)			
*3.90	D	104						
3.96	D	104						
4.14 ^a	D	104				pH7.4		
3.90 (0.40)	Recommended							
$C_{15}H_{17}N$	1,3-Diphenyl-2-aminopropane		CAS # 4275-43-8		$pK_a = 9.31$			
*3.35	D	247	25	SF	AS	pH>12	AQ	
3.35 (0.35)	Recommended							
$C_{16}H_{13}N$	N-Phenyl-1-aminonaphthalene		CAS # 90-30-2		$pK_a = 0.8$ (est.)			
4.20	D	256	22	SF	FL	W	Both	
4.20 (0.40)	Recommended							

Table 15. Amines (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
$C_{16}H_{19}N$			1-Amino-4,4-diphenylbutane		$pK_a = 9.0$ (est.)			
0.74 ^a	D	253		SF	AS	pH6.8	AQ	1
4.0 (0.4)	Recommended							
$C_{18}H_{13}N$			6-Aminochrysene	CAS # 2642-98-0	$pK_a = 3.7$ (est.)			
*4.98	D	217	AMB	SF	RC	W	Both	134
4.98 (0.50)	Recommended							
$C_{18}H_{15}N$			Triphenylamine	CAS # 603-34-9	$pK_a = -5$ (est.)			
5.70	D	132		SF	GLC	pH7	Both	
*5.74	D	104						
5.74 (0.50)	Recommended							
$C_{18}H_{23}N$			N,N-Dimethyl-1-amino-4,4-diphenylbutane		$pK_a = 10.$ (est.)			
2.30 ^a	D	253		SF	AS	pH6.8	AQ	1
4.8 (0.5)	Recommended							

^a Not ion-corrected.^b Ion-corrected.^c Buffer, pH not specified.^d From an unidentified literature source.^e Average value.^f D. Kotzias, personal communication.^g From a restricted correlation plot.

Table 16. Nitriles

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_2H_3N		Ethanenitrile		CAS # 75-05-8				
-0.54	D	257	AMB	SF	GLC	W	AQ	194
*-0.34	D	111		SF	GLC	W	AQ	46
-0.34 (0.05)	Recommended							
C_3H_3N		Propenenitrile (acrylonitrile)		CAS # 107-13-1				
0.00	D	218		SF				
0.09	D	257	AMB	SF	GLC	W	AQ	194
*0.25	D	151		SF	HPLC	NS	Both	
0.25 (0.20)	Recommended							
C_3H_5N		Propanenitrile		CAS # 107-12-0				
-0.10	D	257	AMB	SF	GLC	W	AQ	194
0.04	D	147	18	SF	K	W	Both	148
*0.16	D	30,111		SF	GLC	W	AQ	46
0.16 (0.05)	Recommended							
C_4H_5N		3-Butenenitrile (allylnitrile)		CAS # 109-75-1				
*0.40	D	257	AMB	SF	GLC	W	AQ	194
0.40 (0.10)	Recommended							
C_4H_5N		2-Methylpropenenitrile (methacrylonitrile)		CAS # 126-98-7				
*0.68	D	257	AMB	SF	GLC	W	AQ	194
0.68 (0.25)	Recommended							
C_4H_7N		Butanenitrile		CAS # 109-74-0				
0.53	D	257	AMB	SF	GLC	W	AQ	194
0.60 (0.10)	Recommended							
C_4H_7N		Methylpropanenitrile		CAS # 78-82-0				
*0.46	D	257	AMB	SF	GLC	W	AQ	194
0.46 (0.25)	Recommended							

Table 16. Nitriles (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₅ H ₉ N		Pentanenitrile		CAS # 110-59-8				
*0.94	D	257	AMB	SF	GLC	W	AQ	194
0.94 (0.30)	Recommended							
C ₅ H ₉ N		2-Methylbutanenitrile		CAS # 18936-17-9				
*1.05	D	257	AMB	SF	GLC	W	AQ	194
1.05 (0.10)	Recommended							
C ₅ H ₉ N		3-Methylbutanenitrile		CAS # 625-28-5				
*0.85	D	257	AMB	SF	GLC	W	AQ	194
0.85 (0.35)	Recommended							
C ₆ H ₁₁ N		Hexanenitrile		CAS # 628-73-9				
*1.66	D	257	AMB	SF	GLC	W	AQ	194
1.66 (0.20)	Recommended							
C ₆ H ₁₁ N		4-Methylpentanenitrile		CAS # 542-54-1				
*1.54	D	257	AMB	SF	GLC	W	AQ	194
1.54 (0.15)	Recommended							
C ₇ H ₅ N		Benzonitrile		CAS # 100-47-0				
*1.56	D	46	25	SF	AS	W	AQ	
1.56	D	190	25	SF	AS	W	ORG	191
1.56	D	257	AMB	SF	GLC	W	AQ	194
1.50	I	57		HPLC				
1.57	?	131						
1.56 (0.05)	Recommended							
C ₈ H ₇ N		Phenylethanenitrile		CAS # 140-29-4				
*1.56	D	120		SF	AS	W	AQ	46
1.61	D	257	AMB	SF	GLC	W	AQ	194
1.44	I	57		HPLC				
1.47 ^a	I	64		HPLC				
1.56 (0.20)	Recommended							

Table 16. Nitriles (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₈ H ₇ N		2-Methylbenzonitrile		CAS # 529-19-1				
*2.21	D	104						
2.21 (0.20)	Recommended							
C ₈ H ₁₅ N		Octanenitrile		CAS # 124-12-9				
*2.75	D	257	AMB	SF	GLC	W	AQ	194
2.75 (0.25)	Recommended							
C ₉ H ₇ N		3-Phenylpropenenitrile (cinnamonnitrile, isomer not specified)						
1.94	I	57		HPLC			CAS # 1885-38-7	
*1.96	?	199						
1.94 (0.20)	Recommended							
C ₉ H ₉ N		Benzylethanenitrile		CAS # 645-59-0				
1.66	D	104						
1.70	D	257	AMB	SF	GLC	W	AQ	194
*1.72	D	120		SF	AS	W	AQ	46
1.70	?	199						
1.72 (0.15)	Recommended							
C ₉ H ₉ N		4-Methylphenylethanenitrile		CAS # 2947-61-7				
1.62	?	131						
1.8 (0.2)	Recommended							

^a Average value.

Table 17. Nitro compounds

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_3NO_2		Nitromethane		CAS # 75-52-5				
*-0.35	D	104					Both	
-0.33	D	111		SF	AS	W	one	46
0.08	D	147	20	SF	K	W	Both	148
-0.33 (0.05)		Recommended						
$\text{C}_2\text{H}_5\text{NO}_2$		Nitroethane		CAS # 79-24-3				
0.18	D	111		SF	AS	W	one	46
*0.18	D	104					Both	
0.18 (0.10)		Recommended						
$\text{C}_3\text{H}_7\text{NO}_2$		1-Nitropropane		CAS # 108-03-2				
*0.87	D	104					Both	
0.87 (0.07)		Recommended						
$\text{C}_4\text{H}_9\text{NO}_2$		1-Nitrobutane		CAS # 627-05-4				
*1.47	D	104					Both	
1.47 (0.12)		Recommended						
$\text{C}_4\text{H}_9\text{NO}_2$		2-Methyl-2-nitropropane		CAS # 594-70-7				
1.01	D	104						
*1.17	D	104						
1.17 (0.15)		Recommended						
$\text{C}_5\text{H}_{11}\text{NO}_2$		1-Nitropentane		CAS # 628-05-7				
*2.01	D	104					Both	
2.01 (0.20)		Recommended						

Table 17. Nitro compounds (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₅ NO ₂		Nitrobenzene		CAS # 98-95-3				
1.80	D	104						
1.83	D	108	23	SF	RC	W	Both	
*1.85	D	30,46	25	SF	AS	W	AQ	
1.85	D	86	20	SF	AS	W	AQ	46
1.85	D	9,10	25	G	HPLC	W	Both	11
1.85	D	78	30	SF	AS	W	Both	37
1.88	D	104						
1.70	I	121		HPLC				
1.79	?	150						
1.82	I	56		HPLC				
1.83	I	74	25	from UNIFAC activity coefficients				
1.84	I	75	25	from UNIFAC activity coefficients				
1.85 (0.05)		Recommended						
C ₇ H ₇ NO ₂		2-Nitrotoluene		CAS # 88-72-2				
*2.30	D	104						
2.30 (0.25)		Recommended						
C ₇ H ₇ NO ₂		3-Nitrotoluene		CAS # 99-08-1				
2.40	D	104						
*2.45	D	46	25	SF	AS	W	AQ	
2.45 (0.10)		Recommended						
C ₇ H ₇ NO ₂		4-Nitrotoluene		CAS # 99-99-0				
*2.37	D	46	25	SF	AS	W	AQ	
2.42	D	104						
2.42 (0.10)		Recommended						
C ₇ H ₇ NO ₂		Phenylnitromethane		CAS # 622-42-4				
*1.75	D	104						
1.75 (0.35)		Recommended						

Table 18. Amides

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
CH_3NO		Methanamide (formamide)		CAS # 75-12-7				
*-1.51	D	104						
-1.51	(0.30)	Recommended						
$\text{C}_2\text{H}_5\text{NO}$		Ethanamide (acetamide)		CAS # 60-35-5				
*-1.26	D	104						
-1.26	D	258		SF	GLC	W	ORG	46
-1.15	D	202	25	SF	RC	pH1		
-1.09	D	156		SF	RC	a	Both	
-1.26	(0.10)	Recommended						
$\text{C}_3\text{H}_5\text{NO}$		Propenamide (acrylamide)		CAS # 79-06-1				
-0.90	D	218		SF				
*-0.67	D	104						
-1.24?	I	144		HPLC				
-0.78	(0.13)	Recommended						
$\text{C}_3\text{H}_7\text{NO}$		N,N-Dimethylmethanamide		CAS # 68-12-2				
*-1.01	D	104						
-1.01	(0.20)	Recommended						
$\text{C}_3\text{H}_7\text{NO}$		N-Methylethanamide		CAS # 79-16-3				
-1.10	D	202	25	SF	RC	pH1		
*-1.05	D	104						
-1.05	(0.10)	Recommended						
$\text{C}_4\text{H}_9\text{NO}$		Butanamide		CAS # 541-35-5				
*-0.21	D	111		SF	CR	W	one	46
-0.21	(0.10)	Recommended						
$\text{C}_4\text{H}_9\text{NO}$		N,N-Dimethylethanamide		CAS # 127-19-5				
-0.77	D	202	25	SF	RC	pH1		
*-0.77	D	104						
-0.77	(0.10)	Recommended						

Table 18. Amides (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₆ H ₁₃ NO		N,N-Diethylethanamide			CAS # 685-91-6			
*0.34	D	104						
0.34 (0.12)	Recommended							
C ₇ H ₇ NO		Benzamide		CAS # 55-21-0				
*0.64	D	46	25	SF	AS	W	AQ	
0.64	D	258		SF	GLC	W	AQ	46
0.65	D	104						
0.66	D	154		SF	AS			
0.69	D	260	22	SF	AS	pH9.2	AQ	
0.70	D	260	22	SF	AS	pH3	AQ	
0.84	I	121		HPLC				
0.64 (0.06)	Recommended							
C ₇ H ₇ NO		N-Phenylmethanamide (formanilide)		CAS # 103-70-8				
1.12	D	259	25	SF	AS	W	Both	
*1.15	D	104						
1.26	D	104						
1.00	I	57		HPLC				
1.15 (0.15)	Recommended							
C ₈ H ₉ NO		Phenylethanamide		CAS # 103-81-1				
*0.45	D	120		SF	AS	W	AQ	46
0.45 (0.10)	Recommended							
C ₈ H ₉ NO		3-Methylbenzamide		CAS # 618-47-3				
*1.18	D	104						
1.18 (0.20)	Recommended							
C ₈ H ₉ NO		N-(4-Methylphenyl)methanamide		CAS # 3085-54-9				
*1.61	D	259	25	SF	AS	W	Both	
1.61 (0.25)	Recommended							

Table 18. Amides (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_8H_9NO				N-Phenylethanamide (acetanilide)	CAS # 103-84-4			
1.15	D	104				pH3.1		
*1.16	D	46	25	SF	AS	W	AQ	
1.16	D	86	20	SF	AS	W	AQ	46
1.17	D	104						
1.17	D	104						
1.36	D	104						
1.14	I	60		HPLC				
1.16 ^b	I	57		HPLC				
1.27 ^b	I	64		HPLC				
1.16 (0.05)	Recommended							
C_8H_9NO				N-Methylbenzamide	CAS # 613-93-4			
*0.86	D	104						
0.86 ^c	?	222						
0.86 (0.10)	Recommended							
C_8H_9NO				N-Methyl-N-phenylmethanamide	CAS # 3085-54-9			
*1.09	D	104						
1.09 (0.10)	Recommended							
C_9H_8NO				N-(2-Methylphenyl)ethanamide	CAS # 120-66-1			
0.84?	D	20		SF	AS	W	ORG	264
1.51 (0.20)	Recommended							
C_9H_8NO				N-(3-Methylphenyl)ethanamide	CAS # 537-92-8			
1.59	D	20		SF	AS	W	ORG	264
1.51 (0.20)	Recommended							
C_9H_8NO				N-(4-Methylphenyl)ethanamide	CAS # 103-89-9			
1.59	D	20		SF	AS		ORG	264
1.51 (0.20)	Recommended							

Table 18. Amides (continued)

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_9H_9NO				3-Phenylpropenamide (cinnamide)	CAS # 621-79-4			
*1.43	D	104						
1.41	?	199						
1.43 (0.15)	Recommended							
$C_{12}H_{17}NO$				N,N-Diethyl-2-methylbenzamide	CAS # 2728-04-3			
2.02	D	261	25	SF	HPLC	W	Both	
2.02 (0.20)	Recommended							
$C_{13}H_{11}NO$				N-Phenylbenzamide	CAS # 93-98-1			
*2.62	D	104						
2.70	D	104						
2.62 (0.20)	Recommended							

^a Schistosome saline solution.^b Average value.^c D. E. Leahy and co-workers, personal communication.

Table 19. Sulphur compounds

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C ₃ H ₈ S		Propanethiol		CAS # 107-03-9				
*1.81	D	104						
1.81	(0.15)	Recommended						
C ₄ H ₈ S		Thiophene		CAS # 110-02-1				
*1.81	D	120		SF	AS	W	AQ	46
1.82	D	104						
1.81	(0.20)	Recommended						
C ₄ H ₁₀ S		Butanethiol		CAS # 109-79-5				
*2.28	D	104						
2.28	(0.25)	Recommended						
C ₄ H ₁₀ S		3-Thiapentane (diethylsulphide)		CAS # 352-93-2				
*1.95	D	111		SF	AS	W	AQ	46
1.95	(0.20)	Recommended						
C ₆ H ₆ S		Thiophenol		CAS # 108-98-5				
*2.52	D	104						
2.52	(0.25)	Recommended						
C ₇ H ₈ S		Thiomethylbenzene		CAS # 100-68-5				
*2.74	D	104						
2.74	(0.25)	Recommended						
C ₈ H ₆ S		Benzothiophene		CAS # 95-15-8				
3.09	D	40	25	SF	AS	pH7.4	Both	117
*3.12	D	104						
3.12	(0.10)	Recommended						
C ₁₂ H ₈ S		Dibenzothiophene		CAS # 132-65-0				
*4.38	?	198						
4.38	(0.40)	Recommended						
C ₁₂ H ₁₀ S		Diphenylsulphide		CAS # 139-66-2				
3.47	D	104						
*4.45	D	104						
4.45	(0.40)	Recommended						

Table 20. Other

Log P	Code	Ref.	Temp.	Equil. Method	Anal. Method	Aq. Phase	Phases Analyzed	Method Ref.
C_2H_6OS				Dimethylsulphoxide	CAS # 67-68-5			
*-1.35	D	104						
-1.35 (0.20)	Recommended							
$C_2H_6O_2S$				Dimethylsulphone	CAS # 67-71-0			
*-1.41	D	104						
-1.41 (0.20)	Recommended							
$C_5H_{10}O_3$				Diethylcarbonate	CAS # 105-58-8			
*1.21	D	104						
1.21 (0.25)	Recommended							
$C_6H_{14}O_2S$				Dipropylsulphone	CAS # 598-03-8			
0.39	D	262	24	SF	GLC	W	ORG	263
1.15 (0.20)	Recommended							
C_7H_8OS				Methylphenylsulphoxide	CAS # 1193-82-4			
*0.55	D	104						
0.55 (0.10)	Recommended							
$C_7H_8O_2S$				Methylphenylsulphone	CAS # 3112-85-4			
0.47	D	111		SF	AS	W	one	46
*0.50	D	104						
0.50 (0.10)	Recommended							
$C_{12}H_{10}N_2$				Azobenzene	CAS # 103-33-3			
*3.82	D	46	25	SF	AS	W	AQ	
3.82	D	86	20	SF	AS	W	AQ	46
3.82 (0.20)	Recommended							
$C_{12}H_{10}OS$				Diphenylsulphoxide	CAS # 945-51-7			
*2.06	D	104						
2.06 (0.20)	Recommended							
$C_{13}H_{10}O_3$				Diphenylcarbonate	CAS # 102-09-0			
*3.28	D	104						
3.28 (0.30)	Recommended							

7. References

- ¹A. Leo, C. Hansch, and D. Elkins, *Chem. Rev.* **71**, 525 (1971).
- ²C. Hansch and A. Leo, *Substituent Constants for Correlation Analysis in Chemistry and Biology* (Wiley, New York, 1979).
- ³W. P. Purcell, G. E. Bass, and J. M. Clayton, *Strategy of Drug Design, A Guide to Biological Activity*, Appendix I (Wiley, New York, 1973).
- ⁴A. E. Bird and J. H. C. Nayler, "Design of penicillins", in *Drug Design*, edited by E. J. Ariens, (Academic, New York, 1971), Vol. 2.
- ⁵D. Mackay, *Environ. Sci. Technol.* **16**, 274 (1982).
- ⁶G. R. B. Webster, K. J. Friesen, L. P. Sarna, and D. C. G. Muir, *Chemosphere* **14**, 609 (1985).
- ⁷E. Halfon, *Ecolog. Modelling* **22**, 213 (1983).
- ⁸R. F. Rekker, *The Hydrophobic Fragmental Constant: its Derivation and Application. A Means of Characterizing Membrane Systems* (Elsevier, New York, 1977).
- ⁹Y. B. Tewari, M. M. Miller, S. P. Wasik, and D. E. Martire, *J. Chem. Eng. Data* **27**, 451 (1982).
- ¹⁰S. P. Wasik, Y. B. Tewari, M. M. Miller, and D. E. Martire, *Octanol/Water Partition Coefficients and Aqueous Solubilities of Organic Compounds*, NBSIR No. 81-2406 (U. S. Dept. of Commerce, Washington, 1981).
- ¹¹H. DeVoe, M. M. Miller, and S. P. Wasik, *J. Res. Nat. Bur. Stand.* **86**, 361 (1981).
- ¹²A. Opperhuizen, P. Serné, and J. M. Van der Steen, *Environ. Sci. Technol.* **22**, 286 (1988).
- ¹³C. Repond, J. M. Mayer, H. Van de Waterbeemd, B. Testa, and W. Linter, *Int. J. Pharmaceut.* **38**, 47 (1987).
- ¹⁴R. H. Guy and D. H. Honda, *Int. J. Pharmaceut.* **19**, 129 (1984).
- ¹⁵A. Brodin, B. Sandin, and B. Fajerson, *Acta Pharm. Suec.* **13**, 331 (1976).
- ¹⁶Ya. I. Korenman and V. Yu. Udalova, *Russ. J. Phys. Chem. (Engl. Transl.)* **48**, 708 (1974).
- ¹⁷J. A. Rogers and A. Wong, *Int. J. Pharmaceut.* **6**, 339 (1980).
- ¹⁸M. J. James, S. S. Davis, and N. Anderson, *J. Pharm. Pharmacol., Suppl.* **33**, 108P (1981).
- ¹⁹A. E. Beezer, W. H. Hunter, and D. E. Storey, *J. Pharm. Pharmacol.* **32**, 815 (1980).
- ²⁰J. C. Dearden and G. M. Bresnen, *J. Pharm. Pharmacol., Suppl.* **33**, 107P (1981).
- ²¹W. Riebesehl and E. Tomlinson, *J. Phys. Chem.* **88**, 4770 (1984).
- ²²P. Berti, S. Cabani, G. Conti, and V. Mollica, *J. Chem. Soc., Faraday Trans. 1* **82**, 2547 (1986).
- ²³W. Riebesehl and E. Tomlinson, *J. Chem. Soc., Faraday Trans. 1* **79**, 1311 (1983).
- ²⁴J. M. Sorensen and W. Arlt *Liquid-Liquid Equilibrium Data Collection: Binary Systems*, edited by (Deutsche Gesellschaft für Chemische Apparatewesen (DECHEMA), Frankfurt/Main, 1979), p. 501.
- ²⁵B. T. Bowman and W. W. Sans, *J. Environ. Sci. Health B* **18**, 667 (1983).
- ²⁶A. E. Beezer, W. H. Hunter, and D. E. Storey, *J. Pharm. Pharmacol.* **35**, 350 (1983).
- ²⁷W. Riebesehl and E. Tomlinson, *J. Solution Chem.* **15**, 141 (1986).
- ²⁸R. F. Platford, *J. Chem. Soc., Faraday Trans. 1* **73**, 267 (1977).
- ²⁹R. F. Platford, *J. Solution Chem.* **5**, 645 (1976).
- ³⁰C. Hansch, J. E. Quinlan, and G. L. Lawrence, *J. Org. Chem.* **33**, 347 (1968).
- ³¹D. Mackay, *Environ. Sci. Technol.* **11**, 1219 (1977).
- ³²C. T. Chiou and V. H. Freed, *Environ. Sci. Technol.* **11**, 1220 (1977).
- ³³D. Mackay, A. Bobra, W. Y. Shiu, and S. H. Yalkowsky, *Chemosphere* **9**, 701 (1980).
- ³⁴M. M. Miller, S. Ghodbane, S. P. Wasik, Y. B. Tewari, and D. E. Martire, *J. Chem. Eng. Data* **29**, 184 (1984).
- ³⁵C. Tsonopoulos and J. M. Prausnitz, *Ind. Eng. Chem. Fund.* **10**, 593 (1971).
- ³⁶S. H. Yalkowsky, *Ind. Eng. Chem. Fund.* **18**, 108 (1979).
- ³⁷S. H. Yalkowsky, S. C. Valvani, and T. J. Roseman, *J. Pharmaceut. Sci.* **72**, 866 (1983).
- ³⁸M. M. Miller, S. P. Wasik, G.-L. Huang, W.-Y. Shiu, and D. Mackay, *Environ. Sci. Technol.* **19**, 522 (1985).
- ³⁹C. T. Chiou, D. W. Schmedding, and M. Manes, *Environ. Sci. Technol.* **16**, 4 (1982).
- ⁴⁰K. S. Rogers and A. Cammarata, *J. Med. Chem.* **12**, 692 (1969).
- ⁴¹D. Mackay and W. Y. Shiu, *J. Phys. Chem. Ref. Data* **10**, 1175 (1981).
- ⁴²T. C. Hutchinson, J. A. Hellebust, D. Tam, D. Mackay, R. A. Mascarenhas, and W. Y. Shiu, "The correlation of the toxicity to algae of hydrocarbons and halogenated hydrocarbons with their physical-chemical properties", in *Hydrocarbons and Halogenated Hydrocarbons in the Aquatic Environment*, edited by B. K. Afghan and D. Mackay, (Plenum, New York, 1980).
- ⁴³S. P. Wasik, F. P. Schwarz, Y. B. Tewari, M. M. Miller, and J. H. Purnell, *J. Res. Nat. Bur. Stand.* **89**, 273 (1984).
- ⁴⁴F. H. Clarke, *J. Pharmaceut. Sci.* **73**, 226 (1984).
- ⁴⁵K. L. E. Kaiser and I. Valdmanis, *Can. J. Chem.* **60**, 2104 (1982).
- ⁴⁶T. Fujita, J. Iwasawa, and C. Hansch, *J. Am. Chem. Soc.* **86**, 5175 (1964).
- ⁴⁷K. Opong-Mensah, T. W. Woller, and A. O. Obaseki, *J. Pharm. Biomed. Anal.* **2**, 381 (1984).
- ⁴⁸N. C. Saha, N. Bhattacharjee, N. G. Basak, and A. Lahiri, *J. Chem. Eng. Data* **8**, 405 (1963).
- ⁴⁹H. Terada, Y. Kosuge, N. Nakaya, W. Murayama, Y. Nunogaki, and K. I. Nunogaki, *Chem. Pharm. Bull.* **35**, 5010 (1987).
- ⁵⁰S. S. Davis, G. Elson, E. Tomlinson, G. Harrison, and J. C. Dearden, *Chemistry and Industry* **16**, 677 (1976).
- ⁵¹J. F. M. Kinkel, E. Tomlinson, and P. Smit, *Int. J. Pharmaceut.* **9**, 121 (1981).
- ⁵²E. Tomlinson, *J. Pharmaceut. Sci.* **71**, 602 (1982).
- ⁵³J. F. M. Kinkel and E. Tomlinson, *Int. J. Pharmaceut.* **6**, 261 (1980).
- ⁵⁴L. Rodriguez, V. Zecchi, and A. Tartarini, *Pharm. Acta Helv.* **59**, 95 (1984).
- ⁵⁵B. Dolezal, J. Horejs, and R. Holub, *Fluid Phase Equil.* **18**, 211 (1984).
- ⁵⁶G. D. Veith, N. M. Austin, and R. T. Morris, *Water Res.* **13**, 43 (1979).
- ⁵⁷J. E. Haky and A. M. Young, *J. Liquid Chromatogr.* **7**, 675 (1984).
- ⁵⁸M. M. Schantz and D. E. Martire, *J. Chromatogr.* **391**, 35 (1987).
- ⁵⁹M. M. Schantz, Ph. D. thesis, Georgetown University, 1986; Diss. Abst. Int. B **47**, 4899 (1987).
- ⁶⁰M. S. Mirrlees, S. J. Moulton, C. T. Murphy, and P. J. Taylor, *J. Med. Chem.* **19**, 615 (1976).
- ⁶¹D. Henry, J. H. Block, J. L. Anderson, and G. R. Carlson, *J. Med. Chem.* **19**, 619 (1976).
- ⁶²K. Miyake and H. Terada, *J. Chromatogr.* **157**, 386 (1978).
- ⁶³K. Miyake, F. Kitaura, N. Mizuno, and H. Terada, *J. Chromatogr.* **389**, 47 (1987).
- ⁶⁴J. Ge, W. Liu, and S. Dong, *Separation Sci.* **5**, 182 (1987).
- ⁶⁵C. V. Eadsforth, *Pestic. Sci.* **17**, 311 (1986).
- ⁶⁶J. E. Garst and W. C. Wilson, *J. Pharm. Sci.* **73**, 1616 (1984).
- ⁶⁷O. Papp, K. Valko, G. Szasz, I. Hermecz, J. Vamos, K. Hanko, and Zs. Ignath-Halasz, *J. Chromatogr.* **252**, 67 (1982).
- ⁶⁸W. A. Bruggeman, J. Van der Steen, and O. Hutzinger, *J. Chromatogr.* **238**, 335 (1982).
- ⁶⁹T. Kubota, K. Kano, E. Kawata, and H. Hashizume, *Gifu Yakka Daigaku Kiyo* **36**, 32 (1987).
- ⁷⁰A. Brändström, *Acta Chem. Scand.* **17**, 1218 (1963).
- ⁷¹K. Ezumi and T. Kubota, *Chem. Pharm. Bull.* **28**, 85 (1980).
- ⁷²G. Burgot and J.-L. Burgot, *Thermochimica Acta* **81**, 147 (1984).
- ⁷³P. Seiler, *Eur. J. Med. Chem.-Chim. Ther.* **9**, 473 (1974).
- ⁷⁴W. B. Arbuckle, *Environ. Sci. Technol.* **17**, 537 (1983).
- ⁷⁵J. R. Campbell and R. G. Luthy, *Environ. Sci. Technol.* **19**, 980 (1985).
- ⁷⁶J. T. Chou and P. C. Jurs, *J. Chem. Inf. Comput. Sci.* **19**, 172 (1979).
- ⁷⁷T. M. Dyott, A. J. Stuper, and G. S. Zander, *J. Chem. Inf. Comput. Sci.* **20**, 28 (1980).
- ⁷⁸K. L. E. Kaiser, *Chemosphere* **12**, 1159 (1983).
- ⁷⁹S. H. Yalkowsky and S. C. Valvani, *J. Chem. Eng. Data* **24**, 127 (1979).
- ⁸⁰N. Funasaki, S. Hada, and S. Neya, *J. Phys. Chem.* **89**, 3046 (1985).
- ⁸¹W. J. Doucette and A. W. Andren, *Environ. Sci. Technol.* **21**, 821 (1987).
- ⁸²G. Klopman and L. D. Iroff, *J. Comput. Chem.* **2**, 157 (1981).
- ⁸³M. J. Kamlet, M. H. Abraham, R. M. Doherty, and R. W. Taft, *J. Am. Chem. Soc.* **106**, 464 (1984).
- ⁸⁴K. Yoshida, T. Shigeoka, and F. Yamauchi, *Ecotox. Environ. Safety* **7**, 558 (1981).
- ⁸⁵A. J. Hopfinger and R. D. Battershell, *J. Med. Chem.* **19**, 569 (1976).
- ⁸⁶G. G. Briggs, *J. Agric. Food Chem.* **29**, 1050 (1981).
- ⁸⁷N. C. Deno and H. E. Berkheimer, *J. Chem. Eng. Data* **5**, 1 (1960).
- ⁸⁸R. Staroscik and T. Blaskiewicz, *Die Pharmazie* **40**, 248 (1985).
- ⁸⁹G. Voss, *Analyst* **103**, 233 (1978).
- ⁹⁰L. B. Kier and L. H. Hall, *Molecular Connectivity in Chemistry and Drug Research* (Academic, New York, 1976).
- ⁹¹M. Kuchar, V. Rejholec, E. Kraus, V. Miller, and V. Rabek, *J. Chromatogr.* **280**, 279 (1983).
- ⁹²C. V. Eadsforth and P. Moser, *Chemosphere* **12**, 1459 (1983).
- ⁹³M. Harnisch, H. J. Möckel, and G. Schulze, *J. Chromatogr.* **282**, 315 (1983).

- ⁹⁴D. N. Brooke, A. J. Dobbs, and N. Williams, *Ecotox. Environ. Safety* **11**, 251 (1986).
- ⁹⁵J. Sangster and A. D. Pelton, *J. Phys. Chem. Ref. Data* **16**, 509 (1987).
- ⁹⁶W. J. Lyman, W. F. Reehl, and D. H. Rosenblatt, *Handbook of Chemical Property Estimation Methods* (McGraw-Hill, New York, 1982).
- ⁹⁷J. M. Mayer, H. van de Waterbeemd, and B. Testa, *Eur. J. Chem.-Chim. Ther.* **17**, 17 (1982).
- ⁹⁸S. J. Lewis, M. S. Mirrlees, and P. J. Taylor, *Quant. Struct.-Act. Relat. Pharmacol. Chem. Biol.* **2**, 100 (1983).
- ⁹⁹M. J. Kamlet, R. M. Doherty, P. W. Carr, D. Mackay, M. H. Abraham, and R. W. Taft, *Environ. Sci. Technol.* **22**, 503 (1988).
- ¹⁰⁰G. Kortüm, W. Vogel, and K. Andrussow, *Dissociation Constants of Organic Acids in Aqueous Solution* (Butterworths, London, 1961).
- ¹⁰¹E. P. Serjeant and B. Dempsey, *Ionisation Constants of Organic Acids in Aqueous Solution* (Pergamon, Oxford, 1979).
- ¹⁰²D. Perrin, *Dissociation Constants of Organic Bases in Aqueous Solution* (Butterworths, London, 1965).
- ¹⁰³D. D. Perrin, *Dissociation Constants of Organic Bases in Aqueous Solution*, Supplement (Butterworths, London, 1972).
- ¹⁰⁴Personal communication to or unpublished data in Pomona College Medicinal Chemistry Project (Log P Database).
- ¹⁰⁵G. G. Nys and R. F. Rekker, *Chim. Ther.* **8**, 521 (1973).
- ¹⁰⁶R. F. Platford, *Bull. Environ. Contam. Toxicol.* **21**, 68 (1979).
- ¹⁰⁷R. Mascarenhas, M. A. Sc. thesis, University of Toronto, 1978.
- ¹⁰⁸S. Banerjee, S. H. Yalkowsky, and S. C. Valvani, *Environ. Sci. Technol.* **14**, 1227 (1980).
- ¹⁰⁹M. Coates, D. W. Connell, and D. M. Barron, *Environ. Sci. Technol.* **19**, 628 (1985).
- ¹¹⁰H. Geyer, G. Politzki, and D. Freitag, *Chemosphere* **13**, 269 (1984).
- ¹¹¹C. Hansch and S. M. Anderson, *J. Org. Chem.* **32**, 2583 (1967).
- ¹¹²H. Könemann, R. Zelle, F. Busser, and W. E. Hammers, *J. Chromatogr.* **178**, 559 (1979).
- ¹¹³S. W. Karickhoff, D. S. Brown, and T. A. Scott, *Water Res.* **13**, 241 (1979).
- ¹¹⁴H. Watarai, M. Tanaka, and N. Suzuki, *Anal. Chem.* **54**, 702 (1982).
- ¹¹⁵N. El Tayar, H. van de Waterbeemd, M. Gryllaki, B. Testa, and W. F. Trager, *Int. J. Pharmaceut.* **19**, 271 (1984).
- ¹¹⁶G. R. B. Webster, L. P. Sarna, and D. C. G. Muir, "Octanol-water Partition Coefficient of 1,3,6,8-tetrachlorodibenzo-p-dioxin and Octachlorodibenzo-p-dioxin," in *Chlorinated Dioxins and Dibenzofurans in the Total Environment*, edited by L. H. Keith, C. Rappe, and G. Choudhary, Editors (Butterworths, London, 1985), Vol 2.
- ¹¹⁷K. S. Rogers, *Proc. Soc. Expt. Biol. Med.* **130**, 1140 (1969).
- ¹¹⁸A. Nahum and C. Horvath, *J. Chromatogr.* **192**, 315 (1980).
- ¹¹⁹L. Wang, X. Wang, O. Xu, and L. Tian, *Huanjing Xuebao* **6**, 491 (1986).
- ¹²⁰J. Iwasa, T. Fujita, and C. Hansch, *J. Med. Chem.* **8**, 150 (1965).
- ¹²¹W. E. Hammers, G. J. Meurs, and C. L. DeLigny, *J. Chromatogr.* **247**, 1 (1982).
- ¹²²M. D'Amboise and T. Hanai, *J. Liquid Chromatogr.* **5**, 229 (1982).
- ¹²³J. E. Garst, *J. Pharm. Sci.* **73**, 1623 (1984).
- ¹²⁴C. Hansch and T. Fjita, *J. Am. Chem. Soc.* **86**, 1616 (1964).
- ¹²⁵C. Hansch, K. Nakamoto, M. Gorin, P. Denisevich, E. R. Garrett, S. M. Heman-Ackah, and C. H. Won, *J. Med. Chem.* **16**, 917 (1973).
- ¹²⁶T. Krishnamurthy, and S. P. Wasik, *J. Environ. Sci. Health A* **13**, 595 (1978).
- ¹²⁷M. R. Lichtenwalner and T. J. Speaker, *J. Pharm. Sci.* **69**, 337 (1980).
- ¹²⁸R. A. Rapaport and S. J. Eisenreich, *Environ. Sci. Technol.* **18**, 163 (1984).
- ¹²⁹K. B. Woodburn, W. J. Doucette, and A. W. Andren, *Environ. Sci. Technol.* **18**, 457 (1984).
- ¹³⁰A. C. DeKock and D. A. Lord, *Chemosphere* **16**, 133 (1987).
- ¹³¹W. Wang, L. Wang, L. Tian, Z. Zhang, and J. Qiu, *Huazhong Gong Xueyuan Xuebao* **15**, 135 (1987).
- ¹³²J. E. Haky and B. Leja, *Anal. Letters* **19**, 123 (1986).
- ¹³³J. C. Means, S. G. Wood, J. J. Hassett, and W. L. Banwart, *Environ. Sci. Technol.* **14**, 1524 (1980).
- ¹³⁴J. C. Means, J. J. Hassett, S. G. Wood, and W. L. Banwart, "Sorption properties of energy-related pollutants and sediments", in *Polynuclear Aromatic Hydrocarbons*, edited by P. W. Jones and P. Leber, (Ann Arbor Science, Ann Arbor, 1979).
- ¹³⁵C. T. Chiou, V. H. Freed, D. W. Schmedding, and R. L. Kohnert, *Environ. Sci. Technol.* **11**, 475 (1977).
- ¹³⁶B. Scheele, *Chemosphere* **9**, 293 (1980).
- ¹³⁷B. J. Mallon and F. L. Harrison, *Bull. Environ. Contam. Toxicol.* **32**, 316 (1984).
- ¹³⁸L. P. Sarna, P. E. Hodge, and G. R. B. Webster, *Chemosphere* **13**, 975 (1984).
- ¹³⁹J. H. Canton and R. C. C. Wegman, *Water Res.* **17**, 743 (1983).
- ¹⁴⁰R. L. E. Ehrenkaufer, B. W. Agranoff, J. Bieszki, K. Frey, S. Hays, and D. Jewett, *J. Label. Compounds Radiopharm.* **21**, 87 (1984).
- ¹⁴¹B. McDuffie, *Chemosphere* **10**, 73 (1981).
- ¹⁴²C. V. Eadsforth and P. Moser, *OECD Guideline PC No. 84.1*, Organization for Economic Co-operation and Development, 1984; see also Refs. 92 and 104.
- ¹⁴³S. J. Lewis, M. S. Mirrlees, and P. J. Taylor, *Quant. Struct.-Act. Relat. Pharmacol. Chem. Biol.* **2**, 1 (1983).
- ¹⁴⁴S. Fujisawa and E. Masuhara, *J. Biomed. Mater. Res.* **15**, 787 (1981).
- ¹⁴⁵D. McLachlan, T. Arnason, and J. Lam, *Biochem. Systematics Ecol.* **14**, 17 (1986).
- ¹⁴⁶H. Ellgehausen, C. d'Hondt, and R. Fuerer, *Pestic. Sci.* **12**, 219 (1981).
- ¹⁴⁷R. Collander, *Acta Chem. Scand.* **5**, 774 (1951).
- ¹⁴⁸R. Collander, *Acta Chem. Scand.* **3**, 717 (1949).
- ¹⁴⁹R. Serrentino, L. Citti, P. G. Gervasi, and G. Turchi, *Ital. J. Biochem.* **32**, 111 (1983).
- ¹⁵⁰P.-Y. Lu and R. L. Metcalf, *Environ. Health Perspect.* **10**, 269 (1975).
- ¹⁵¹P. Pratesi, L. Villa, V. Ferri, C. de Micheli, E. Grana, C. Grieco, C. Silipo, and A. Vittoria, *Il Farmaco Ed. Sci.* **34**, 579 (1979).
- ¹⁵²N. Funasaki, S. Hada, S. Neya, and K. Machida, *J. Phys. Chem.* **88**, 5786 (1984).
- ¹⁵³J. Takeda, H. Morikawa, H. Kinoshita, and M. Senda, *Plant Cell Physiol.* **12**, 949 (1971).
- ¹⁵⁴L. S. Yaguzhinskii, E. G. Smirnova, L. A. Ratnikova, G. M. Kolesova, and I. P. Krasinskaya, *J. Bioenerg.* **5**, 163 (1973).
- ¹⁵⁵N. F. H. Ho, J. Y. Park, W. Morozowich, and W. I. Higuchi, "Physical model approach to the design of drugs with improved intestinal absorption", in *Design and Biopharmaceutical Properties of Prodrugs Analogs*, edited by E. B. Roche, (American Pharmaceutical Association, Washington, 1977).
- ¹⁵⁶E. M. Cornford, *J. Membr. Biol.* **64**, 217 (1982).
- ¹⁵⁷G. M. Grass and J. R. Robinson, *J. Pharm. Sci.* **73**, 1021 (1984).
- ¹⁵⁸W. Riebesehl, E. Tomlinson, and H. J. M. Grünbauer, *J. Phys. Chem.* **88**, 4775 (1984).
- ¹⁵⁹E. O. Dillingham, R. W. Mast, G. E. Bass, and J. Autian, *J. Pharm. Sci.* **62**, 22 (1973).
- ¹⁶⁰J. W. Roddy, *Ind. Eng. Chem. Process Des. Dev.* **20**, 104 (1981).
- ¹⁶¹L. G. Herbette, D. W. Chester, and D. G. Rhodes, *Biophys. J.* **49**, 91 (1986).
- ¹⁶²C. Bluestein and H. N. Posmantner, *Anal. Chem.* **38**, 1865 (1966).
- ¹⁶³C. Hansch, R. M. Muir, T. Fujita, P. P. Maloney, F. Geiger, and M. Streich, *J. Am. Chem. Soc.* **85**, 2817 (1963).
- ¹⁶⁴N. Funasaki, S. Hada, and S. Neya, *J. Chromatogr.* **361**, 33 (1986).
- ¹⁶⁵Y. Yonezawa and Y. Urushigawa, *Chemosphere* **8**, 139 (1979).
- ¹⁶⁶R. M. Carlson, R. E. Carlson, and H. L. Kopperman, *J. Chromatogr.* **107**, 219 (1975).
- ¹⁶⁷C. Hansch, A. Steward, S. Anderson, and D. Bentley, *J. Med. Chem.* **11**, 1 (1968).
- ¹⁶⁸H. Machleidt, S. Roth, and P. Seeman, *Biochim. Biophys. Acta* **255**, 178 (1972).
- ¹⁶⁹I. F. Skidmore and M. W. Whitehouse, *Biochem. Pharmacol.* **14**, 547 (1965).
- ¹⁷⁰Ya. I. Korenman, *Russ. J. Phys. Chem. (Engl. Transl.)* **46**, 42 (1972).
- ¹⁷¹H. Umeyama, T. Nagai, and H. Nogami, *Chem. Pharm. Bull.* **19**, 1714 (1971).
- ¹⁷²H. P. A. Illing and D. Benford, *Biochim. Biophys. Acta* **429**, 768 (1976).
- ¹⁷³E. Freese, B. C. Levin, R. Pearce, T. Sreevalsan, J. J. Kaufman, W. S. Koski, and N. M. Semo, *Teratology* **20**, 413 (1979).
- ¹⁷⁴W. Butte, C. Fooken, R. Klussmann, and D. Schuller, *J. Chromatogr.* **214**, 59 (1981).
- ¹⁷⁵A. Leo, C. Hansch, and C. Church, *J. Med. Chem.* **12**, 766 (1969).
- ¹⁷⁶P. R. Kiezyk and D. Mackay, *Can. J. Chem. Eng.* **49**, 747 (1971).
- ¹⁷⁷I. Kojima and S. S. Davis, *Int. J. Pharm.* **20**, 247 (1984).
- ¹⁷⁸P. R. Kiezyk, M. A. Sc. thesis, University of Toronto, 1971.
- ¹⁷⁹J. M. Mayer, B. Testa, H. van de Waterbeemd, and A. Bornand-Crausaz, *Eur. J. Med. Chem.* **17**, 453 (1982).
- ¹⁸⁰Ya. I. Korenman and V. V. Pereshein, *J. Appl. Chem. USSR (Engl. Transl.)* **43**, 1421 (1970).
- ¹⁸¹Ya. I. Korenman, E. M. Tishchenko, and N. N. Sel'manshchuk, *Russ. J. Phys. Chem. (Engl. Transl.)* **54**, 745 (1980).
- ¹⁸²Ya. I. Korenman, *J. Appl. Chem. USSR (Engl. Transl.)* **46**, 394 (1973).

- ¹⁸³Ya. I. Korenman and V. V. Pereshein, *J. Appl. Chem. USSR* (Engl. Transl.) **43**, 1421 (1970).
- ¹⁸⁴R. F. Platford, *Chemosphere* **12**, 1107 (1983).
- ¹⁸⁵Ya. I. Korenman, I. I. Butyaeva, and M. M. Gel'fand, *J. Appl. Chem. USSR* (Engl. Transl.) **47**, 475 (1974).
- ¹⁸⁶L. K. J. Tong and M. C. Glesmann, *J. Am. Chem. Soc.* **79** 4305 (1957).
- ¹⁸⁷M. Stockdale and M. J. Selwyn, *Eur. J. Biochem.* **21**, 565 (1971).
- ¹⁸⁸H. G. Johnson and E. L. Piret, *Ind. Eng. Chem.* **40**, 743 (1948).
- ¹⁸⁹S. H. Unger, J. R. Cook, and J. S. Hollenberg, *J. Pharm. Sci.* **67**, 1364 (1978).
- ¹⁹⁰H. L. Holmes and C. E. Lough, "Effect of Intramolecular Hydrogen Bonding on Partition Coefficients", Suffield Technical Note No. DRES-TN-365, Defence Research Establishment Suffield/Information Canada, U.S. NTIS Report No. AD-A030683, 1976.
- ¹⁹¹D. J. Currie, C. E. Lough, R. F. Silver, and H. L. Holmes, *Can. J. Chem.* **44**, 1035 (1966).
- ¹⁹²F. E. Norrington, R. M. Hyde, S. G. Williams, and R. Wootton, *J. Med. Chem.* **18**, 604 (1975).
- ¹⁹³H. Tanii, H. Tsuji, and K. Hashimoto, *Toxicol. Letters* **30**, 13 (1986).
- ¹⁹⁴H. Tanii and K. Hashimoto, *Toxicol. Letters* **11**, 125 (1982).
- ¹⁹⁵J. D. Chapman, J. A. Raleigh, J. Borsa, R. G. Webb, and R. Whitehouse, *Int. J. Radiat. Biol.* **21**, 475 (1972).
- ¹⁹⁶A. Lazare, C. Lazare, J. Bastide, and J. Couquelet, *Ann. Pharm. Franc.* **32**, 677 (1974).
- ¹⁹⁷A. Khan, J. J. Hassett, W. L. Banwart, J. C. Means, and S. G. Wood, *Soil Sci.* **128**, 297 (1979).
- ¹⁹⁸J. C. Means, EPA Report No. 600/3-80-041, 1980; see Ref. 104.
- ¹⁹⁹C. E. Lough, Suffield Memorandum 17, 1971; see Ref. 104.
- ²⁰⁰K. E. Whitehead and C. J. Geankoplis, *Ind. Eng. Chem.* **47**, 2114 (1955).
- ²⁰¹R. H. Leonard, W. H. Peterson, and M. J. Johnson, *Ind. Eng. Chem.* **40**, 57 (1948).
- ²⁰²R. V. Wolfenden, *Biochem.* **17**, 201 (1978).
- ²⁰³J. B. Umland, *J. Chem. Ed.* **60**, 1081 (1983).
- ²⁰⁴J. A. Moore, J. L. Dalrymple, and O. R. Rodig, *Experimental Methods in Organic Chemistry*, 3rd ed. (Saunders College Publishing, New York, 1982).
- ²⁰⁵I. M. Korenman, E. V. Lunicheva, E. G. Pomerantseva, and F. D. Khairulina, *J. Appl. Chem. USSR* (Engl. Transl.) **47**, 2432 (1974).
- ²⁰⁶P. E. Keane, J. Simiand, E. Mendes, V. Santucci, and M. Morre, *Neuropharmacology* **22**, 875 (1983).
- ²⁰⁷K. Nishimura, Y. Nozaki, A. Yoshimi, S. Nakamura, M. Kitagawa, N. Kakeya, and K. Kitao, *Chem. Pharm. Bull.* **33**, 282 (1985).
- ²⁰⁸J. Halmekoski and H. Hannikainen, *Suom. Kemistil.* **37**, 221 (1964).
- ²⁰⁹F. H. Clarke and N. M. Cahoon, *J. Pharm. Sci.* **76**, 611 (1987).
- ²¹⁰J. A. Plaizer-Vercammen, *J. Pharm. Sci.* **76**, 817 (1987).
- ²¹¹M. Laznicek, J. Kvetina, J. Mazak, and V. Krch, *J. Pharm. Pharmacol.* **39**, 79 (1987).
- ²¹²K. Bowden and R. C. Young, *J. Med. Chem.* **13**, 225 (1970).
- ²¹³M. Kuchar, V. Rejholec, B. Brunova, J. Grimova, O. Matousova, O. Nemecik, and H. Cepelakova, *Coll. Czech. Chem. Commun.* **47**, 2514 (1982).
- ²¹⁴J. M. Wolosin and H. Ginsburg, *Biochim. Biophys. Acta* **389**, 20 (1975).
- ²¹⁵H. Tomida, T. Yotsuyanagi, and K. Ikeda, *Chem. Pharm. Bull.* **26**, 2824 (1978).
- ²¹⁶X.-R. Xu, H. Xu, Y.-A. Lu, and J. Chen, *Yao Hsueh Hsueh Po* **14**, 246 (1979).
- ²¹⁷J. C. Means, S. G. Wood, J. J. Hassett, and W. L. Banwart, *Environ. Sci. Technol.* **16**, 93 (1982).
- ²¹⁸S. Fujisawa and E. Masuhara, *J. Den. Res.* **59**, 2056 (1980).
- ²¹⁹S. Nakagawa, N. Okajima, T. Kitahaba, K. Nishimura, T. Fujita, and M. Nakajima, *Pestic. Biochem. Physiol.* **17**, 243 (1982).
- ²²⁰H. Z. Yang, M. Nishimura, K. Nishimura, S. Kuroda, and T. Fujita, *Pestic. Biochem. Physiol.* **29**, 217 (1987).
- ²²¹N. M. Nielsen and H. Bundgaard, *J. Pharm. Sci.* **77**, 285 (1988).
- ²²²A. L. J. DeMeere, P. J. Taylor, H. J. M. Grünbauer, and E. Tomlinson, *Int. J. Pharm.* **31**, 209 (1986).
- ²²³A. L. J. DeMeere, "Drug Absorption Through Artificial Membranes," (1985) (unpublished) see Ref. 104.
- ²²⁴M. Tichy, *Collect. Czech. Chem. Commun.* **39**, 935 (1974).
- ²²⁵M. Uchida, T. Fujita, and M. Nakajima, *Pestic. Biochem. Physiol.* **2**, 383 (1973).
- ²²⁶A. Opperhuizen, *Toxicol. Environ. Chem.* **15**, 249 (1987).
- ²²⁷P. Isnard and S. Lambert, *Chemosphere* **17**, 21 (1988).
- ²²⁸M. T. M. Tulp and O. Hutzinger, *Chemosphere* **7**, 849 (1978).
- ²²⁹E. E. Kenaga and C. A. I. Goring, "Relationship between water solubility, soil sorption, octanol-water partitioning and bioconcentration of chemicals in biota," in *Proceedings 3rd Aquatic Toxicology Symposium*, New Orleans, 1978, ASTM-STP No. 707 (American Society for Testing and Materials, Philadelphia, 1980).
- ²³⁰I. M. Korenman, N. Yu. Gurevich, and T. G. Kulagina, *J. Appl. Chem. USSR* (Engl. Transl.) **46**, 726 (1973).
- ²³¹K. B. Sandell, *Naturwissenschaften* **49**, 12 (1962).
- ²³²K. B. Sandell, *Monatsh. Chem.* **89**, 36 (1958).
- ²³³J. S. Fowler, B. M. Gallagher, R. R. MacGregor, and A. R. Wolf, *J. Pharm. Exp. Ther.* **198**, 133 (1976).
- ²³⁴P. J. Gehring, T. R. Torkelson, and F. Oyen, *Toxicol. Appl. Pharmacol.* **11**, 361 (1967).
- ²³⁵K. C. Yeh and W. I. Higuchi, *J. Pharm. Sci.* **65**, 80 (1976).
- ²³⁶O. E. Schultz, C. Jung, and K. E. Möller, *Z. Naturforsch. B* **25**, 1024 (1970).
- ²³⁷K. Kishida and T. Otori, *Jpn. J. Ophthalmol.* **24**, 251 (1980).
- ²³⁸A. Martin-Villodre, J. M. Pla-Delfina, J. Moreno, M. D. Perez-Buendia, J. Miralles, E. F. Collado, E. Sanchez-Moyano, and A. Del Pozo, *J. Pharmacokinet. Biopharm.* **14**, 615 (1986).
- ²³⁹K. Kimura, M. Nagaoka, H. Agatsuma, and S. Ohgiya, *Yakugaku Zasshi* **99**, 235 (1979).
- ²⁴⁰T. J. Janjic, E. B. Milosavljevic, and W. Nanayakkara, *Analisis* **10**, 197 (1982).
- ²⁴¹M. Katayama, M. Yamamoto, S. Kobayashi, K. Oguchi, and H. Yasuhara, *J. Pharm. Pharmacol.* **38**, 382 (1986).
- ²⁴²Y. Ichikawa, T. Yamano, and H. Fujishima, *Biochim. Biophys. Acta* **171**, 32 (1969).
- ²⁴³G. L. Grunewald, M. A. Pleiss, C. L. Gatchell, R. Pazhenchovsky, and M. F. Rafferty, *J. Chromatogr.* **292**, 319 (1984).
- ²⁴⁴D. E. Nichols, A. T. Shulgin, and D. C. Dyer, *Life Sci.* **21**, 569 (1977).
- ²⁴⁵F. Mack and H. Bönisch, *Naunyn-Schmiederberg's Arch. Pharmacol.* **310**, 1 (1979).
- ²⁴⁶H. Lentzen and A. Philippu, *Biochem. Pharmacol.* **30**, 1759 (1981).
- ²⁴⁷B. G. A. Lindeke, U. Paulsen-Sörman, G. Hallström, A.-H. Khuthier, A. K. Cho, and R. C. Kammerer, *Drug Metab. Dispos.* **10**, 700 (1982).
- ²⁴⁸C. F. Barfknecht, D. E. Nichols, and W. J. Dunn, *J. Med. Chem.* **18**, 208 (1975).
- ²⁴⁹J. P. Liberti and K. S. Rogers, *Biochim. Biophys. Acta* **222**, 90 (1970).
- ²⁵⁰V. G. Granik, R. A. Al'tshuler, I. V. Persianova, M. D. Mashkovskii, and Yu. N. Sheinker, *Farmak. Toksikol. (Moscow)* **40**, 31 (1977).
- ²⁵¹R. M. Bartholow, L. E. Eiden, J. A. Ruth, G. L. Grunewald, J. Siebert, and C. O. Rutledge, *J. Pharmacol. Exp. Ther.* **202**, 532 (1977).
- ²⁵²K. C. Yeh and W. I. Higuchi, *J. Pharm. Sci.* **61**, 1648 (1972).
- ²⁵³R. A. Maxwell, R. M. Ferris, J. Burcsu, E. C. Woodward, D. Tang, and K. Williard, *J. Pharmacol. Exp. Ther.* **191**, 418 (1974).
- ²⁵⁴M. A. Pleiss and G. L. Grunewald, *J. Med. Chem.* **26**, 1760 (1983).
- ²⁵⁵S. H. Unger and G. H. Chiang, *J. Med. Chem.* **24**, 262 (1981).
- ²⁵⁶S. Ozeki and K. Tejima, *Chem. Pharm. Bull.* **27**, 638 (1979).
- ²⁵⁷H. Tanii and K. Hashimoto, *Arch. Toxicol.* **55**, 47 (1984).
- ²⁵⁸T. Sotomatsu, Y. Nakagawa, and T. Fujita, *Pestic. Biochem. Physiol.* **27**, 156 (1987).
- ²⁵⁹J. Fastrez and A. R. Fersht, *Biochem.* **12**, 1067 (1973).
- ²⁶⁰M. Johansen and H. Bundgaard, *Arch. Pharm. Chem. Sci. Ed.* **8**, 141 (1980).
- ²⁶¹R. P. Moody, J. M. Carroll, and A. M. E. Kresta, *Toxicol. Ind. Health* **3**, 479 (1987).
- ²⁶²C. Takayama, A. Fujinami, O. Kirino, and Y. Hisada, *Agr. Biol. Chem.* **46**, 2755 (1982).
- ²⁶³C. Takayama and A. Fujinami, *Pestic. Biochem. Physiol.* **12**, 163 (1979).
- ²⁶⁴F. F. Cantwell and H. Y. Mohammed, *Anal. Chem.* **51**, 218 (1979).
- ²⁶⁵S. Banerjee and P. H. Howard, *Environ. Sci. Technol.* **22**, 839 (1988).